



User manual



Quick start



Hardware



Configuration



Parameters



fw 4.4.x.x
2020-4-23
version 1.5

Table of Contents

Important Notice	5
Getting started	6
1. M!DGE router	7
1.1. Introduction	7
1.2. Key features	7
1.3. Standards	8
2. M!DGE in detail	9
3. Implementation notes	11
3.1. Ethernet SCADA protocols	11
3.2. Serial SCADA protocols	11
3.3. Network center	11
3.4. VPN tunnels	11
4. Product	12
4.1. Dimensions	12
4.2. Connectors	12
4.3. Indication LEDs	18
4.4. Technical specifications	19
4.5. Model offerings	22
4.6. Accessories	24
5. Bench test / Step-by-Step guide	25
5.1. Connecting the hardware	25
5.2. Powering up your wireless router	25
5.3. Connecting M!DGE to a programming PC	25
5.4. Basic setup	26
6. Installation	27
6.1. Mounting	27
6.2. Antenna mounting	27
6.3. Power supply	27
7. Web Configuration	28
7.1. HOME	28
7.2. INTERFACES	29
7.3. ROUTING	69
7.4. FIREWALL	83
7.5. VPN	88
7.6. SERVICES	102
7.7. SYSTEM	138
7.8. LOGOUT	160
8. Command Line Interface	161
8.1. General usage	162
8.2. Print help	163
8.3. Getting config parameters	163
8.4. Setting config parameters	164
8.5. Updating system facilities	164
8.6. Manage keys and certificates	164
8.7. Getting status information	165
8.8. Scan	166
8.9. Sending e-mail or SMS	167
8.10. Restarting services	167
8.11. Debug	168
8.12. Resetting system	168
8.13. Rebooting system	169

8.14. Running shell commands	169
8.15. CLI commands history	169
8.16. CLI-PHP	169
9. Troubleshooting	175
9.1. Common errors	175
9.2. Messages	175
9.3. Troubleshooting tools	175
10. Safety, environment, licensing	177
10.1. Safety instructions	177
10.2. RoHS and WEEE compliance	178
10.3. EU Declaration of Conformity	180
10.4. Country of Origin	183
10.5. Warranty	184
A. Glossary	185
Index	187
Revision History	189

List of Figures

1. Cellular router M!DGE	6
2.1. M!DGE front and terminal panel	9
4.1. Dimensions in millimeters	12
4.2. Antenna connectors SMA	12
4.3. 4× Eth RJ45 Plug	13
4.4. MicroSIM cards slots	15
4.5. Screw terminal	15
4.6. Reset button	17
4.7. Indication LEDs	18
4.8. Flat bracket	24
4.9. Flat bracket dimensions	24
10.1. EU Declaration of Conformity RoHS, WEEE	179
10.2. EU Declaration of Conformity	180
10.3. Country of Origin declaration	183

List of Tables

4.1. Pin assignment Ethernet interface	13
4.2. Ethernet Port Specification	13
4.3. USB 2.0 Host Port Specification	13
4.4. USB pin description	14
4.5. Screw terminal pin assignment	16
4.6. Digital input levels	16
4.7. Digital output parameters	16
4.8. M!DGE interfaces and status indicators	18
4.9. Technical specifications	19

Important Notice

Copyright

© 2020 RACOM. All rights reserved.

Products offered may contain software proprietary to RACOM s. r. o. (further referred to under the abbreviated name RACOM). The offer of supply of these products and services does not include or imply any transfer of ownership. No part of the documentation or information supplied may be divulged to any third party without the express written consent of RACOM.

Disclaimer

Although every precaution has been taken in preparing this information, RACOM assumes no liability for errors and omissions, or any damages resulting from the use of this information. This document or the equipment may be modified without notice, in the interests of improving the product.

Trademark

All trademarks and product names are the property of their respective owners.

Important Notice

- Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e. have errors), or be totally lost. Significant delays or losses of data are rare when wireless devices such as the M!DGE are used in an appropriate manner within a well-constructed network. M!DGE should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. RACOM accepts no liability for damages of any kind resulting from delays or errors in data transmitted or received using M!DGE, or for the failure of M!DGE to transmit or receive such data.
- Under no circumstances is RACOM or any other company or person responsible for incidental, accidental or related damage arising as a result of the use of this product. RACOM does not provide the user with any form of guarantee containing assurance of the suitability and fit for purpose.
- RACOM products are not developed, designed or tested for use in applications which may directly affect health and/or life functions of humans or animals, nor to be a component of similarly important systems, and RACOM does not provide any guarantee when company products are used in such applications.

Getting started

M!DGE Wireless Router will only operate reliably over the cellular network if there is a strong signal. For many applications a flexible stub antenna would be suitable but in some circumstances it may be necessary to use a remote antenna with an extension cable to allow the antenna itself to be positioned so as to provide the best possible signal reception.

1. Install the SIM card

Insert a SIM card into the SIM socket. Make sure the SIM is enabled for data transmission.

2. Connect and fit the cellular antenna

If needed, contact RACOM for suitable antennas and other details.

3. Connect the LAN cable

Connect one M!DGE Ethernet port to your computer using an Ethernet cat.5 cable.

4. Connect the power supply

Connect the power supply wires to the M!DGE screw terminals, ensuring correct polarity. Switch on the power supply.

5. Setting of IP address of the connected computer

By default the DHCP server is enabled, thus you can allow the Dynamic Host Configuration Protocol (DHCP) on your computer to lease an IP address from the M!DGE. Wait approximately 20 seconds until your computer has received the parameters (IP address, subnet mask, default gateway, DNS server).

As an alternative you can configure a static IP address on your PC (e.g. 192.168.1.2/24) so that it is operating in the same subnet as the M!DGE. The M!DGE default IP address for the first Ethernet interface is 192.168.1.1, the subnet mask is 255.255.255.0.

6. Start setting up using a web browser

Open a web browser such as Internet Explorer or Firefox. In the address field of the web browser, enter default IP address of M!DGE (i.e. <http://192.168.1.1>); initial screen will appear. Follow the instructions and use the M!DGE Web Manager to configure the device.



Fig. 1: Cellular router M!DGE



Note

M!DGE can be safely turned off by unplugging the power supply.

1. M!DGE router

1.1. Introduction

Although M!DGE wireless routers have been specifically designed for SCADA and telemetry, they are well suited to a variety of wireless applications. M!DGE HW and SW are ready to maintain reliable and secure connections from a virtually unlimited number of remote locations to a central server. Both standard Ethernet/IP and serial interfaces are available. Moreover, a digital input and a digital output can be used for direct monitoring and control of application devices; the second DI and DO are available using an extension module.

M!DGE versatility is further enhanced by four independent Ethernet ports. These can be configured to either support independent LANs (e.g. LAN and WAN settings), or simply connect up to four devices within one LAN (effectively replacing an Eth switch). M!DGE software is based on proven components, including an Embedded Linux operating system and standard TCP/IP communication protocols.

Thanks to the compact size and versatility of M!DGE, wireless routers prove indispensable in many SCADA and telemetry, as well as POS, ATM, lottery and security/surveillance applications.

M!DGE together with RACOM RipEX radio router offers an unrivalled solution for combining cellular and UHF/VHF licensed radios in a single network.

1.2. Key features

Mobile Interface Parameters

- Mobile Connection options: LTE, HSPA+, HSDPA, HSUPA, UMTS, EDGE, GPRS and GSM
- Global connectivity
- Transparent hand-over between 2G, 3G and 4G

Power supply

- Input voltage: 12 – 24 VDC
- Average power consumption: 7 W

Services / Networking

- Fallback Management
- Connection supervision, Automatic connection recovery
- Quality of Service (QoS)
- OpenVPN, IPsec, PPTP, GRE, Dial-In, Mobile IP
- VRRP
- OSPF, BGP
- DHCP server, DNS proxy server, DNS update agent, NTP
- Telnet server, SSH server, Web server
- Device server, Protocol server, SDK, LXC containers
- Port Forwarding (NAPT), Firewall, Access Control Lists
- Modbus TCP - Modbus RTU conversion

Interfaces

- 4 Ethernet ports: LAN, WAN/LAN
- RS232
- 1× DI, 1× DO
- USB host

Diagnostic and Management

- Web interface, CLI available
- File configuration
- OTA SW update
- Advanced troubleshooting
- SMS remote control, SMS and E-mail notification
- SNMPv1/v2c/3

1.3. Standards

Safety / Health	EN 62368-1:2014
	EN 62311:2008
EMC	EN 55032:2015
	EN 55035:2017
	EN 61000-6-2:2016
	EN 61000-6-3:2007+A1:2011+AC:2012
	EN 301 489-1 V2.1.1
	EN 301 489-3 V2.1.1
	EN 301 489-7 V1.3.1
	EN 301 489-17 V3.2.0
	EN 301 489-24 V1.5.1
	EN 301 489-52 V1.1.1
RF Spectrum	EN 300 328 V2.1.1
	EN 301 511 V9.0.2
	EN 301 908-1 V11.1.1
	EN 301 908-2 V11.1.1
	EN 301 908-13 V11.1.1
Vibration & shock	EN 60068-2-6:2008
	ETS 300 019-2-3:1994, Class 3.4
	EN 61850-3:2014
Seismic	EN 60068-2-27:2010
Environmental	EN 61850-3:2014
	IEEE 1613:2009

2. M!DGE in detail



Fig. 2.1: M!DGE front and terminal panel

All M!DGE Wireless Routers run M!DGE Software. Software offers the following key features:

- Interfaces and Connection Management (*Section 7.2, "INTERFACES"*)
 - Dial-out (permanent, on switchover, distributed)
 - Link Supervision
 - Fallback to backup profile
 - SIM and PIN management
 - Automatic or manual network selection
 - Ethernet (LAN, WAN, bridging, IP passthrough, VLAN management)
 - Bridges
 - USB (autorun, device server)
 - Serial port (login console, device server, protocol server, SDK, Modem bridge, Modem emulator)
 - Digital I/O
- Routing (*Section 7.3, "ROUTING"*)
 - Static Routing
 - Extended Routing
 - Multipath Routes
 - Multicast
 - BGP
 - OSPF
 - Mobile IP
 - Quality of Service (QoS)
- Security / Firewall (*Section 7.4, "FIREWALL"*)
 - NAT / Port Forwarding
 - Stateful Inspection Firewall
 - Firewall
- Virtual Private Networking (VPN) (*Section 7.5, "VPN"*)
 - OpenVPN Server/Client
 - IPsec Peer
 - PPTP Server/Client
 - GRE Peer
- Services (*Section 7.6, "SERVICES"*)

- SDK
- NTP Server
- DHCP Server
- DNS Server
- Dynamic DNS Client
- E-mail Client
- Notification via E-mail and SMS
- SMS Client
- SSH/Telnet Server
- SNMP Agent
- Web Server
- Redundancy
- Modbus TCP
- Discovery
- Terminal server
- LXC containers
- System Administration (*Section 7.7, "SYSTEM"*)
 - Configuration via Web Manager
 - Configuration via Command Line Interface (CLI) accessible via Secure Shell (SSH) and telnet
 - Batch configuration with text files
 - User administration
 - Troubleshooting tools
 - Over the air software update
 - Licensing (extra features)
 - Keys and certificates (HTTPS, SSH, OpenVPN, ...)
 - Legal Notice

3. Implementation notes

3.1. Ethernet SCADA protocols

SCADA equipment with an Ethernet protocol behaves as standard Ethernet equipment from a communications perspective. Thus the communication goes transparently through the cellular network. The implementation requires heightened caution to IP addressing and routing. NAT functionality should be used frequently.

3.2. Serial SCADA protocols

A SCADA serial protocol typically uses simple 8 or 16 bit addressing. The mobile network address scheme is an IP network, where range is defined by the service provider (sometimes including individual addresses, even in the case of a private APN). Consequently, a mechanism of translation between SCADA and the IP addresses is required. To make matters worse, IP addresses may be assigned to GPRS (EDGE, UMTS, etc.) devices dynamically upon each connection.

Please read application note "*M!DGE/MG102i - Serial SCADA Protocols*"¹ which describes how to efficiently solve this problem using RACOM routers.

3.3. Network center

In every network, the center plays a key role and has to be designed according to customer's requirements. Several possible solutions are described in the application note "*M!DGE/MG102i - Typical usage*"².

3.4. VPN tunnels

Customer data security arriving through the mobile network is often very important. Private APN is the basic security requirement, but not safe enough for such applications.

VPN tunnels solution is closely connected with the center and is also described in application note "*M!DGE/MG102i - VPN Configuration*"³.

¹ <https://www.racom.eu/eng/products/m/midge/app/scada.html>

² https://www.racom.eu/eng/products/m/midge/app/midge-mg102i_centre.html

³ https://www.racom.eu/eng/products/m/midge/app/VPN_config.html

4. Product

4.1. Dimensions




Fig. 4.1: Dimensions in millimeters

4.2. Connectors

4.2.1. Antenna SMA



Fig. 4.2: Antenna connectors SMA

The M!DGE router is equipped with two antenna connectors. The ANT connector serves as a main antenna connection, the AUX connector is auxiliary and serves for better communication with BTS (diversity).

4.2.2. 4× Eth RJ45



Fig. 4.3: 4× Eth RJ45 Plug

Tab. 4.1: Pin assignment Ethernet interface

RJ-45 Socket	ETH (Ethernet 10BaseT and 100BaseT)	
pin	signal	
1	TX+	
2	TX-	
3	RX+	
6	RX-	



Note

Pairs 4-5 and 7-8 have an internal 75 Ohm termination.

Tab. 4.2: Ethernet Port Specification

Feature	Specification
Speed	10/100 Mbps
Mode	TX-
Crossover	Automatic MDI/MDI-X

4.2.3. USB

MIDGE uses USB 2.0, Host A interface. USB interface is wired as standard:

Tab. 4.3: USB 2.0 Host Port Specification

Feature	Specification	
Speed	Low, Full & Hi-Speed	
Current	max. 500 mA	
Max. cable length	3 m	
Cable shield	mandatory	
Connector type	Type A	

Tab. 4.4: USB pin description

USB pin	signal	wire
1	+5 V	red
2	Data (-)	white
3	Data (+)	green
4	GND	black

4.2.4. MicroSIM cards



Fig. 4.4: MicroSIM cards slots

The M!DGE router is equipped with two MicroSIM (3FF) cards slots which are placed under a SIM card cover. Use PH0 screw driver for its opening. If using only one SIM card, use holder one.

The SIM card holder has a locking mechanism - for opening pull the front part of the holder down and then you can open it. After inserting of SIM card (cropped edge left, connectors down), close the holder and lock it.



Important

Power off the router before inserting the SIM card.

4.2.5. Screw terminal



Fig. 4.5: Screw terminal

Screw terminal plug types:

Phoenix Contact 1847204 (MC 1.5/10-STF-3.5) for 10 pins plug and

Phoenix Contact 1847181 (MC 1.5/ 8-STF-3.5) for 8 pins plug (or equivalent).

This EXT plug is delivered only for units equipped with internal extension module.

Nominal cross section: 1.5 mm²

Tab. 4.5: Screw terminal pin assignment

pin	pin description	signal
1	12-24 VDC +	Power input plus: 12–24 VDC (-20% +20 %) = 9.6–28.8 VDC
2	12-24 VDC -	Power input minus – internally connected with casing
3	RS232 GND	RS-232 GND (non-isolated)
4	RS232 RxD	RS-232 RxD (non-isolated)
5	RS232 TxD	RS-232 TxD (non-isolated)
6	DI -	Digital input - Negative signal input (isolated to GND)
7	DI +	Digital input - Positive signal input (isolated to GND)
8	DO NO	Digital Output isolated, Relay contact normally open
9	DO COM	Digital Output isolated, Relay common
10	DO NC	Digital Output isolated, Relay contact normally closed

Polarity Reversal protection circuit (PTC fuse) used on pin 1 and pin 2, but the reverse polarity with soft power supply could cause damage after a few minutes of wrong polarity attached.

Pins 2 and 3 Pins are internally connected.

Pins 6 and 7 are galvanically isolated (1.5 kVAC). If voltage between the + and – pins is bigger than 60 VDC, the input circuit could be damaged. Reversed polarity will not harm the circuit.

Tab. 4.6: Digital input levels

logical level 0	0 to 3 VDC
logical level 1	9 to 32 VDC
Note: Negative input voltage is not recognised.	

Tab. 4.7: Digital output parameters

Maximal continuous current	1 A
Maximal switching voltage	32 VDC
Maximal switching capacity	32 W

4.2.6. Reset button

The Reset button is placed close to the USB connector. Use a blunt tool no more than 1 mm in diameter (e.g. a paper clip) to press the button.

The reset button has two functions:

- Reboot the system
 - Press at least 3 seconds to release a system reboot.
 - The reboot is indicated with the red blinking STAT LED.
- Factory reset
 - Press at least 10 seconds to release a factory reset.
 - The start of the factory reset is confirmed by all LEDs lighting up GREEN for a second.
- Recovery procedure
 - Press at least 15 seconds to release a recovery procedure.
 - The start of the recovery procedure is confirmed by all LEDs lighting up RED for a second.




Fig. 4.6: Reset button



Note

Contact our technical support (support@racom.eu) for recovery procedure details and required files.

4.3. Indication LEDs




Fig. 4.7: Indication LEDs

The following table describes the default M!DGE status indicators.

Tab. 4.8: M!DGE interfaces and status indicators

Description	State	Function
STAT	green blinking	Device busy device is in startup, software or configuration update
	green on	Device is ready
WAN	off	Hotlink is disabled
	blinking	Hotlink connection is being established
	on	Hotlink connection is up
LAN	green	ETH: enabled as LAN and link status is up
	off	No ETH LAN-connection is up
VPN	green on	VPN connection is up
	green blinking	VPN connection is being established
	off	VPN connection down
EXT	on / off / blinking	EXT LED indicates the state of the extension interfaces. Hint: Cellular (WWAN) signal strength can be indicated (green = excellent, orange = medium, red = weak).
SYS		Shows the overall system state. This could be derived from health indicators such as: - all services up and running - overall throughput is normal - CPU load is normal - the supervisor - User application (state set by user in SDK or LXC)
	green on	System operation state: normal
	green blinking	System operation state: warning or in a transition
	red on	System operation state: emergency, watchdog, failure

4.4. Technical specifications

Tab. 4.9: Technical specifications


Frequency bands E	4G LTE Band 20 (800 MHz), Band 5 (850 MHz), Band 8 (900 MHz), Band 3 (1800 MHz), Band 1 (2100 MHz), Band 7 (2600 MHz)
	3G UMTS/HSDPA/HSUPA Band 5 (850 MHz), Band 8 (900 MHz), Band 2 (1900 MHz), Band 1 (2100 MHz)
	2G GSM/GPRS/EDGE GSM 850 MHz, E-GSM 900 MHz, DCS 1800 MHz, PCS 1900 MHz
	Ublox TOBY L-210 FCC ID XPYTOBL210
Frequency bands P	4G LTE Band 28 (750 MHz), Band 5 (850 MHz), Band 8 (900 MHz), Band 3 (1800 MHz), Band 1 (2100 MHz), Band 7 (2600 MHz)
	3G UMTS/HSDPA/HSUPA Band 5 (850 MHz), Band 8 (900 MHz), Band 2 (1900 MHz), Band 1 (2100 MHz)
	2G GSM/GPRS/EDGE GSM 850 MHz, E-GSM 900 MHz, DCS 1800 MHz, PCS 1900 MHz
	Ublox TOBY L-280 FCC ID XPYTOBL280
Frequency bands A	4G LTE Band 17 (700 MHz), Band 5 (850 MHz), Band 4 (1700 MHz), Band 2 (1900 MHz), Band 7 (2600 MHz)
	3G UMTS/HSDPA/HSUPA Band 5 (850 MHz), Band 8 (900 MHz), Band 4 (AWS, i.e. 1700 MHz), Band 2 (1900 MHz), Band 1 (2100 MHz)
	2G GSM/GPRS/EDGE GSM 850 MHz, E-GSM 900 MHz, DCS 1800 MHz, PCS 1900 MHz
	Ublox TOBY L-200 FCC ID XPYTOBL200
Frequency bands U	3G UMTS/HSDPA/HSUPA Band 5 (850 MHz), Band 8 (900 MHz), Band 2 (1900 MHz), Band 1 (2100 MHz)
	2G GSM/GPRS/EDGE GSM 850 MHz, E-GSM 900 MHz, DCS 1800 MHz, PCS 1900 MHz
Specification	4G LTE 3GPP Release 9 Long Term Evolution (LTE) Evolved Uni. Terrestrial Radio Access (E-UTRA) Frequency Division Duplex (FDD) DL Multi-Input Multi-Output (MIMO) 2×2
	3G UMTS/HSDPA/HSUPA 3GPP Release 8 Dual-Cell HS Packet Access (DC-HSPA+) UMTS Terrestrial Radio Access (UTRA) Frequency Division Duplex (FDD) DL Rx diversity
	2G GSM/GPRS/EDGE 3GPP Release 8 Enhanced Data rate GSM Evolution (EDGE)

	GSM EGPRS Radio Access (GERA) Time Division Multiple Access (TDMA) DL Advanced Rx Performance Phase 1	
	Data rates up to 150 Mbps downlink / 50 Mbps uplink	
Ethernet	4× Ethernet 10/100 Base-T, Auto MDX, 4× RJ45, bridged or routed	
Serial Interface	1× 3-wire RS232 on 15-pin screw terminal block	
Digital I/O	1 digital input	0–3 VDC level 0 9–32 VDC level 1
	1 digital output	Relay outputs Limiting continuous current 1 A Max. switching voltage 32 VDC Max. switching capacity 32 W Isolation 1500 Vp (transients)
GNSS (option)	Active antenna 3.3 VDC; SMA female 72-channel Ublox M8 engine GPS/QZSS L1 C/A, GLONASS L10F BeiDou B1I, Galileo E1B/C, SBAS L1 C/A: WAAS, EGNOS, MSAS, GAGAN	
	Ublox NEO-M8N	
GNSS Time pulse (option)	TTL logic: 1 pulse/s; SMA female	
USB service interface	USB host interface supporting memory devices USB type A connector USB2.0	
SIM	2× micro SIM (3FF)	
Antenna Interface	Impedance:	50 Ω
	Connector:	2× SMA female supporting MIMO
Power Supply	Input voltage:	9.6–28.8 VDC (12–24 VDC –20 % / +20 %)
	Avg. power consumption:	7 W (including max. 2.5 W on USB port)
Environmental Conditions	For indoor use only, IP40 Metal casing, DIN rail mounting kit included Temperature range: –40 to +70 °C (–40 to +158 °F) Humidity: 0 to 95 % (non condensing) MTBF (Mean Time Between Failure): > 220.000 hours (> 25 years) Vibration & shock: ETS 300 019-2-3:1994, Class 3.4 Seismic: EN 60068-2-27:2010 Environmental: EN 61850-3: 2014 IEEE 1613:2009	
Mounting	DIN rail mounting	
Dimensions	45 W × 110 D × 125 H mm (1.77 × 4.33 × 4.92 in)	

Weight	Ca. 450 g (0.99 lbs)
Type Approval	CE, FCC

Options	
Antennas	Various antennas suitable for your application are available
Mounting kit	Flat bracket mounting kit

4.5. Model offerings



- Trade name** - trade and marketing name of the product. This name is used for all products within the same product family.
 Possible values:
 M!DGE
- Gen.** - generation of the product of specific Trade name. The very first generation doesn't have any number in this position.
 Possible values:
 none
 2
- Band** - *frequency bands*
 Possible values:
 E – 4G/3G/2G, Europe, Middle East, Africa
 P – 4G/3G/2G, Asia, Pacific, South America
 A – 4G/3G/2G, Americas
 U – only 3G/2G, world wide
 NOTE: 'P' and 'A' are available for high volumes only.
- Slot** - Proprietary extension slot
 Possible values:
 N – not used
 C – The second RS232/485 + 1× DI, 1× DO, Part No.: M!DGE2-HW-COM/IO

pin description	signal
1	RS-232 GND (non-isolated)
2	RS-232 RxD (non-isolated); RS485 A (Half-Duplex)
3	RS-232 TxD (non-isolated); RS485 B (Half-Duplex)
4	Digital input - Negative signal input (isolated to GND)
5	Digital input - Positive signal input (isolated to GND)
6	Digital Output isolated, Relay contact normally opened
7	Digital Output isolated, Relay common
8	Digital Output isolated, Relay contact normally closed

- **mPCle** - mPCle slot

Possible values:

N – not used

E – The second cellular module, Bands E, Part No.: mPCle-E

P – The second cellular module, Bands P, Part No.: mPCle-P

A – The second cellular module, Bands A, Part No.: mPCle-A

U – The second cellular module, Bands U, Part No.: mPCle-U

G – Internal GPS (GNSS) module, Part No.: mPCle-GPS

NOTE: Just one option for mPCle slot is possible.

- **Bands, Slot, mPCle** positions are used only for M!DGE2.

- **SW keys** - if unit is ordered with SW keys, all keys are specified in this bracket. SW key activates the feature, which is under the license. SW key can be ordered independently for specific S/N anytime later on.

Possible values M!DGE2:

LXC – Linux container, Part No.: M!DGE2-SW-LXC

SERVER – Server clients extension, Part No.: M!DGE2-SW-SERVER

Feature	Default	SW key SERVER
DHCP reservations	35	35
Local host names	35	35
NAPT rules	35	35
Firewall rules	50	50
Firewall address groups	15	15
OpenVPN clients	10	25
Static routes	30	30
Mobile IP	yes	yes
DynDNS server	no	yes

- **Type** - specific product type for which type approvals like CE, FCC etc. are issued.

Possible values:

M!DGE

M!DGE2

- **Order code** – the complete product code, which is used on Quotations, Invoices, Delivery notes etc.

In order to find out the correct Order code, please use **RACOM WebService**¹.

¹ <https://webservice-new.racom.eu/main/eshop.list?t=10>

4.6. Accessories

4.6.1. F bracket

Flat-bracket

Installation bracket for flat mounting. For usage details see chapter *Mounting* and chapter *Dimensions*.



Fig. 4.8: Flat bracket




Fig. 4.9: Flat bracket dimensions

5. Bench test / Step-by-Step guide

Before starting to work with the HW please be sure that you have a SIM card enabled for data and you have all the necessary information from the mobile operator (PIN, APN, login, passwd)

5.1. Connecting the hardware

5.1.1. Install the SIM card

Insert a SIM card into the SIM socket, use the first one. Make sure the SIM is enabled for data transmission.

There are two reasons for installing the SIM card as the first task: a) the SIM card could be damaged when inserted into the powered equipment, b) the information from SIM card are read only after a power cycle.

5.1.2. Connect the cellular antenna

Fit a cellular antenna. For details see *RACOM web*¹ or contact RACOM for suitable antennas.

5.1.3. Connect the LAN cable

Connect one M!DGE Ethernet port to your computer using an Eth cat.5 cable.

5.1.4. Connect the power supply

Connect the power supply wires to the M!DGE screw terminals, ensuring correct polarity. Switch on the power supply.

5.2. Powering up your wireless router

Switch on your power supply. The STAT LED flashes for a few seconds and after 8 seconds it starts blinking to a green light. After approximately 30 seconds your router will have booted and will be ready; the STAT LED remains shining.

When the Mobile Connection is enabled the WAN LED starts blinking while connecting to the cellular network – the color (green/orange/red) represents the signal strength (excellent, medium, weak).

You'll find the description of the individual LED states in *Section 4.3, "Indication LEDs"*.

5.3. Connecting M!DGE to a programming PC

- a. Please connect the Ethernet interfaces of your computer and M!DGE.
- b. If not yet enabled, please enable the Dynamic Host Configuration Protocol (DHCP) so that your computer can lease an IP address from M!DGE. Wait a moment until your PC has received the parameters (IP address, subnet mask, default gateway, DNS server).

Alternative: Instead of using the DHCP, configure a static IP address on your PC (e.g. 192.168.1.10 mask 255.255.255.0) so that it is operating in the same subnet as the M!DGE.

¹ https://www.racom.eu/eng/products/gprs-router-midge.html#accessories_antennas

The default IP address is 192.168.1.1 for all Eth interfaces (Eth1 - Eth4), the default subnet mask is 255.255.255.0 for all interfaces.

Default DHCP range 192.168.1.100 to 192.168.1.199

- c. Start a Web Browser on your PC. Type the M!DGE IP address in the address bar:
http://192.168.1.1
- d. Please set a password for the admin user account. Choose something that is both easy to remember and a strong password (such as one that contains numbers, letters and punctuation). The password must have a minimum length of 6 characters. It must contain a minimum of 2 numbers and 2 letters.

Admin Password Setup

Please set a password for the admin account.
It shall have a minimum length of 6 characters and contain at least 2 numbers and 2 letters.

Username:	admin
Enter new password:	••••••
Confirm new password:	

I agree to the [terms and conditions](#)

Configure automatic mobile data connection



Note

For security reasons, there is no default password.

- e. Agree to the terms and conditions. The user is now obliged to accept our end user license agreement during the initial M!DGE setup.
- f. You might check the "Configure automatic mobile data connection" for automatic WWAN configuration. Manual changes are usually required afterwards. Note that Firewall is also enabled with predefined WAN administration ports.

5.4. Basic setup

The M!DGE Web Manager can always be reached via the Ethernet interface. After successful setup, Web Manager can also be accessed via the mobile interface. Any up to date web browser can be used. Any web browser supporting JavaScript can be used. By default, the IP address of the 1st Ethernet interface is 192.168.1.1, the web server runs on port 80.

The minimum configuration steps include:

1. Defining the admin password
2. Entering the PIN code for the SIM card
3. Configuring the Access Point Name (APN)
4. Starting the mobile connection



Note

Router M!DGE can be safely turned off by unplugging the power supply.

6. Installation

6.1. Mounting

M!DGE Wireless Router is designed for a DIN rail mounting or on a panel using flat bracket. Please consider the safety instructions in *Section 6.1, "Mounting"*.

6.2. Antenna mounting

M!DGE Wireless Routers will only operate reliably over the cellular network if there is a strong signal. For many applications the flexible stub antenna provided would be suitable but in some circumstances it may be necessary to use a remote antenna with an extended cable to allow the antenna itself to be positioned so as to provide the best possible signal reception.

Beware of the deflective effects caused by large metal surfaces (elevators, machine housings, etc.), close meshed iron constructions and choose the antenna location accordingly. Fit the antenna or connect the antenna cable to the ANT connector.

In external antennas the surge protection of coaxial connection would be required.



Note

Be sure that the antenna was installed according to the recommendation by the antenna producer and all parts of the antenna and antenna holder are properly fastened.

6.3. Power supply

M!DGE can be powered with an external power source capable of voltages from 9.6 to 28.8 Volts DC. M!DGE should be powered using a certified (CSA or equivalent) power supply, which must have a limited and SELV circuit output.

7. Web Configuration

7.1. HOME

This page gives you a system overview. It helps you when initially setting up the device and also functions as a dashboard during normal operation.

M!DGE



HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Status

Summary
WAN
Ethernet
LAN
DHCP
OpenVPN
System

Summary

Description	Administrative Status	Operational Status
Hotlink		LAN2
LAN2	enabled	up
WWAN1	enabled	up
OpenVPN1	enabled, server	up

The highest priority link which has been established successfully will become the so-called **hotlink** which holds the default route for outgoing packets.

Detailed information about status of each WAN interface is available in a separate window.

M!DGE



HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Status

Summary
WAN
Ethernet
LAN
DHCP
OpenVPN
System

LAN2 | WWAN1

Description	Value
Administrative state	enabled
Operational state	up
Link is up since	2014-06-04 14:54:34
IP address	192.168.131.234
Gateway	192.168.131.254
Transfer rate down / up	29 Byte/s / 10 Byte/s
Data downloaded / uploaded since 2014-05-21 14:57:52	6.77 MB / 3.35 MB <input type="button" value="Reset"/>

Status

Summary
WAN
WWAN
Ethernet
LAN
Bridges
DHCP
System

WWAN1

Description	Value
Administrative state	enabled
Operational state	up
Link is up since	2018-03-05 14:55:04
IP address	10.203.0.28
Modem	Mobile1
SIM	SIM1 (ready)
PDP	PDP1
Registration status	registeredInHomeNetwork
Service type	HSPA
Network	O2 - CZ@ (Cell EDB1860)
Signal level	48% (medium)
Transfer rate down / up	0 bit/s / 0 bit/s
Data downloaded / uploaded	387.88 KB / 583.25 KB reset

7.2. INTERFACES

Details for all physical connections are given in *Section 4.2, "Connectors"*.

7.2.1. WAN

Link Management

Each available item in the WAN Link Manager matches with the particular WAN interface. Depending on your hardware model, WAN links can be made up of either Wireless Wide Area Network (WWAN), Wireless LAN (WLAN), Ethernet or PPP over Ethernet (PPPoE) connections. Please note that each WAN link has to be configured and enabled in order to appear on this page.

In case a WAN link goes down, the system will automatically switch over to the next link in order of priority (the priorities can be changed using the arrows on the right side of the window). A link can be either established when the switch occurs or permanently to minimize link downtime.

WAN

Link Management
Supervision
Settings

Ethernet

Port Assignment
VLAN Management
IP Settings

Mobile

SIMs
Interfaces

WAN Link Management

In case a WAN link goes down, the system will automatically switch over to the next link in order of priority. A link can be either established when the switch occurs or permanently to minimize link downtime. Outgoing traffic can also be distributed over multiple links on a per IP session basis.

Priority	Interface	Operation Mode	
1st	LAN2	permanent	 
2nd	WWAN1	permanent	 

Apply

1st priority: This link will be used whenever possible.

2nd priority: The first fallback technology.

Up to four priorities can be used.

Links are being triggered periodically and put to sleep in case it was not possible to establish them within a certain amount of time. Hence it might happen that permanent links will be dialed in background and replace links with lower priority again as soon as they got established. In case of interfering links sharing the same resources (for instance in dual-SIM operation) you may define a switch-back interval after which an active hotlink is forced to go down in order to let the higher-prio link getting dialed again.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

WAN

Link Management

Supervision

Settings

Ethernet

Port Setup

VLAN Management

IP Settings

Mobile

Modems

SIMs

Interfaces

WAN Link Configuration WWAN1

Operation mode: on switchover

Switch back: after seconds

IP pass-through: enabled disabled

Bridge interface: None

Bridge interface: If WAN is configured as WLAN client, the LAN interface to which the WAN link should be bridged.

Outgoing traffic can also be distributed over multiple links on a per IP session basis. Choose the option "distributed" as an Operation Mode with the appropriate Weight.

In the following example, the outgoing traffic will be distributed between LAN2 (80 %) and WWAN1 (20 %) links.



Note

This option is general and applies to all outgoing traffic. See *Section 7.3.3, "Multipath Routes"* for more detailed configuration.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

WAN

Link Management

Supervision

Settings

Ethernet

Port Assignment

VLAN Management

IP Settings

Mobile

SIMs

Interfaces

WAN Link Management

In case a WAN link goes down, the system will automatically switch over to the next link in order of priority. A link can be either established when the switch occurs or permanently to minimize link downtime. Outgoing traffic can also be distributed over multiple links on a per IP session basis.

Priority	Interface	Operation Mode	Weight	
1st	LAN2	distributed	4	↓ ↗
2nd	WWAN1	distributed	1	↑ ↗

Apply

We recommend using the **permanent** option for WAN links. However, in case of time-limited mobile tariffs, the **switchover** option should be used.

After clicking on the WWAN "Edit" button, you can additionally set the "IP passthrough" option for the selected LAN interface. The result is that the connected device over the selected LAN port will obtain M!DGE's mobile IP address via DHCP. In another words, M!DGE will be transparent for the connected device and will only serve for the mobile connectivity. Typically, such connected device (e.g. firewall) will not need any special configuration facing M!DGE, it will just use its mobile IP address (usually the public IP address).

Once established, a small subnet containing the cellular IP is created, by default the netmask is 255.255.255.248. This small subnet consists of a network and broadcast address as a regular subnet. In some situations it may lead to unreachability of several remote hosts due to IP address overlapping. If this is the case, user can manually configure the APN network, e.g. 10.203.0.0/255.255.128.0.

In any case, the M!DGE unit is reachable via the default gateway automatically obtained from M!DGE by DHCP. The gateway IP address is set as the first available IP address after the specified APN address range. If not specified, it is the first usable IP within the /29 subnet.



Note

We recommend to define the APN network/netmask manually. There might be situations in which the default /29 disables the communication. E.g. WWAN IP is 10.10.10.6. The connected device obtains this IP via DHCP and sets the default gateway to 10.10.10.7 - but this IP is a broadcast IP within /29 subnet and the communication is not possible. If you configure subnet 10.10.10.0/29 manually, a default gateway would be 10.10.10.8 in newly created local /28 subnet.

Example: If the APN network is 10.203.0.0/17, the default gateway is set to 10.203.128.0. The web interface is reachable via this IP address over the selected LAN interface. The connected device's network mask is /16 (1 bit wider), otherwise the default gateway would not be usable.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

LAN1 | LAN2

DHCP Leases on LAN2

Interface	IP Address	MAC Address	Name	Expires
LAN2	10.203.0.29	00:23:AE:02:5E:E0	mrazek-NB	2016-09-22 12:26:10

Status
 Summary
 WAN
 WWAN
 Ethernet
 LAN
 DHCP
 System



Note

- This option is configurable within WWAN links only. Remember that LAN1 cannot be used as the port for the IP passthrough functionality.
- LAN10 is not usable within M!DGE routers. Do not select it.

- WAN**
- Link Management
- Supervision
- Settings

- Ethernet**
- Port Setup
- VLAN Management
- IP Settings

- Mobile**
- Modems
- SIMs
- Interfaces

- Bridges**

- USB**

- Serial**

- Digital I/O**

WAN Link Configuration WWAN1

Operation mode:

Multipath-TCP:

IP pass-through: enabled
 disabled

Interface:

WAN network: (optional)

WAN netmask: (optional)

Connection Supervision

- WAN**
- Link Management
- Supervision
- Settings

- Ethernet**
- Port Assignment
- VLAN Management
- IP Settings

Link Supervision

Network outage detection can be performed by sending pings on each WAN link to authoritative hosts. The link will be declared as down in case all trials failed. You may further specify an emergency action if a certain downtime is reached.

Link	Hosts	Emergency Action
WWAN1	10.203.0.1	reboot after 30 min

Network outage detection can be used for switching between available WAN links and can be performed by sending pings on each link to authoritative hosts. A link will be declared as down if all trials have failed. The link will be considered up again if at least one host is reachable.

You may further specify an emergency action if no uplink can be established at all.

Configurable actions are:

- None
- Restart link services
- Reboot system

WAN

Link Management
Supervision
Settings

Ethernet

Port Assignment
VLAN Management
IP Settings

Mobile

SIMs
Interfaces

USB**Serial Port****Digital I/O****Link Supervision**

Network outage detection can be performed by sending pings on each WAN link to authoritative hosts. The link will be declared as down in case all trials failed. You may further specify an emergency action if a certain downtime is reached.

Link:

Mode: also validate when link comes up
 only validate if link is up

Primary host:

Secondary host: (optional)

Ping timeout: milliseconds

Ping interval: seconds

Retry interval (if ping failed): seconds

Max. number of failed trials:

Emergency action: none
 restart link services
 reboot system

after minutes being down

Link:	The WAN link to be monitored (can be ANY for all configured links).
Mode:	Specifies whether the link is monitored during the connection establishment or only when it is already up.
Primary host:	Reference host one which will be used for checking IP connectivity (via ICMP pings).
Secondary host:	Reference host two which will be used for checking IP connectivity (via ICMP pings). The test is considered successful if either the primary or the secondary host answers.
Ping timeout:	Time for which the system is waiting for the ping response. With mobile networks the response time can be quite long (several seconds) in special cases. You can check the typical response using SYSTEM – Troubleshooting – Network Debugging – Ping. The first response typically takes a longer time than the following ones in cellular networks, the Ping timeout should be set to the longer time than with the first response.
Ping interval:	Time to wait before sending the next probe.
Retry interval (if ping failed):	If the first trial fails, ping hosts in this modified interval until the ping is successful or the maximum number of failed trials is reached.
Max. number of failed trials:	The maximum number of failed ping trials until the ping check will be declared as failed.
Emergency action:	Configure the Emergency action which should be taken after the maximum downtime is reached. Using "reboot" performs the system reboot. The option "restart services" restarts all link-related applications including the modem reset. No action is done if the "none"

option is set. Configure the maximum amount of downtime in minutes for which the link could not be established.

Settings

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

WAN
[Link Management](#)
[Supervision](#)
[Settings](#)

Ethernet
[Port Assignment](#)
[VLAN Management](#)
[IP Settings](#)

Mobile
[SIMs](#)
[Interfaces](#)

USB

TCP Maximum Segment Size
 The maximum segment size defines the largest amount of data of TCP packets (usually MTU minus 40). You may decrease the value in case of fragmentation issues or link-based limits.

MSS adjustment: enabled disabled

Maximum segment size:

The maximum segment size defines the largest amount of data of TCP packets (usually MTU minus 40). You may decrease the value in case of fragmentation issues or link-based limits.

MSS adjustment Enable or disable MSS adjustment on WAN interfaces.

Maximum segment size Maximum number of bytes in a TCP data segment.

7.2.2. Ethernet

M!DGE routers ship with 4 dedicated Ethernet ports (ETH1 to ETH4) which can be linked via RJ45 connectors.

ETH1 usually forms the LAN1 interface which should be used for LAN purposes. Other interfaces can be used to connect other LAN segments or for configuring a WAN link. The LAN10 interface will be available as soon as a pre-configured USB Ethernet device has been plugged in (e.g. XA Ethernet/USB adapter).

Port Setup - Port Assignment

This menu can be used to individual assigning of Ethernet ports to LAN interfaces if you want to have different subnets per port or to use one port as the WAN interface.

If it is desired to have both ports in the same LAN you may assign them to the same interface. Please note that the ports will be bridged by software and operated by running the Spanning Tree Protocol.

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Port Assignment | **Link Settings**

Ethernet 1

Administrative status: enabled disabled

Network interface: LAN1 ▾

Ethernet 2

Administrative status: enabled disabled

Network interface: LAN1 ▾

Ethernet 3

Administrative status: enabled disabled

Network interface: LAN1 ▾

Ethernet 4

Administrative status: enabled disabled

Network interface: LAN4 ▾

Apply

Port Setup - Link Settings

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Port Assignment | **Link Settings**

Link speed for Ethernet 1: auto-negotiated ▾

Link speed for Ethernet 2: auto-negotiated ▾

Apply

Link negotiation can be set for each Ethernet port individually. Most devices support auto negotiation which will configure the link speed automatically to comply with other devices in the network. In case of negotiation problems, you may assign the modes manually but it has to be ensured that all devices in the network utilize the same settings then.

VLAN Management

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

WAN

Link Management
Supervision
Settings

Ethernet

Port Setup
VLAN Management
IP Settings

Mobile

SIMs
Interfaces

USB

Add VLAN Interface

Network interface:

ID:

Priority:

Network mode: routed bridged

M!DGE routers support Virtual LAN according to IEEE 802.1Q which can be used to create virtual interfaces on top of the Ethernet interface. The VLAN protocol inserts an additional header to Ethernet frames carrying a VLAN Identifier (VLAN ID) which is used for distributing the packets to the associated virtual interface. Any untagged packets, as well as packets with an unassigned ID, will be distributed to the native interface. In order to form a distinctive subnet, the network interface of a remote LAN host must be configured with the same VLAN ID as defined on the router. Further, 802.1P introduces a priority field which influences packet scheduling in the TCP/IP stack.

The following priority levels (from the lowest to the highest) exist:

Parameter	VLAN Priority Levels
0	Background
1	Best Effort
2	Excellent Effort
3	Critical Applications
4	Video (< 100 ms latency and jitter)
5	Voice (< 10 ms latency and jitter)
6	Internetwork Control
7	Network Control

IP Settings

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

WAN

Link Management
Supervision
Settings

Ethernet

Port Setup
VLAN Management
IP Settings

IP Address Management

Network Interface	Mode	IP Address Mode	IP Address	Netmask	
LAN1	LAN	Static IP	192.168.20.254	24	
LAN4	WAN	Static IP	192.168.2.100	24	

Two individual tabs will be used when different LANs are set in the Port settings menu. Each of them can be configured either in the LAN mode or in the WAN mode.

**Note**

The default IP address is 192.168.1.1/24 (LAN1).

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

LAN1

IP Settings LAN1

Mode: LAN WAN

Static Configuration

IP address:

Netmask:

Alias IP address:

Alias subnet mask:

MTU:

Static configuration of M!DGE's own IP address and Subnet mask is available for the LAN mode. The Alias IP address enables configuring the LAN interface with a second IP address/subnet.

MTU Configure MTU of a given Ethernet interface.

**Note**

Setting of the IP address is interconnected with the DHCP Server (if enabled) - menu the SERVICES - DHCP Server menu.

- WAN
 - Link Management
 - Supervision
 - Settings

- Ethernet
 - Port Setup
 - VLAN Management
 - IP Settings

- Mobile
 - SIMs
 - Interfaces

- USB

- Serial

- Digital I/O

LAN1
LAN2

IP Settings LAN1

Mode: LAN WAN

WAN mode: DHCP client static IP PPPoE

Static Configuration

IP address:

Netmask:

Default gateway:

Primary DNS server:

Secondary DNS server:

MTU:

Apply
Continue

WAN mode enables the following possibilities:

- DHCP client:** The IP configuration will be retrieved from a DHCP server in the network. No further configuration is required (you may only set MTU).

- Static IP:** IP configuration will be set manually. At least the Default gateway and the Primary DNS server must be configured along with the IP address and subnet mask.

- PPPoE:** PPPoE is the preferred protocol when communicating with another WAN access device (like a DSL modem).
 - Username:** PPPoE user name to be used for authentication at the access device.
 - Password:** PPPoE password to be used for authentication at the access device.
 - Service Name:** Specifies the service name set of the access concentrator. Leave it blank unless you have many services and need to specify the one you need to connect to.
 - Access Concentrator Name:** This may be left blank and the client will connect to any access concentrator.

7.2.3. Mobile

Modems

Configuration

This page lists all available WWAN modems. They can be disabled on demand.

Query

This page allows you to send Hayes AT commands to the modem. Besides the 3GPP-conforming AT command-set, further modem-specific commands can be applied (can be provided on demand). Some modems also support running Unstructured Supplementary Service Data (USSD) requests, e.g. for querying the available balance of a prepaid account.

SIMs

The SIM page gives an overview about the available SIM cards, their assigned modems and the current state. Once a SIM card has been inserted, assigned to a modem and successfully unlocked, the card should remain in state ready and the network registration status should have turned to registered. If not, please double-check your PIN.

Please keep in mind that registering to a network usually takes some time and depends on signal strength and possible radio interferences. You may hit the Update button at any time in order to restart PIN unlocking and trigger another network registration attempt.

Under some circumstances (e.g. in case the modem flaps between base stations) it might be necessary to set a specific service type or assign a fixed operator. The list of operators around can be obtained by initiating a network scan (may take up to 60 seconds). Further details can be retrieved by querying the modem directly, a set of suitable commands can be provided on request.

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

WAN
[Link Management](#)
[Supervision](#)
[Settings](#)

Ethernet
[Port Setup](#)
[VLAN Management](#)
[IP Settings](#)

Mobile
[Modems](#)
SIMs
[Interfaces](#)

Mobile SIMs

This menu can be used to assign a default modem to each SIM which will also be used by SMS and GSM voice services. A SIM card can get switched in case of multiple WWAN interfaces sharing the same modem.

SIM	Default	Current	State	PIN Protection	Registered	
SIM1	Mobile1	Mobile1	ready	disabled	yes	
SIM2	none	none	unassigned	unknown	no	

Configuration

A SIM card is generally assigned to a default modem but this may switch, for instance if you set up two WWAN interfaces with one modem but different SIM cards. Close attention has to be paid when other services (such as SMS or Voice) are operating on that modem as a SIM switch will affect their operation.

- WAN
 - Link Management
 - Supervision
 - Settings
- Ethernet
 - Port Setup
 - VLAN Management
 - IP Settings
- Mobile**
 - Modems
 - SIMs
 - Interfaces
- Bridges
- USB
- Serial
- Digital I/O

Configure SIM1

SIM state:	ready
SIM ID:	ICCID8942020622802259004
PIN code:	<input type="text" value="••••••••"/> show
PUK code:	<input type="text"/> show (not required)
Default modem:	Mobile1 ▾
Bands:	all bands ▾
Preferred service:	automatic ▾
Registration mode:	packet-switched only ▾
Network selection:	automatic ▾ scan networks

You can configure the following parameters:

- PIN protection** Depending on the used card, it can be necessary to unlock the SIM with a PIN code. Please check the account details associated with your SIM whether the PIN protection is enabled.
- PIN code** The PIN code for unlocking the SIM card
- PUK code** The PUK code for unlocking the SIM card if the card was blocked due to several wrong PIN attempts.
- Default modem** The default modem assigned to this SIM card.
- Bands** The list of allowed bands to which the unit can connect. Current ublox module does not support manual band selection.
- Preferred service** The preferred service type to be used with this SIM card. Remember that the link manager might change this in case of different settings. The default option is "automatic", in areas with interfering base stations you can force a specific type (e.g. 3G-only) in order to prevent any flapping between the stations around.
- Registration mode** The default option is set to "all networks". You can limit the modem registration to "packet-switched only" (e.g. no Dial-in Server) or "circuit-switched only" option, which can be for example used for the Dial-in Server so one can use PPP over the Circuit-Switched Networks (analog modem style).
- Network selection** LAI is a globally unique number that identifies the country, network provider and LAC of any given location area. It can be used to force the modem to register to a particular mobile cell in case of competing stations. You may further initiate mobile network scan for getting networks in range and assign a LAI manually.

WWAN Interfaces

This page can be used to manage your WWAN interfaces. The resulting link will pop up automatically on the WAN Link Management page once an interface has been added. The Mobile LED will be blinking during the connection establishment process and goes on as soon as the connection is up. Refer to the troubleshooting section or log files in case the connection did not come up.

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

WAN

- Link Management
- Supervision
- Settings

Ethernet

- Port Setup
- VLAN Management
- IP Settings

Mobile

- Modems
- SIMs
- Interfaces

Mobile Interfaces

Interface	Modem	SIM	PDP	Number	Service	APN / User	
WWAN1	Mobile1	SIM1	PDP1	*99***1#	2G-only	internet	-

The following mobile settings are required:

- Modem The modem to be used for this WWAN interface
- SIM The SIM card to be used for this WWAN interface
- Preferred service The preferred service type

Please note that these settings supersede the general SIM based settings as soon as the link is being dialed.

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

WAN

- Link Management
- Supervision
- Settings

Ethernet

- Port Assignment
- VLAN Management
- IP Settings

Mobile

- SIMs
- Interfaces

USB

- Serial Port
- Digital I/O

Edit WWAN Interface WWAN1

Mobile

Connection

Advanced

Connection settings:

load from database

specify

Phone number:

Access point name:

Authentication: None

None
PAP
CHAP
PAP+CHAP

Generally, the connection settings are derived automatically as soon as the modem has been registered and the network provider has been found in our database. Otherwise, it will be required to configure the following settings:

- Phone number The phone number to be dialed, for 3G+ connections this commonly refers to be *99***1#. For circuit switched 2G connections you can enter the fixed phone number to be dialed in the international format (e.g. +420xx).
- Access point name The access point name (APN) being used

Authentication	The authentication scheme being used, if required this can be PAP or/and CHAP
Username	The username used for authentication
Password	The password used for authentication

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

WAN

Link Management

Supervision

Settings

Ethernet

Port Setup

VLAN Management

IP Settings

Mobile

Modems

SIMs

Interfaces

WLAN

Administration

Configuration

IP Settings

Bridges

USB

Edit Mobile Interface WWAN1

Mobile
Connection
Advanced

Required signal strength: dBm (range -120..-40) [more info](#)

Home network only:

Negotiate DNS:

Call to ISDN:

Header compression:

Data compression:

Client address:

MTU:

Further on, you may configure the following advanced settings:

Required signal strength	The minimum required signal strength before the connection is dialed. It can be specified as the RSSI level in dBm units, or as the Quality level in percent. See the "more info" button to see the exact values.
Home network only	Determines whether the connection should only be dialed when registered to the home network.
Negotiate DNS	Specifies whether the DNS negotiation should be performed and the retrieved name-servers should be applied to the system.
Call to ISDN	This option must be enabled in case of 2G connections talking to an ISDN modem.
Header compression	Enables or disables Van Jacobson TCP/IP Header Compression for PPP-based connections. This feature will improve TCP/IP performance over slow serial links. Has to be supported by your provider.
Data compression	Enables or disables the data compression for PPP-based connections. Data compression reduces the packet size to improve throughput. Has to be supported by your provider.
Client address	Specifies a fixed client IP address on the mobile interface.

MTU

The Maximum Transmission Unit represents the largest amount of data that can be transmitted within one IP packet and can be defined for any WAN interface.

7.2.4. Bridges

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

BR1 BR2

Bridge Settings BR1

Administrative status: Disabled
 Enabled
 Enabled with local interface

Local IP Configuration

IP Address

Netmask

MTU

Apply

Software bridges can be used to bridge layer-2 devices like OpenVPN TAP, GRE or WLAN interfaces without the need for a physical LAN interface.

Administrative status	Enable (with/without local interfaces) or disable software bridges. If you need an interface in the local system, you need to define an IP address for the local device.
IP Address	IP address of the local interface (available only if "Enabled with local interface" was selected)
Netmask	Netmask of the local interface (available only if "Enabled with local interface" was selected)
MTU	Optional MTU size for the local interface (available only if "Enabled with local interface" was selected)

7.2.5. USB

Administration

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Administration | **Devices** | Autorun

USB Administration

This menu can be used to activate USB-based serial and network devices.

Administrative status: enabled disabled

Enable hotplug:

Apply

Enable or disable the USB administration. If enabled, any supported USB converter can be attached and configured for example as another serial link (RS232, see *Section 7.2.6, “Serial Port”*).



Note

Supported modules are pl2303, ch341, ftdi (quad-channel adapter), asix, pegasus and rndis.

Following parameter can be configured:

- **Enable hotplug (always enabled)**

Click on the Refresh button in the tab Devices for displaying connected USB devices and add them with by clicking on the plus sign.

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Administration | **Devices** | Autorun

Connected USB Devices

Vendor ID	Product ID	Bus ID	Manufacturer	Device	Type
0557	2008	1-1.2	Prolific Technology Inc.	USB-Serial Controller	serial

Enabled USB Devices

Vendor ID	Product ID	Bus ID	Module	Type	Attached
0557	2008	1-1.2	pl2303	serial	yes

Refresh

Autorun

This feature can be used to automatically perform a software/config update as soon as an USB storage stick has been plugged in. Following files must exist in the root directory of a FAT16/32 formatted stick:

- For authentication: `autorun.key`
- For a software update: `sw-update.img`
- For a configuration update: `cfg-<SERIALNO>.zip` or `cfg.zip`

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Administration | Devices | **Autorun**

WAN
Link Management
Supervision
Settings

Ethernet
Port Assignment
VLAN Management
IP Settings

Mobile
SIMs
Interfaces

USB

Serial

Digital I/O

USB Autorun

This feature can be used to automatically perform a software/config update as soon as an USB storage stick has been plugged in.
The following files must exist in the root directory of a FAT16/32 formatted stick:

For authentication: `autorun.key` ([download](#))

Running a script: `autorun.sh`

Performing a software update: `sw-update.img`

Loading a configuration update: `cfg-<SERIAL>.zip` or `cfg.zip`

Administrative status: enabled
 disabled

Only allow enabled devices:

Apply

Administrative status Enable or disable autorun feature.

Only allow enabled devices Check this if only enabled devices are allowed to proceed with autorun.

The `autorun.key` file must hold valid access keys to perform any actions when the storage device is plugged in. The keys are made up of your admin password (SHA256). They can be generated and downloaded. You may also define multiple keys in this file (line-after-line) in case your admin password differs if applied to multiple M!DGE routers.

For new devices with an empty password the hash key `e3b0c44298fc1c149afb4c8996fb92427ae41e4649b934ca495991b7852b855` can be used.

The hash keys can be generated by running the command `echo -n "<admin-password>" | sha256sum` on a Linux system or an Internet hash key generator (search for "sha-256 hash calculator").

7.2.6. Serial Port

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Serial Port Administration

Port	Protocol	Used by	
SERIAL1	RS232	protocol server	
SERIAL2 (USB)	RS232	login console	

Refresh

WAN
Link Management
Supervision
Settings


Ethernet
Port Assignment
VLAN Management
IP Settings

Mobile
SIMs
Interfaces

USB

Serial

The serial protocol can function in various ways, configure it using the Edit button on the right. If the USB Administration is enabled, an extra SERIAL2 (USB) is available.



Five possibilities are available:

None	The serial port is not used at all.
Login console	A possibility to control the unit via the CLI commands when connected to the serial port (115200 8N1). There are no extra configuration parameters.
Device server	Use this option to control the serial device via IP (transmit the data over the cellular network, ...). See the details below.
Modem bridge	Direct connection between the LTE modem tty and the serial interface.
Modem emulator	Replacement for legacy dial-in / dial-out connections based on analog or GSM modems (AT commands support).
Protocol server	Special implementation of various serial protocols like Modbus, IEC101, DNP3, ... See the details below.
SDK	This option enables controlling the serial interface via the SDK scripts (similar to C programming). See <i>chapter SDK</i> for more details.

Device Server

WAN
Link Management
Supervision
Settings
Ethernet
Port Assignment
VLAN Management
IP Settings
Mobile
SIMs
Interfaces
USB
Serial
Digital I/O

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Administration Port Settings

SERIAL1 Port Settings

Physical protocol:	RS232
Baud rate:	115200
Data bits:	8 data bits
Parity:	None
Stop bits:	1 stop bit
Software flow control:	None
Hardware flow control:	None

Server Configuration

Protocol on IP port:	TCP raw
Port:	2000
Timeout:	<input type="radio"/> endless <input checked="" type="radio"/> numbered 600
Allow remote control (RFC 2217):	<input type="checkbox"/>
Show banner:	<input checked="" type="checkbox"/>
Allow clients from:	<input checked="" type="radio"/> everywhere <input type="radio"/> specify

Apply

Serial Port Settings:

Configure the required RS232 parameters.

Physical protocol: Only RS232 is supported.

Baud rate: Specifies the baud rate of the COM port.

Data bits: Specifies the number of data bits contained in each frame.

Parity: Specifies the parity used with every frame that is transmitted or received.

Stop bits: Specifies the number of stop bits used to indicate the end of a frame.

Software flow control: In XON/XOFF software flow control, either end can send a stop (XOFF) or start (XON) character to the other end to control the rate of incoming data.

Hardware flow control: While 3 wired connection is used with MIDGE hardware flow control is not available.

Server

Configuration:

Protocol on IP port: "Telnet" or "TCP raw"

Port: The TCP port used by the application.

Timeout: Endless or numbered (in seconds).

- Allow remote control (RFC 2217) Telnet with the RFC 2217 extension.
- Show banner The option for displaying the banner of the connected serial device.
- Allow clients from The option for limiting the access based on the host IP address.



Important

The UDP Device Server functionality has been moved into SDK only. The required script for this functionality can be provided on demand.

Modem emulator

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

WAN

- Link Management
- Supervision
- Settings

Ethernet

- Port Setup
- VLAN Management
- IP Settings

Mobile

- Modems
- SIMs
- Interfaces

Bridges

USB

Serial

Digital I/O

Administration

Port Settings

SERIAL1 Port Settings

Physical protocol:

Baud rate:

Hardware flow control:

Incoming Connections via Telnet

Port:

Phonebook Entries

Number	IP address	Port
<input style="width: 95%;" type="text"/>	<input style="width: 95%;" type="text"/>	<input style="width: 95%;" type="text"/>
<input style="width: 95%;" type="text"/>	<input style="width: 95%;" type="text"/>	<input style="width: 95%;" type="text"/>
<input style="width: 95%;" type="text"/>	<input style="width: 95%;" type="text"/>	<input style="width: 95%;" type="text"/>

Modem emulator enables replacement for legacy dial-in / dial-out connections based on analog or GSM modems. M!DGE supports the Hayes AT Command set on the serial interface and behaves like a regular router.

You can easily replace your old Modem with M!DGE. There is also no need to configure the attached device as you can prepare the M!DGE accordingly.

- Physical protocol RS232
- Baud rate Specifies the baud rate of the RS232 port.
- Hardware flow control While 3 wired connection is used with M!DGE hardware flow control is not available.
- Port Any incoming connection will be received on the Port configured. This Port needs to be allowed, keep this in mind for Firewall configurations.

The Phonebook configuration will keep the aliases of any Phone numbers so that you do not need to reconfigure your device and can use the original addressing scheme.

Number Remote phone number.

IP address Remote IP address.

Port Remote port number.



Note

More details in the *Serial SCADA Protocols*¹ application note.

Protocol Server

The port settings configuration is the same as with the Device Server - *the section called "Device Server"* except the Advanced settings called MTU and Idle size.

MTU

An incoming frame is closed at this size even if the stream of bytes continues. Consequently, a permanent data stream coming to the serial interface results in a sequence of MTU-sized frames sent over the network. The default value is set to 1400 bytes.

Idle size

Received frames on COM are closed when the gap between bytes is longer than the Idle value. This parameter defines the maximum gap (in milliseconds) in the received data stream. If the gap exceeds this value, the link is considered idle, the received frame is closed and forwarded to the network.

The default Idle size differs based on the serial baud rate configuration. Remember that the default Idle sizes are set to the minimal possible values:

bps	ms
115200	120
57600	60
38400	30
19200	20
9600	10
4800	5
2400	5
1200	5
600	5
300	5

¹ <https://www.racom.eu/eng/products/m/midge/app/ser/index.html>

- WAN
 - Link Management
 - Supervision
 - Settings

- Ethernet
 - Port Assignment
 - VLAN Management
 - IP Settings

- Mobile
 - SIMs
 - Interfaces

- USB

- Serial

- Digital I/O

Administration	Port Settings	Protocol Server
SERIAL1 Port Settings		
Physical protocol:	<input type="text" value="RS232"/>	
Baud rate:	<input type="text" value="115200"/>	
Data bits:	<input type="text" value="8 data bits"/>	
Parity:	<input type="text" value="None"/>	
Stop bits:	<input type="text" value="1 stop bit"/>	
Software flow control:	<input type="text" value="None"/>	
Hardware flow control:	<input type="text" value="None"/>	
Advanced Settings		
MTU	<input type="text" value="1400"/>	bytes
Idle size	<input type="text" value="120"/>	ms
<input type="button" value="Apply"/>		

Each SCADA protocol like Modbus, DNP3, IEC101, DF1 etc. has its unique message format, most importantly its unique way of addressing the remote units. The following text is valid for all M!DGE/RipEX units (further in this *the section called "Protocol Server"* referred to as a "Unit") - the special properties for mobile cellular networks (e.g. limitation of broadcasting) are mentioned here. The basic task for the protocol server is to check whether a received frame is within the protocol format and is not corrupted. Most of the SCADA protocols are using some type of Error Detection Code (Checksum, CRC, LRC, BCC, etc.) for data integrity control, so each Unit calculates this code and checks it against the received one.

Cellular mobile network operates in IP environment, so the basic task for the Protocol server is to convert SCADA serial packets to UDP datagrams. The Address translation settings are used to define the destination IP address and UDP port. Then these UDP datagrams are sent to the M!DGE router, processed there and are forwarded as unicasts through the mobile network to their destination. When the gateway defined in the Routing table belongs to the Ethernet LAN, UDP datagrams are instead forwarded to the Ethernet interface. After reaching the gateway, the datagram is forwarded according to the Routing table.

When the UDP datagram reaches its final IP destination, it should be in a M!DGE or RipEX router again. It is processed further according to its UDP port. It can be delivered to the Protocol server where where the datagram is decapsulated and the data received on the serial interface of the source unit are forwarded to COM. The UDP port can also be that of a Terminal server (RipEX) or any other special protocol daemon on Ethernet like Modbus TCP etc. The datagram is then processed according to the respective settings.



Note

All timeouts in the parameters described below are derived from the time when the packet is sent into the COM driver, i.e. it includes the transfer time of the packet. Take this into account especially when there is a low Baud rate set in the COM settings.

**Important**

If configuring the Protocol server together with VPN tunnels the "Poll response control" protocol specific parameter must be turned off.

Common parameters

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Administration | Port Settings | **Protocol Server** | Help

Protocol Server

Protocol

Transport Protocol

Port

Parameters

Mode of Connected device

Broadcast

Poll response control

Address translation

Address translation

Base IP

Mask

Interface (Destination port)

For any SCADA protocol, the Transport protocol and the specific port can be chosen. The default values is UDP port 8882. The unit listens on this port for incoming messages and forwards them to the Protocol server itself.

**Note**

Only UDP protocol is currently implemented.

The parameters described in this section are typical of most protocols. There is only a link to them in description of the respective Protocol.

Mode of Connected device

List box: Master, Slave

Default = Master

The typical SCADA application follows the Master–Slave scheme where the structure of the message is different for the Master and Slave SCADA units. Because of that, it is necessary to set which type of SCADA unit is connected to the Unit.

**Important**

For the SCADA Master, set Master, for the SCADA Slave, set Slave.

- **Master**

The SCADA Master always sends addressed messages to Slaves. Addressing is different for each SCADA protocol, so this is one of the main reasons why an individual Protocol server in each Unit for each SCADA protocol has to be used.

- **Broadcast**

List box: On, Off

Default = Off

Some Master SCADA units send broadcast messages to all Slave units. SCADA applications typically use a specific address for such messages. RipEX (Protocol utility) converts such messages into a customized IP broadcast and broadcasts it to all RipEX units resp. to all SCADA units within the network.



Note

Broadcasts in the cellular network are not possible, thus setting of broadcast functionality is not allowed with M!DGE units.

If **On**, the address for broadcast packets in the SCADA protocol has to be defined:

- **Broadcast address format** - List box Hex, Dec - format in which the broadcast address is defined.

- **Broadcast address** - address in the defined format (Hex, Dec)

- **Address translation**

List box: Table, Mask

Default = Mask

In a SCADA protocol, each SCADA unit has a unique address, a "Protocol address". In a cellular mobile network, each SCADA unit is represented by an IP address (typically that of the ETH interface) and a UDP port (that of the protocol daemon or the COM port server to which the SCADA device is connected via serial interface).

A translation between the "Protocol address" and the IP address & UDP port pair has to be done. It can be done either via Table or Mask.

Hence, a SCADA message received from the serial interface is encapsulated into a UDP/IP datagram, where the destination IP address and the destination UDP port are defined according to the settings of the Address translation.

- **Mask**

Translation using the Mask is simpler to set, however it has some limitations:

- all IP addresses used have to be within the same network, which is defined by this Mask

- the same UDP port is used for all the SCADA units, which results in the following:

- SCADA devices on all sites have to be connected to the same interface

- only one SCADA device can be connected to one COM port

- **Base IP**

Default = IP address of the ETH interface

When creating the IP destination address of UDP datagram, in which the serial SCADA message received from COM is encapsulated, this is created, this Base IP is taken as the basis and only the part defined by the Mask is replaced by the 'Protocol address'.

- **Mask**

Default = 255.255.255.0

A part of the Base IP address defined by this Mask is replaced by the 'Protocol address'. The SCADA protocol address is typically 1 byte, so Mask 255.255.255.0 is most frequently used.

- **UDP port (Interface)**

List box: COM, Manual

This UDP port is used as the destination UDP port in the UDP datagram in which the serial SCADA packet received from COM1 is encapsulated. The default UDP port for COM can be

used or the UDP port can be set manually. If the destination IP address belongs to a Unit and the UDP port is not assigned to COM (COM1(2) or to a Terminal server in case of RipEX) or to any special daemon running in the destination address, the packet is discarded.



Note

M!DGE use UDP port 8882 for its COM port.

■ Table

The Address translation is defined in a table. There are no limitations such as when the Mask translation is used. If there are more SCADA units on the RS485 (e.g. with RipEX COM2) their interface, their "Protocol addresses" should be translated to the same IP address and UDP port pair, where the multiple SCADA units are connected. There are 3 possibilities how to fill in the line in the table:

- One "Protocol address" to one "IP address" (e.g.: 56 --> 192.168.20.20)
- Range of "Protocol addresses" to one "IP address" (e.g.: 56 – 62 ==> 192.168.20.20)
- Range of "Protocol addresses" to range of "IP addresses" (e.g.: 56 – 62 ==> 192.168.20.20 – 26). One option is to write only the start IP and a dash, the system will add the end address itself.

- **Protocol address**

This is the address which is used by the SCADA protocol. It may be set either in Hexadecimal or Decimal format according to the List box value.

Protocol address length can be 1 byte, but for the DNP3 and UNI protocols support 2 bytes addresses.

- **IP**

The IP address to which Protocol address will be translated. This IP address is used as the destination IP address in the UDP datagram in which serial SCADA packet received from COM is encapsulated.

- **UDP port (Interface)**

This is the UDP port number which is used as the destination UDP port in the UDP datagram in which the serial SCADA message, received from COM, is encapsulated.

- **Note**

You may add a note to each address up to 16 characters long for your convenience. (E.g. "Remote unit #1").

- **Active**

You may tick/un-tick each translation line in order to make it active/not active.

- **Modify**

Edit, Delete Add buttons allow to edit or to add or to delete a line. The lines can be sorted using up and down arrows.

- **Slave**

The SCADA Slave typically only responds to Master requests, however in some SCADA protocols it can communicate spontaneously.

Messages from the serial interface are processed in a similar way as the Master site, i.e. they are encapsulated in UDP datagrams, processed by the router inside the M!DGE unit and forwarded to the respective interface, typically to the mobile network.

- **Broadcast accept**

List box: On, Off

Default = Off

If **On**, broadcast messages from the Master SCADA device to all Slave units are accepted and sent to connected Slave SCADA unit.



Important

Broadcasting is not supported with mobile networks.

PROTOCOLS IMPLEMENTED:

Within several protocols, parameter "Poll response control" can be set. Turn it off if using any kind of port forwarding or VPN tunnels. Otherwise, it can be set to "On". More details about this parameter can be found at *UNI protocol description*.

None

All received frames from the COM port as well as from the network are discarded.

Async link

The async link creates asynchronous link between two COM ports on different Units. Received frames from COM are sent without any processing transparently to the mobile network to set the IP destination and UDP port. Received frames from the mobile network are sent to the respective COM according to the UDP port setting.

• **Parameters**

- **Destination IP**
This is the IP address of the destination Unit.
- **UDP port (Interface)**
This is the UDP port number which is used as the destination UDP port in the UDP datagram in which the packet received from COM is encapsulated.

C24

C24 is a serial polling-type communication protocol used in Master–Slave applications.

Multiple C24 Masters can be used within one network and one Slave can be polled by more than one Master.

Italicised parameters are described in Common parameters.

Mode of Connected device

Master

Address translation

Table

Mask

Slave

• **Protocol frames**

List box: 1C, 2C, 3C, 4C

Default = 1C

One of the possible C24 Protocol frames can be selected.

• **Frames format**

List box: Format1, Format2, Format3, Format4, Format5

Default = Format1

One of the possible C24 Frames formats can be selected. According to the C24 protocol specification, it is possible to set Frames formats 1–4 for Protocol frames 1C–3C and formats 1–5 for 4C.



Important

The Unit accepts only the set Protocol frames and Frames format combination. All other combinations frames are discarded by the Unit and not passed to the application.

- **Local ACK**

List box: Off, On

Default = Off

Available for Protocol frame 1C only. When **On**, ACK on COM is send locally from this unit, not over the mobile network.

Cactus

Cactus is a serial polling-type communication protocol used in Master–Slave applications. Multiple Cactus Masters can be used within one network and one Slave can be polled by more than one Master.

Italicised parameters are described in Common parameters.

Mode of Connected device

Master

Broadcast

Note: There is no the possibility to set Broadcast address, since Cactus broadcast messages always have the address 0x00. Hence when the Broadcast is On, packets with this destination are handled as broadcasts. Broadcasting is not supported with mobile networks.

Address translation

Table

Mask

Slave

Broadcast accept

- **Max gap timeout [ms]**

Default = 30

The longest time gap for which a frame can be interrupted and still received successfully as one frame. It should not be set below 10ms, while 15–40 ms should be OK for a typical Cactus protocol device.

Comli

Comli is a serial polling-type communication protocol used by Master–Slave applications. More Comli Masters can be used within one network and one Slave can be polled by more Masters. Broadcasts packets are not used, so the configuration is using only some parameters described in *Common parameters*.

Mode of Connected device

Master

Address translation

Table

Mask

Slave

DF1

Only the full-duplex mode of DF1 is supported. Each frame in the Allen-Bradley DF1 protocol contains the source and destination addresses in its header, so there is no difference between Master and Slave in the full-duplex mode in terms of Unit configuration.

- **Block control mode**

List box: BCC, CRC

Default = BCC

According to the DF1 specification, either BCC or CRC for Block control mode (data integrity) can be used.

- **Broadcast**

According to the DF1 specification, packets for the destination address 0xFF are considered broadcasts. Broadcasts are not supported with the mobile network.

Address translation

Table

Mask

- **Advanced parameters**

- **ACK Locally**

List box: Off, On

Default = On

If "**On**", ACK frames (0x1006) are not transferred over-the-air.

When the Unit receives a data frame from the connected device, it generates the ACK frame (0x1006) locally. When the Unit receives the data frame from the mobile network, it sends the frame to the connected device and waits for the ACK. If the ACK is not received within 1 sec. timeout, Unit sends ENQ (0x1005). ENQ and ACK are not generated for broadcast packets.

DNP3

Each frame in the DNP3 protocol contains the source and destination addresses in its header, so there is no difference between Master and Slave in terms of the M!DGE configuration. The DNP3 allows both Master–Slave polling as well as spontaneous communication from remote units.

- **Broadcast** - Note: There is not the option to set the Broadcast address, since DNP3 broadcast messages always have addresses in the range 0xFFFFD – 0xFFFF. Broadcasting is not supported by mobile networks, thus it is not possible to set the broadcast to On..

Address translation

Table

Mask

IEC 870-5-101

IEC 870-5-101 is a serial polling-type communication protocol used by Master–Slave application. More IEC 870-5-101 Masters can be used within one network and one Slave can be polled by more Masters.

IEC 870-5-101 protocol configuration is using all parameters described in *Common parameters*.

Mode of Connected device

Master

Broadcast - only On, Off. Protocol broadcast address is not configurable, it is defined by Address mode in Advance parameter (default 0xFF), but broadcasting is not allowed within mobile networks.

Address translation

Table

Mask

Slave

Broadcast accept

• **Advanced parameters**

○ **Address mode**

Even if IEC 870-5-101 is the standard, there are some users who have customized this standard according to their needs. If addressed byte has been moved, MIDGE/RipEX has to read it at the correct frame position.

■ **IEC101**

Address byte location according to IEC 870-5-101 standard.

Broadcast from Master station is generated when address byte is 0xFF.

■ **2B ADDR**

Two byte address (IEC 870-5-101 standard is 1 byte). The frame is 1 byte longer than the standard one. There is the Intel sequence of bytes: low byte, high byte. Mask Address translation has to be used, because Table one is limited to just one byte address length.

The Master station broadcast is generated when the low address byte is 0xFF and high address byte is also 0xFF.

■ **TELEGYR**

The Control byte in the standard IEC packet is omitted. The frame is 1 byte shorter than a standard one. This is typically used in the Telegyr 805/809 protocol.

Broadcast from Master station broadcast is generated when the address byte is 0x00.

■ **SINAUT**

The sequence of Address byte and Control byte in the frame is swapped-over.

Master station broadcast is generated when the address byte is 0x00.

ITT Flygt

ITT Flygt is a serial polling-type communication protocol used in Master–Slave applications.

ITT Flygt protocol configuration uses all parameters described in *Common parameters*.

Mode of Connected device

Master

Broadcast

Note: There is no possibility to set the Broadcast address, since ITT Flygt broadcast messages always have the address 0xFFFF. Hence when the Broadcast is **On**, packets with this destination are handled as broadcasts. Broadcasting is not available with mobile cellular networks.

- **First Slave Address**

Default = 1

Slave addresses are not defined in the ITT Flygt protocol. However Slave addresses have to be defined in the Unit network. This is the First Slave address in decimal format.

- **Number of Slaves**

Default = 1

Since the ITT Flygt protocol Master (centre) polls the Slaves (remotes) one by one without any addressing, the number of Slaves has to be defined.

Address translation

Table

Mask

Slave

Broadcast accept

- **Wait timeout [ms]**

Default = 5000

An ITT Flygt Slave sometimes sends the WAIT COMMAND (0x13) to its Master. The Unit does not accept the next WAIT COMMAND (discards it), till the Wait timeout expires. The Recommended value is in the 1–10 seconds range.

Modbus

Modbus RTU is a serial polling-type communication protocol used by Master–Slave application. More Modbus Masters can be used within one network and one Slave can be polled by more Masters. Modbus protocol configuration uses all parameters described in *Common parameters*.

Mode of Connected device

Master

Broadcast

Address translation

Table

Mask

Slave

Broadcast accept

Profibus

RipEX supports Profibus DP (Process Field Bus, Decentralized Periphery) the widest-spread version of Profibus. The Profibus DP is supported even by M!DGE, but it will work satisfactorily only with mobile networks with very short transport delays, like LTE or UMTS. The Profibus protocol configuration uses all parameters described in *Common parameters*.

*Mode of Connected device**Master**Broadcast**Address translation**Table**Mask**Slave**Broadcast accept***RP570**

RP570 is a serial polling-type communication protocol used in Master–Slave applications.

Multiple RP570 Masters can be used within one network and one Slave can be polled by more than one Master.

Italicised parameters are described in *Common parameters*.

*Mode of Connected device**Master*

- **Local simulation RB**

List box: Off, On

Default = Off

The RP570 protocol Master very often transmits the RB packets (hold packets) solely to check whether Slaves are connected. In order to minimize the mobile network payload, the Unit can be configured to respond to these packets locally and not to transmit them to the Slaves over the mobile network.

If **On**, the Unit responds to RB packets received from the RP 570 master locally over the COM interface. However from time to time (RB period) the RB packets are transferred over the network in order to check whether the respective Slave is still on. When the RB response from the Slave to this RB packet is not received over the mobile network within the set RB timeout, i.e. the respective Slave is out of order, the central Unit stops local answering to RB packets from the master for the respective Slave.

- **RB Net period [s]**

Default = 10

The M!DGE/RipEX responds to the RB packets locally and in the set RB period the RB packets are transferred over the network.

- **RB Net timeout [s]**

Default = 10 (maximum=8190)

Whenever an RB packet is sent over the network, the set RB Net timeout starts. When the RB response from the remote unit (Slave) is not received within the timeout, i.e. the respective Slave is out of order, the central Unit stops the local answering to RB packets from the master for the respective Slave.

*Address translation**Table*

Mask

Slave

- **Local simulation RB**

List box: Off, On

Default = Off

The RP570 Slave expects to receive RB packets from the Master. When the Local simulation RB on the Master is On, the RB packets are transferred over the mobile network only in the RB Net period (see the Master settings). The Local simulation RB has to be set the same (On or Off) on all sites in the network, i.e. on the master as well as all Slaves.

If **On**, the Unit generates RB packets locally and transmits them over the COM interface in the RB Request period and expects the RB response for each RB packet from the RP570 Slave within the RB Response timeout. When the Unit does not receive the response(s) from the RP570 Slave, the Unit does not respond to the RB packet from the Master, which it receives over the mobile networks.

- **RB Request period [ms]**

Default = 200 (maximum=8190)

M!DGE/RipEX sends locally RB packets to the connected RTU in the set period.

- **RB Response timeout [ms]**

Default = 500 (maximum=8190)

The Unit expects a response to the RB packet within the set timeout. If it is not received, the Unit does not respond to RB packets from the Master received over the mobile network.

- **RTU address (Hex)**

Default = 01

Active only when the Local simulation RB is On. The connected RTU's address is supposed to be filled in. This address (0x00-0xFF) is used in the RB packets generated locally in the M!DGE/RipEX and transmitted over the COM.

Siemens 3964(R)

The 3964 protocol is utilized by the Siemens Company as a Point-to-Point connection between two controllers. Meanwhile it has become an industry standard that can be found on many devices as a universal communications interface. 3964R is the same as 3964, in addition it only uses BCC (Block Check Character). 3964(R) handle only the link layer (L2 in OSI model), hence Unit uses a similar way to read "SCADA address" as in UNI protocol.

There is a handshake STX(0x02) – DLE(0x10) at the start of communication and DLE+ETX – DLE at the end. This handshake is performed by M!DGE/RipEX locally, it is not transferred over the network.

Communication goes as follows:

LocalRTU→STX→LocalRipex

LocalRipex→DLE→LocalRTU

LocalRTU→DATA+DLE+ETX+BCC→LocalRipex

LocalRipex→DATA→RemoteRipex*

LocalRipex→DLE→LocalRTU

RemoteRipex→STX→RemoteRTU

RemoteRTU→DLE→RemoteRipex

RemoteRipex→DATA+DLE+ETX+BCC→RemoteRTU

RemoteRTU→DLE→RemoteRipex

* only this packet is transferred over the RipEX network, all the other ones are handled locally.

Italicised parameters are described in *Common parameters*.

Mode of Connected device

Master

- **Address mode**

List box: Binary (1 B), Binary (2B LSB first), Binary (2B MSB first).

Default = Binary (1 B)

MIDGE/RipEX reads the Protocol address in the format and length set (in bytes).

- **Address position**

Specify the sequence number of the byte, where the Protocol address starts.

Note 1: 3964(R) protocol uses an escape sequence (control sequence) for DLE (0x10), i.e. when 0x10 is in user data, 0x1010 is sent instead. When the address position is calculated, the bytes added by the escape sequence algorithm are not taken into account.

Note 2: The first byte in the packet has the sequence number 1, not 0.

Broadcast

Address translation

Table

Mask

Slave

Broadcast accept

- **DLE timeout [ms]**

Default = 1000 (min. 300, max. 8190)

MIDGE/RipEX expects a response (DLE) from the connected device (RTU) within the set timeout. If it is not received, the Unit repeats the frame according to the "Retries" setting.

- **Retries [No]**

Default = 3 (min. 0, max. 7)

When DLE timeout is „On“, and the DLE packet is not received from the connected device (RTU) within the set DLE timeout, the Unit retransmits the frame. The number of possible retries is specified.

- **Priority**

List box: Low, High

Default = Low

When the equipment sends STX and receives STX instead of DLE, there is a collision, both devices want to start communication. In such a case, one unit has to have priority. If the Priority is High, the Unit waits for DLE. When it is Low, the Unit send DLE.

Note: Obviously, two devices which are communicating together must be set so that one has High priority and the other has Low.

- **BCC**

List box: On, Off
Default = On

BCC (Block Check Character) is a control byte used for data integrity control, it makes the reliability higher. BCC is used by 3964R, 3964 does not use it.

The unit checks (calculates itself) this byte while receiving a packet on COM. Unit transmits DLE (accepts the frame) only when the check result is OK. The BCC byte is not transferred over the network, it is calculated locally in the end Unit and appended to the received data.

UNI

UNI is the "Universal" protocol utility designed by RACOM. It is supposed to be used when the application protocol is not in the Unit list. The key condition is that messages generated by the Master application device always contain the respective Slave address and that address (or its relevant part) position, relative to the beginning of the message (packet, frame), is always the same (Address position).

Generally two communication modes are typical for the UNI protocol: In the first one, communication always has to be initiated by the Master and only one response to a request is supported; in the second mode, Master-Master communication or combination of UNI protocol with ASYNC LINK protocol and spontaneous packet generation on remote sites are possible.

The UNI protocol is fully transparent, i.e. all messages are transported and delivered in full, without any modifications.

Italicised parameters are described in *Common parameters*.

Mode of Connected device

Master

- **Address mode**

List box: Binary (1 B), ASCII (2 B), Binary (2B LSB first), Binary (2B MSB first).

Default = Binary (1 B)

M!DGE/RipEX reads the Protocol address in the format and length set (in bytes).

The ASCII 2-byte format is read as 2-character hexadecimal representation of one-byte value. E.g. ASCII characters AB are read as 0xAB hex (10101011 binary, 171 decimal) value.

- **Address position**

Specify the sequence number of the byte, where the Protocol address starts. Note that the first byte in the packet has the sequence number 1, not 0.

- **Address mask (Hex)**

When the Address mode is Binary 2 bytes, a 16-bit value is read from the SCADA protocol message according to the Address mode setting (either the MSB or the LSB first), The resulting value is then bit-masked by the Address mask and used as the input value for SCADA to IP address translation (e.g. via a table). The default value of the Address mask is 0xFFFF, hence the full 16-bit value is used by default.

Example:

The Address mode is set to Binary (2B LSB first), the Address mask is set to 7FF0 and the Address position is set to 2. The SCADA message starts with bytes (in hex) 02 DA 92 C3 .. The 2-byte address is read as 0x92DA (note the LSB came first in the message), Then 0x7FF0 mask is applied and the resulting value 0x12D0 (0x92DA & 0x7FF0) is used as the input for the translation.

- **Poll response control**

List box: On, Off

Default = On

On – The Master accepts only one response per request and it must come from the specific remote to which the request was sent. All other packets are discarded. This applies to the Master–Slave communication scheme.

Note: It may happen, that a response from a Slave (No.1) is delivered after the respective timeout expired and the Master generates the request for the next Slave (No.2) in the meantime. In such a case the delayed response from No.1 would have been considered as the response from No.2. When Poll response control is On, the delayed response from the Slave No.1 is discarded and the Master stays ready for the response from No.2.

Off – The Master does not check packets incoming from the mobile network - all packets are passed to the application. That allows e.g. spontaneous packets to be generated at remote sites. This mode is suitable for the Master–Master communication scheme or a combination of the UNI and ASYNC LINK protocols.

Broadcast

Address translation

Table

Mask

Slave

Broadcast accept

7.2.7. Digital I/O

The Digital I/O page displays the current status of the I/O ports and can be used to turn output ports on or off.

You can apply the following settings:

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

WAN
Link Management
Supervision
Settings

Ethernet
Port Assignment
VLAN Management
IP Settings

Mobile
SIMs
Interfaces

USB

Serial Port

Digital I/O

Digital I/O Port Administration

DO1: <input type="checkbox"/>	off	<input type="button" value="turn on"/>
DO2: <input checked="" type="checkbox"/>	on	<input type="button" value="turn off"/>
DI1:	off	
DI2:	off	

Digital I/O Port Configuration

DO1 after reboot:	<input type="button" value="default v"/>
DO2 after reboot:	<input type="button" value="default v"/>

Besides on and off you may keep the status after reboot at default which corresponds to the default state as the hardware will be initialized at power-up.


The digital inputs and outputs can also be monitored and controlled by SDK scripts.

7.2.8. GNSS (optional)


Specification:

Receiver	72-channel GPS/QZSS L1 C/A, GLONASS L10F, BeiDou B1I, Galileo E1B/C, SBAS L1 C/A: WAAS, EGNOS, MSAS, GAGAN
Data stream	JSON or NMEA
Tracking sensitivity	up to -162 dBm
Supported antennas	active

The GNSS antenna port have the following specification:



Max. allowed cable length	30m
Max. allowed antenna gain	3.0 dBi
Min. distance between colocated radio transmitter antennas (e.g.: GNSS to LTE)	20cm
Connector type	SMA
Time pulse	TTL logic (L: 0 to 0.8 V, H: 2 to 3.3 V), minimal connected load 100 Ω



GNSS status

This pages provides further information about the satellites in view and values derived from them:

Azimuth frames	The azimuth (rotation around the vertical axis) in degrees as stated in GPGSV
SNR	The SNR (Signal to Noise Ratio), often referred as signal strength

**Note**

Please note that the values are shown as calculated by the daemon, their accuracy might be suggestive.

Administration

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Configuration | Position | Satellites | Supervision

GNSS Module Configuration

Administrative status: enabled
 disabled

Operation mode: standalone

Antenna type: active (3V DC)
 passive

Accuracy: 50 meters

Fix frame interval: 1 seconds

GNSS Server Configuration

Server port: 2947

Allow clients from: nowhere
 everywhere
 specify

Clients start: in raw mode

Apply

The GNSS page lets you enable or disable the GNSS modules present in the system and can be used to configure the daemon that can be used to share access to receivers without contention or loss of data and to respond to queries with a format that is substantially easier to parse than the NMEA 0183 emitted directly by the GNSS device.

We are currently running the Berlios GPS daemon (version 3.15), supporting the new JSON format. Please navigate to <http://www.catb.org/gpsd/> for getting more information about how to connect any clients to the daemon remotely. The position values can also be queried by the CLI and used in SDK scripts.

GNSS Module Configuration

Administrative status	Enable or disable the GNSS module
Operation mode	The mode of operation, either standalone or assisted (for AGPS)
Antenna type	The type of the connected GPS antenna, active 3 VDcT powered
Accuracy	The desired accuracy in meters

Fix frame interval

The amount of time to wait between 1x attempts

GNSS Server Configuration

Server port	The TCP port on which the daemon is listening for incoming connections
Allow clients from	Specifies where clients can connect from, can be either everywhere or from a specific network
Clients start mode	Specifies how data transferal is accomplished when a client connects. You can specify on request which typically requires an R to be sent. Data will be sent instantly in case of raw mode which will provide NMEA frames or super-raw which includes the original data of the GPS receiver. If the client supports the JSON format (i.e. newer libgps is used) the json mode can be specified.



Note

Please consider to restrict access to the server port, either by a specifying a dedicated client network or by using a firewall rule.

Satellites

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Satellites
Configuration
Position
Supervision

GNSS Satellites

25 satellites in view (17 used)

- WAN
 - Link Management
 - Supervision
 - Settings
- Ethernet
 - Port Setup
 - VLAN Management
 - IP Settings
- Mobile
 - Modems
 - SIMs
 - Interfaces
- Bridges
- USB
- Serial
- GNSS**

Supervision

WAN
Link Management
Supervision
Settings
Ethernet
Port Setup
VLAN Management
IP Settings
Mobile
Modems
SIMs
Interfaces
Bridges
USB
Serial
GNSS

HOME | **INTERFACES** | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Configuration	Position	Satellites	Supervision
---------------	----------	------------	--------------------

GNSS Supervision

Administrative status: enabled
 disabled

Mode: validate NMEA stream
 validate GPS fix

Max. downtime: seconds

Emergency action: restart server
 reset module

GNSS supervision

Administrative status	Enable or disable GNSS supervision
Mode	Specifies whether to monitor the NMEA stream or GPS fixes
Max. downtime	The period of time without valid NMEA stream or GPS 1x after which an emergency action shall be taken
Emergency action	The corresponding emergency action. You can either let just restart the server, which will also re-initialize the GPS function on the module, or reset the module in severe cases. Please note that this may have effects on any running WWAN/SMS services.

7.3. ROUTING

7.3.1. Static Routes

This menu shows all routing entries of the system, which can consist of active and configured ones. (Netmasks can be specified in CIDR notation, e.g. **24** expands to 255.255.255.0).

- Static Routes
- Extended Routes
- Multipath Routes
- Multicast
 - IGMP Proxy
 - Static Routes
- BGP
- OSPF
- Mobile IP
 - Administration
- QoS
 - Administration
 - Classification

Static Routes

This menu shows all routing entries of the system, they can consist of active and configured ones. The flags are as follows: (A)ctive, (P)ersistent, (H)ost Route, (N)etwork Route, (D)efault Route (Netmasks can be specified in CIDR notation)

Destination	Netmask	Gateway	Interface	Metric	Flags
0.0.0.0	0.0.0.0	0.0.0.0	WWAN1	0	AD
10.203.0.29	255.255.255.255	0.0.0.0	WWAN1	0	APH  
10.203.0.227	255.255.255.255	0.0.0.0	WWAN1	0	AH 
192.168.2.0	255.255.255.0	192.168.1.254	LAN4	0	PN  
192.168.10.0	255.255.255.0	0.0.0.0	LAN1	0	AN
					

Route lookup

- Destination:** Destination network or host provided by IP addresses in dotted decimal.
- Netmask:** Subnet mask which forms, in combination with the destination, the network to be addressed. A single host can be specified by a netmask of 255.255.255.255, a default route corresponds to 0.0.0.0.
- Gateway:** The next hop which operates as gateway for this network (can be omitted on peer-to-peer links).
- Interface:** Network interface on which a packet will be transmitted in order to reach the gateway or network behind.
- Metric:** The routing metric of the interface (default 0). The routing metric is used by routing protocols, higher metrics have the effect of making a route less favourable; metrics are counted as additional costs to the destination network.
- Flags:** (A)ctive, (P)ersistent, (H)ost Route, (N)etwork Route, (D)efault Route
 The flags obtain the following meanings:
 - Active The route is considered active, it might be inactive if the interface for this route is not yet up
 - Persistent The route is persistent, which means it is a configured route, otherwise it corresponds to an interface route
 - Host The route is a host route, typically the netmask is set to 255.255.255.255.
 - Network The route is a network route, consisting of an address and net-mask which forms the subnet to be addressed
 - Default Route The route is a default route, address and netmask are set to 0.0.0.0, thus matching any packet

You can check the corresponding routing via the "Route lookup" functionality. Just fill in the desired IP address and click on the "Lookup" button. The detailed information about the chosen route will be displayed.

**Note**

The maximum number of manual static routes is 10. This number can be increased to 30 with a SERVER licence.

Static Routes
Extended Routes
Multipath Routes
Mobile IP Administration

[HOME](#) | [INTERFACES](#) | **[ROUTING](#)** | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

Route Lookup

Address / Host:

8.8.8.8 is being routed to **LAN2** via **192.168.131.254** using source address 192.168.131.234

7.3.2. Extended Routes

Extended routes can be used to perform policy-based routing, they generally precede static routes.

Extended routes can be made up not only of a destination address/netmask but also a source address/netmask, incoming interface and the type of service (TOS) of packets.

Static Routes
Extended Routes
Multipath Routes
Multicast
BGP
OSPF
Mobile IP Administration
QoS Administration Classification

[HOME](#) | [INTERFACES](#) | **[ROUTING](#)** | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

Add Extended Route

Incoming interface:

Source address:

Source netmask:

Destination address:

Destination netmask:

Protocol:

Type of Service:

Route to:

Gateway:

Interface: discard if down

Incoming interface	The interface on which the packet enters the system
Source address	The packet source address
Source netmask	The packet source netmask
Destination address	The packet destination address
Destination netmask	The packet destination netmask
Protocol	Protocol used (ANY, UDP or TCP)

Type of Service	The ToS value within the packet header (possible values are any, normal-service (0), minimize-cost (2), maximize-reliability (4), maximize-throughput (8), minimize-delay (16))
Route to	Specifies the target interface or gateway to where the packet should get routed to. Check the "discard if down" option for discarding data if the Interface is down (e.g. nothing is connected).

7.3.3. Multipath Routes

Multipath routes perform weighted IP-session distribution for particular subnets across multiple interfaces.

[HOME](#) | [INTERFACES](#) | **[ROUTING](#)** | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

Static Routes
Extended Routes
Multipath Routes
Mobile IP Administration
QoS Administration Classification

Add Multipath Route

Target network:	<input type="text" value="77.75.0.0"/>
Target netmask:	<input type="text" value="255.255.0.0"/>
Distribution:	
Interface:	<input type="text" value="WWAN1"/>
Weight:	<input type="text" value="1"/>
Gateway:	<input type="text" value="0.0.0.0"/> (optional)
Interface:	<input type="text" value="LAN2"/>
Weight:	<input type="text" value="1"/>
Gateway:	<input type="text" value="192.168.131.254"/> (optional)
	<input type="button" value="+"/>

At least two interfaces must be defined to establish the Multipath routing. Additional interfaces can be added by pressing the "plus" sign.

Target network/netmask	The target network for which the Multipath routing will be applied
Interface	The interface for the selected path
Weight	Interface weight in relation to the others (e.g. values 4 and 1 for two paths will result in 80 and 20 % of distribution)
Nexthop	Nexthop address to be used as a default gateway for the selected interface

7.3.4. Multicast

Multicast routing (MCR) can be configured and managed by a daemon. Only one MCR daemon can be used at a time.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes

Extended Routes

Multipath Routes

Multicast

IGMP Proxy

Static Routes

Administrative status: IGMP proxy
 static routes
 disabled

Apply

MIDGE routers ship with two different MCR daemons to select from, depending on your dependencies:

- | | |
|---------------|---|
| IGMP proxy | Forwarding of multicast messages that are dynamically detected on a given interface to another interface. |
| Static routes | List of MCR rules to forward messages of dedicated source and group from a given interface to another. |
| Disabled | Disable routing of multicast messages. |

IGMP proxy

IGMP proxy which is able to maintain multicast groups on a particular interface and distribute incoming multicast packets towards the downstream interfaces on which hosts have joined the groups.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes

Extended Routes

Multipath Routes

Multicast

IGMP Proxy

Static Routes

BGP

OSPF

IGMP Proxy

Incoming interface:

Sender network:

Sender netmask:

Distribute to:

Apply

- | | |
|-----------------------|---|
| Administrative status | Specifies whether multicast routing is active. |
| Incoming interface | The upstream interface on which multicast groups are joined and on which multicast packets come in. |
| Distribute to | Specifies the downstream interfaces to which multicast packets will be forwarded. |

Static Routes

Routes multicast messages in different directions depending on their origin and group based on a given set of MCR rules:

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

- Static Routes
- Extended Routes
- Multipath Routes
- Multicast
 - IGMP Proxy
 - Static Routes
- BGP
- OSPF

Add Static Multicast Route

Group:

Source:

Incoming interface: NONE ▾

Outgoing interface: NONE ▾

Group	IP address of MCR group.
Source	Source-IP of the packets.
Incoming interface	Interface to listen on for messages of given group and source.
Outgoing interface	Interface to forward the messages to.

7.3.5. BGP

The BGP tab allows to set up peerings of the M!DGE router with other Border Gateway Protocol enabled routers.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

- Static Routes
- Extended Routes
- Multipath Routes
- Multicast
- BGP**
- OSPF
- Mobile IP
 - Administration
- QoS
 - Administration
 - Classification

General
Neighbors
Networks

BGP General Settings

Administrative status: enabled
 disabled

AS number:

Redistribute connected routes:

Redistribute local routes:

Redistribute OSPF routes:

Disable when redundancy backup:

BGP status	Specifies whether the BGP routing protocol is active.
AS number	The number of the autonomous system to which the M!DGE router belongs (available range: 1 - 4294967295).
Redistribute connected routes	Redistribute routes to networks which are directly connected to the M!DGE router.
Redistribute local routes	Redistribute routes from the M!DGE router's own routing table.

Redistribute OSPF routes	Redistribute routes learned via the OSPF routing protocol.
Disable when redundancy backup	Disables the BGP protocol when the router is set to slave mode by the VRRP redundancy protocol.

The neighbors tab is used to configure all the BGP routers to peer with.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes
Extended Routes
Multipath Routes
Multicast
BGP
OSPF
Mobile IP Administration

General | **Neighbors** | Networks

Add BGP Neighbor

IP address:

AS number:

Password:

Multihop:

Apply Cancel

IP address	IP address of the peer router.
As number	Autonomous system number of the peer router (available range 1 - 4294967295).
Password	Password for authentication with the peer router. If left blank authentication is disabled.
Multihop	Allow multiple hops between this router and the peer router instead of requiring the peer to be directly connected.

The Networks tab allows to add IP network prefixes that shall be distributed via BGP in addition to the networks that are redistributed from other sources as defined on the general tab.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes
Extended Routes
Multipath Routes
Multicast
BGP
OSPF

General | **Neighbors** | **Networks**

Add BGP Network

Prefix:

Prefix length:

Apply Cancel

Prefix	Prefix of the network to be distributed.
Prefix length	Length of the prefix to be distributed.

7.3.6. OSPF

The OSPF tab allows the M!DGE router to be added to a network of OSPF routers.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes

Extended Routes

Multipath Routes

Multicast

BGP

OSPF

Mobile IP Administration

QoS Administration Classification

General Interfaces Networks

OSPF General Settings

Administrative status: enabled disabled

Redistribute connected routes:

Redistribute local routes:

Redistribute BGP routes:

Redistribute default route:

Disable when redundancy backup:

Apply

- OSPF status** Specifies whether the OSPF routing protocol is active.
- Redistribute connected routes** Redistribute routes to networks which are directly connected to the M!DGE router.
- Redistribute local routes** Redistribute routes from the M!DGE router’s own routing table.
- Redistribute BGP routes** Redistribute routes learned via the BGP routing protocol.
- Redistribute default route** Redistribute the routers default route.
- Disable when redundancy backup** Disables the OSPF protocol when the router is set to slave mode by the VRRP redundancy protocol.

The interfaces tab is used to define OSPF specific settings for the IP interfaces of the router. If no settings are defined for a specific interface, default settings will be used.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes

Extended Routes

Multipath Routes

Multicast

BGP

OSPF

Mobile IP Administration

QoS Administration Classification

General Interfaces Networks

Add OSPF Interface

Interface:

Authentication:

Key:

Key ID:

Cost:

Passive:

Apply Cancel

- Interface** The name of the interface for which settings shall be defined.

Authentication	The authentication protocol to be used on the interface to authenticate OSPF packets.
Key	The key to be used for authentication.
Key ID	The ID of the key to be used for authentication (1-255).
Cost	The cost for sending packets via this interface. If not specified or set to 0, OSPF defaults are used.
Passive	Do not send out OSPF packets on this interface.

The networks tab defines the IP networks to be handled in OSPF as well as to which routing area they belong.

The screenshot shows a web configuration interface with a navigation menu at the top: HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT. Below the menu are three tabs: General, Interfaces, and Networks (which is selected). On the left side, there is a sidebar menu with items: Static Routes, Extended Routes, Multipath Routes, Multicast, BGP, OSPF, and Mobile IP Administration. The main content area is titled 'Add OSPF Network' and contains three input fields: 'Prefix:' (a wide text box), 'Prefix length:' (a small text box), and 'Area:' (a small text box). At the bottom of the form are two buttons: 'Apply' and 'Cancel'.

Prefix	Prefix of the network.
Prefix length	Length of the prefix.
Area	Routing area to which this interface belongs (0-65535, 0 means backbone).

7.3.7. Mobile IP

Mobile IP (MIP) can be used to enable a seamless switch between different WAN technologies.

It boasts with very small outages during switchover while keeping all IP sessions alive which is being accomplished by communicating with the static public IP address of a home agent which will encapsulate the packets and send them further to the router. Switching works by telling the home agent that the hotlink address has changed, the agent will then re-route (that means encapsulate the packets with the new target address) the packets transparently down to the box.

Our implementation supports RFC 3344, 5177, 3024 and 3519 and interoperability with Cisco has been verified. However, MIDGE routers can run as node and home agent which makes them able to replace expensive kits in the backbone for smaller scenarios.

Static Routes

Extended Routes

Multipath Routes

Mobile IP

Administration

QoS

Administration

Classification

Mobile IP

Mobile IP can be used to move from one network to another while maintaining a permanent IP address and thus avoiding that running IP sessions (including VPN tunnels) must be reconnected.

Administrative status: mobile node
 home agent
 disabled

Primary home agent address:

Secondary home agent address: (optional)

Home address:

SPI:

Authentication type:

Shared secret:

Life time:

MTU:

UDP encapsulation: enabled disabled

Mobile network address: (optional)

Mobile network mask: (optional)

Apply

If MIP is run as the Mobile node, the following settings can be configured:

- Primary home agent address: The address of the primary home agent
- Secondary home agent address: The address of the secondary (fallback) home agent
- Home address: The permanent home address of the node which can be used to address the box
- SPI: The Security Parameter Index (SPI) identifying the security context between a pair of nodes (represented in 8 chars hex)
- Authentication type: The used authentication, can be prefix-suffix-md5 or hmac-md5
- Shared secret: The shared secret used for authentication, can be a 128-bit hex or ASCII string
- Life time: The lifetime of security associations in seconds
- MTU: Maximum transmission unit in bytes
- UDP encapsulation: Specifies whether UDP encapsulation shall be used
- Mobile network address: Optionally specifies a subnet which should be routed to the box
- Mobile network mask: The netmask for the optional routed network

[HOME](#) | [INTERFACES](#) | **[ROUTING](#)** | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

[Static Routes](#)

[Extended Routes](#)

[Multipath Routes](#)

Mobile IP

Administration

[QoS](#)

Administration

Classification

Mobile IP

Mobile IP can be used to move from one network to another while maintaining a permanent IP address and thus avoiding that running IP sessions (including VPN tunnels) must be reconnected.

Administrative status:

mobile node

home agent

disabled

Home network address:

Home network mask:

If MIP is run as home agent, you will have to set up a home address and netmask first and configure various nodes afterwards which are made up of the following settings:

SPI	The home address of the network
Authentication type	The mask for the home network.
Shared secret	The shared secret used for the mobile node authentication at the home agent. This can be either a 128-bit hexadecimal value or a random length ASCII string.

[HOME](#) | [INTERFACES](#) | **[ROUTING](#)** | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

[Static Routes](#)

[Extended Routes](#)

[Multipath Routes](#)

Mobile IP

Administration

Mobile Nodes

SPI:

Authentication type:

Shared secret:

7.3.8. Quality of Service (QoS)

M!DGE routers are able to prioritize and shape certain kinds of IP traffic. This is currently limited on egress, which means that only outgoing traffic can be stipulated. The current QoS solution is using Stochastic Fairness Queueing (SFQ) classes in combination with Hierarchy Token Bucket (HTB) qdiscs. Its principle of operation can be summarized as ceiling the max. throughput per link and shaping traffic by reflecting the specified queue priorities. In general, the lowest priority number of a queue gets most out of the available bandwidth.

In case of demands for other class or qdisc algorithms please contact our support team in order to evaluate the best approach for your application.

QoS Administration

The administration page can be used to enable and disable QoS.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes

Extended Routes

Multipath Routes

Multicast

BGP

OSPF

Mobile IP
Administration

QoS
Administration
Classification

Quality Of Service

QoS can be used to prioritize or reserve a specific bandwidth for your IP services. You can configure multiple queues on the interfaces and assign services to them by means of IP packet selectors.

Administrative Status enabled
 disabled

Apply

QoS Classification

The classification section can be used to define the WAN interfaces on which QoS should be active.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes

Extended Routes

Multipath Routes

Multicast

BGP

OSPF

Mobile IP
Administration

QoS
Administration
Classification

Add QoS Interface

Interface:

Bandwidth congestion:

Upstream bandwidth: Mbit/s

Apply Cancel

Interface: The WAN interface on which QoS should be active.

Bandwidth congestion: The bandwidth congestion method. In case of the auto option, the system will try to apply limits in a best-effort way. However, it is suggested to set fixed bandwidth limits as they also offer a way of tuning the QoS behaviour.

Upstream bandwidth:	The available bandwidth for outgoing traffic.
IP to ping (primary)	An IP, which answers ICMP echo requests to determine the bandwidth of the link.
IP to ping (secondary)	An IP, which answers ICMP echo requests to determine the bandwidth of the link.

When defining limits, you should consider bandwidth limits which are at least possible as most shaping and queues algorithms will not work correctly if the specified limits cannot be achieved. In particular, any WWAN interfaces operating in a mobile environment are suffering variable bandwidths, thus rather lower values should be used.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes

Extended Routes

Multipath Routes

Multicast

BGP

OSPF

Mobile IP Administration

QoS
Administration
Classification

QoS Classification

Interface	Bandwidth	Queues
WWAN1	fixed 4.00 Mbit/s up	Outbound:
		high prio 1 0.00 Mbit/s
		default prio 2 0.00 Mbit/s
		low prio 3 0.00 Mbit/s

Apply

In case an interface has been activated, the system will automatically create the following queues:

high:	A high priority queue which may hold any latency-critical services (such as VoIP).
default:	A default queue which will handle all other services.
low:	A low priority queue which may hold less-critical services for which shaping is intended.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes

Extended Routes

Multipath Routes

Multicast

BGP

OSPF

Mobile IP Administration

QoS
Administration
Classification

Edit Outbound QoS Queue on WWAN1

Name:

Set TOS:

Priority:

Upstream bandwidth: Mbit/s

Assigned Services

Source	Destination	Type of Service

Apply Cancel

Each queue can be configured as follows:

Name:	The name of the QoS queue.
Priority:	A numerical priority for the queue, lower values indicate higher priorities.

Bandwidth: The maximum possible bandwidth for this queue in case the total bandwidth of all queues exceeds the set upstream bandwidth of "QoS Interface Parameters".

Set TOS The TOS/DiffServ value to set on matching packets.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Static Routes

Extended Routes

Multipath Routes

Multicast

BGP

OSPF

Mobile IP
Administration

QoS
Administration
Classification

Add QoS Service

Interface: WWAN1

Queue: high (outbound)

Source: ANY specify
Address:
Netmask:

Destination: ANY specify
Address:
Netmask:

Protocol:

Source port: ANY specify

Destination port: ANY specify

Type of Service:

- unspecified
- normal-service (0)
- minimize-cost (2)
- maximize-reliability (4)
- maximize-throughput (8)
- minimize-delay (16)
- numeric

You can now configure and assign any services to each queue. The following parameters apply:

- Interface:** The QoS interface of the queue
- Queue:** The QoS queue to which this service shall be assigned
- Source:** Specifies a network address and netmask used to match the source address of packets
- Destination:** Specifies a network address and netmask used to match the destination (target) address of packets
- Protocol:** Specifies the protocol for packets to be matched
- Type of Service:** Specifies the ToS/DiffServ for packets to be matched

7.4. FIREWALL

This router uses Linux's netfilter/iptables firewall framework (see <http://www.netfilter.org> for more information). It is set up of a range of rules which control each packet's permission to pass the router. Packets, not matching any of the rules, are allowed by default.

7.4.1. Firewall

Administration

The administration page can be used to enable and disable firewalling. When turning it on, a shortcut can be used to generate a predefined set of rules which allow administration (over HTTP, HTTPS, SSH or TELNET) by default but block any other packets coming from the WAN interface. Please note that the specified rules are processed by order, that means, traversing the list from top to bottom until a matching rule is found. If there is no matching rule found, the packet is allowed.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | **[FIREWALL](#)** | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

Firewall

- Administration
- Address / Port Groups
- Filtering Rules

NAPT

- Administration
- Inbound Rules
- Outbound Rules

Firewall Administration

Administrative status: enabled
 disabled

Allow WAN administration:

Administrative status: Enable or disable packet filtering.

Allow WAN administration: This option will predefine the rules for services on the WAN link as follows (TCP ports 80, 443, 22 and 23):

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | **[FIREWALL](#)** | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

Firewall

- Administration
- Address / Port Groups
- Filtering Rules

NAPT

- Administration
- Inbound Rules
- Outbound Rules

Firewall Filtering Rules

This menu can be used to filter the packets passing the device and targeting its services. Packets which are not matching any of the rules below will be ALLOWED.

Description	Mode	Source	Destination	Port(s)	
ALLOW-WAN-ADMIN	ALLOW	ANY on WAN	ANY	TCP ADMIN-PORTS	
DENY-WAN-ALL	DENY	ANY on WAN	ANY	ANY	

Address / Port Groups

This menu can be used to form address or port groups which can be later used for firewall rules in order to reduce the number of rules.

Firewall

- Administration
- Address / Port Groups
- Filtering Rules

NAPT

- Administration
- Inbound Rules
- Outbound Rules

Firewall Port Groups

Description	Ports	
ADMIN-PORTS	80, 443, 22, 23	 
		

Add Firewall Rule

Firewall

- Administration
- Address / Port Groups
- Filtering Rules

NAPT

- Masquerading
- Inbound Rules
- Outbound Rules

Edit Firewall Rule

Description:

Action: log matches

Incoming interface:

Outgoing interface:

Source: ANY MAC LOCAL specify

Destination: ANY LOCAL specify

Protocol:

Destination port(s): single port multiple ports group
 80, 443, 22, 23

- Description: A meaningful description about the purpose of this rule.
- Action: Whether the packets of this rule should be allowed or denied.
- Log matches: Throw a syslog message if rule matches.
- Incoming interface: The Interface on which matching packets are received.
- Outgoing interface: The interface on which matching packets are received.
- Source: Source address of matching packets. Possible values are "ANY", "LOCAL" (addressed to the system itself), "Group" or "Specify" (specified by an address/netmask).
- Destination: The destination address of matching packets, can be "ANY", "LOCAL" (addressed ... itself), "Group" or "Specify" (specified by address/netmask).
- Protocol: Used IP protocol of matching packets.
- Destination port(s): Destination port of matching packets. You can specify a single port or a range of ports here. Note that protocol must be set to UDP/TCP when using port filters.

Transparent Firewall

M!DGE can be configured with its Ethernet interfaces being bridged. In this case, the transparent firewall functionality can be configured to limit reachability of individual hosts connected to M!DGE based on their MAC addresses, i.e. units connected to ETH1 cannot communicate to units connected to ETH2.

M!DGE



HOME | INTERFACES | ROUTING | **FIREWALL** | VPN | SERVICES | SYSTEM | LOGOUT

Firewall

- Administration
- Address / Port Groups
- Filtering Rules

NAPT

- Administration
- Inbound Rules
- Outbound Rules

Firewall Filtering Rules

This menu can be used to filter the packets passing the device and targeting its services. Packets which are not matching any of the rules below will be ALLOWED.

Description	Mode	Source	Destination	Port(s)	
Rule1	DENY	00:13:3B:99:9F:9F on LAN1	ANY	ICMP	
Rule2	DENY	00:14:38:05:CE:BC on LAN2	ANY	ICMP	

7.4.2. NAPT

This page allows setting of the options for Network Address and Port Translation (NAPT). NAPT translates IP addresses or TCP/UDP ports and enables communication between hosts on a private network and hosts on a public network. It generally allows a single public IP address to be used by many hosts from the private LAN network.

Administration

The administration page lets you specify the interfaces on which masquerading will be performed. NAT will hereby use the address of the selected interface and choose a random source port for outgoing connections and thus enables communication between hosts from a private local area network towards hosts on the public network.

HOME | INTERFACES | ROUTING | **FIREWALL** | VPN | SERVICES | SYSTEM | LOGOUT

Firewall

- Administration
- Address / Port Groups
- Filtering Rules

NAPT

- Masquerading
- Inbound Rules
- Outbound Rules

Masquerading

This menu can be used to configure the interfaces on which masquerading will be performed.

Interface	Source	
WAN	ANY	

Interface The outgoing interface on which connections will be masqueraded.

Source address The source address or network from which matching packets are masqueraded.

- Firewall
 - Administration
 - Address / Port Groups
 - Filtering Rules
- NAPT**
 - Masquerading
 - Inbound Rules
 - Outbound Rules

Add Masquerading Rule

Interface:

Source: ANY specify

Address:

Netmask:

Inbound Rules

Inbound rules can be used to modify the target section of IP packets and, for instance, forward a service or port to an internal host. By doing so, you can expose that service and make it available from the Internet. You may also establish 1:1 NAT mapping for a single host using additional outbound rules.



Note

The rules are processed by order, that means, traversing the list from top to bottom until a matching rule is found. If there is no matching rule found, the packet will pass as is.

- Firewall
 - Administration
 - Address / Port Groups
 - Filtering Rules
- NAPT**
 - Masquerading
 - Inbound Rules
 - Outbound Rules

Add NAPT Rule For Inbound Packets

Description:

Map: host network

Packet Selection

Incoming interface:

Source: ANY specify

Target address: ANY specify

Target protocol / port(s): to

Redirect to

Address:

Port: same port specify

- Description: A meaningful rule description
- Incoming interface: Interface from which matching packets are received
- Source: The source address or network from which matching packets are received.
- Map: Choosing whether the rule applies to the host or to the network.

Target address:	Destination address of matching packets (optional)
Target port(s):	Used UDP/TCP port range of matching packets
Redirect to:	Address to which matching packets will be redirected
Redirect port:	Port to which matching packets will be targeted

Outbound Rules

Outbound rules will modify the source section of IP packets and can be used to establish 1:1 NAT mappings but also to redirect packets to a specific service.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | **[FIREWALL](#)** | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

Firewall

[Administration](#)
[Address / Port Groups](#)
[Filtering Rules](#)

NAPT

[Masquerading](#)
[Inbound Rules](#)
[Outbound Rules](#)

Add NAPT Rule For Outbound Packets

Description:	<input type="text"/>
Map:	<input type="radio"/> host <input checked="" type="radio"/> network
Packet Selection	
Outgoing interface:	<input type="text" value="WAN"/>
Target:	<input checked="" type="radio"/> ANY <input type="radio"/> specify
Source network:	<input type="text"/>
Source netmask:	<input type="text"/>
Rewrite to	
Network:	<input type="text"/>
Netmask:	<input type="text"/>
<input type="button" value="Add"/> <input type="button" value="Cancel"/>	

Description:	A meaningful description of this rule
Map:	Choosing whether the rule applies to the host or to the network.
Outgoing interface:	Outgoing interface on which matching packets are leaving the router
Target	The target address or network to which matching packets are destined.
Source address/ports:	Source address/ports of matching packets (if Map is set to "host")
Source network/netmask:	Source network/netmask of matching packets (if Map is set to "network")
Rewrite to address/port:	Address/port to which the source address/port of matching packets will be rewritten to
Rewrite to network/netmask:	Network/netmask to which the source network/netmask of matching packets will be rewritten to

7.5. VPN

7.5.1. OpenVPN

Administration

- OpenVPN administrative status Enable or disable OpenVPN.
- Restart on link change If checked, the tunnel is restarted whenever any link changes the status.
- Multipath TCP Enables OpenVPN multipath TCP support.

If enabled, OpenVPN client configurations will be started whenever a WAN link has been established. Server configuration will be started immediately after the bootup.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | [SYSTEM](#) | [LOGOUT](#)

OpenVPN

Administration

Tunnel Configuration

IPsec

Administration

Tunnel Configuration

PPTP

Administration

Tunnel Configuration

OpenVPN Administration

OpenVPN administrative status: enabled
 disabled

Restart on link change:

Multipath TCP support:

Tunnel Configuration

The router supports a single server tunnel and up to 4 client tunnels. You can specify tunnel parameters in standard configuration or upload an expert mode file which has been created in advance. Refer to section *the section called "Client Management"* to learn more about how to manage clients and generate the files.

- Operation mode Choose the client or server mode for this tunnel



Note

M!DGE can be running up to 4 OpenVPN tunnels in the Client mode, but only one tunnel in the Server mode.

Client Mode

OpenVPN
Administration
Tunnel Configuration
IPsec
Administration
Tunnel Configuration
PPTP
Administration
Tunnel Configuration
GRE
Administration
Tunnel Configuration
Dial-in Server

HOME | INTERFACES | ROUTING | FIREWALL | **VPN** | SERVICES | SYSTEM | LOGOUT

Tunnel 1 | Tunnel 2 | Tunnel 3 | Tunnel 4

OpenVPN Tunnel 1 Configuration

Operation mode:	<input type="radio"/> disabled	<input checked="" type="radio"/> client	<input checked="" type="radio"/> standard	<input type="radio"/> expert
Peer selection:	single	Server:		Port: 1194
Interface type:	TUN	Protocol:	UDP	
Network mode:	<input checked="" type="radio"/> routed	MTU:		<input type="radio"/> bridged
Authentication:	certificate-based	HMAC digest:	SHA1	
Encryption:	BF-CBC			
Options:	<input checked="" type="checkbox"/> use compression	<input type="checkbox"/> use keepalive	<input type="checkbox"/> redirect gateway	<input type="checkbox"/> negotiate DNS

Apply

Peer selection	Specifies how the remote peer shall be selected, besides a single server you may configure multiple servers which can , in case of failures, either be selected sequentially (i.e. failover) or randomly (i.e. load balancing).
Server	The remote server address or hostname
Port	The remote server port (1194 by default)
Interface type	The VPN device type which can be either TUN (typically used for routed connections) or TAP (used for bridged networks)
Protocol	The OpenVPN tunnel protocol to be used.
Network mode	Defines how the packets should be forwarded, can be routed or bridged from or to a particular interface. You can also set the MTU for the tunnel.
Authentication	You can choose between credential-based (where you have to specify a username and password) and certificate-based options. Note that keys/certificates have to be created in the SYSTEM -> Keys & Certificates menu. You may also upload files which you have generated on your host system.
HMAC digest	HMAC is commonly used message authentication algorithm (MAC) that uses a data string, a secure algorithm, and a key, to produce a digital signature. OpenVPN's HMAC usage is to first encrypt a packet, then HMAC the resulting cipher text. If OpenVPN receives a packet with a bad HMAC, it drops this packet. HMAC usually adds 16 or 20 Bytes per packet.

Encryption	Required cipher mechanism used for encryption.
Use compression	Enable or disable OpenVPN compression.
Use keepalive	Can be used to send a periodic keep alive packet in order to keep the tunnel up despite inactivity.
Redirect gateway	By redirecting the gateway, all packets will be directed to the VPN tunnel. Please ensure that essential services (such as DNS or NTP servers) can be reached via the network behind the tunnel. If in doubt, create an extra static route pointing to the correct interface.
Negotiate DNS	If enabled, the system will use the nameservers which have been negotiated over the tunnel.
Allow duplicates	Allow multiple clients with the same common name to concurrently connect.
Verify certs	Check peer certificate against local CRL.

Server Mode

OpenVPN

Administration
Tunnel Configuration

IPsec

Administration
Tunnel Configuration

PPTP

Administration
Tunnel Configuration

GRE

Administration
Tunnel Configuration

Dial-in Server

HOME | INTERFACES | ROUTING | FIREWALL | **VPN** | SERVICES | SYSTEM | LOGOUT

Tunnel 1 | Tunnel 2 | Tunnel 3 | Tunnel 4

OpenVPN Tunnel 1 Configuration

Operation mode: disabled client server standard expert

Server port:

Type:

Protocol:

Network mode: routed bridged MTU:

Cipher:

Authentication:

HMAC digest:

Options: use compression use keepalive redirect gateway allow duplicates verify certs

Apply

A server tunnel typically requires the following files:

- server.conf (OpenVPN configuration file),
- ca.crt (root certificate file),
- server.crt (certificate file),
- server.key (private key file),

- dh1024.pem (Diffie Hellman parameters file),
- a directory (with default name “ccd”) containing client-specific configuration files.



Important

OpenVPN tunnels require a correct system time. Please ensure that all NTP servers are reachable. When using host names, a working DNS server is required as well.

Client Management

Once you have successfully set up an OpenVPN server tunnel, you can manage and enable clients connecting to your service. Currently connected clients can be seen on this page, including the connect time and IP address. You may kick connected clients by disabling them.

In the Networking section you can specify a fixed tunnel endpoint address for each client. Please note that, if you intend to use a fixed address for a particular client, you would have to apply fixed addresses to the other ones as well.

You may specify the network behind the clients as well as the routes to be pushed to each client. This can be useful for routing purposes, e.g. in case you want to redirect traffic for particular networks towards the server. Routing between the clients is generally not allowed but you can enable it if desired.

Finally, you can generate and download all expert mode files for enabled clients which can be used to easily populate each client.

Operating in server mode with certificates, it is possible to block a specific client by revoking a possibly stolen client certificate (see *Keys & Certificates*).



Note

The downloaded expert mode file needs to be unzipped and then individual client expert files can be uploaded to the respective routers.

HOME | INTERFACES | ROUTING | FIREWALL | **VPN** | SERVICES | SYSTEM | LOGOUT

Clients | **Networking**

Client Management

Client	Address	Networks		
Client1	dynamic			
Client2	dynamic	192.168.100.0/24		

Download

OpenVPN
Administration
Tunnel Configuration
Client Management

IPsec
Administration
Tunnel Configuration

PPTP
Administration
Tunnel Configuration



Note

See the *OpenVPN configuration*² example in our Application notes.

² <https://www.racom.eu/eng/products/m/midge/app/vpn/OpenVPN.html>

7.5.2. IPsec

IPsec is a protocol suite for securing IP communications by authenticating and encrypting each packet of a communication session and thus establishing a secure virtual private network.

IPsec includes various cryptographic protocols and ciphers for key exchange and data encryption and can be seen as one of the strongest VPN technologies in terms of security.

It uses the following mechanisms:

- AH Authentication Headers (AH) provide connectionless integrity and data origin authentication for IP datagrams and ensure protection against replay attacks.
- ESP Encapsulating Security Payloads (ESP) provide confidentiality, data-origin authentication, connectionless integrity, an anti-replay service and limited traffic-flow confidentiality.
- SA Security Associations (SA) provide a secure channel and a bundle of algorithms that provide the parameters necessary to operate the AH and/or ESP operations. The Internet Security Association Key Management Protocol (ISAKMP) provides a framework for authenticated key exchange.

Negotiating keys for encryption and authentication is generally done by the Internet Key Exchange protocol (IKE) which consists of two phases:

- IKE phase 1 IKE authenticates the peer during this phase for setting up an ISAKMP secure association. This can be carried out by either using main or aggressive mode. The main mode approach utilizes the Diffie-Hellman key exchange and authentication is always encrypted with the negotiated key. The aggressive mode just uses hashes of the pre-shared key and therefore represents a less secure mechanism which should generally be avoided as it is prone to dictionary attacks.
- IKE phase 2 IKE finally negotiates IPsec SA parameters and keys and sets up matching IPsec SAs in the peers which is required for AH/ESP later on.

Administration

HOME | INTERFACES | ROUTING | FIREWALL | **VPN** | SERVICES | SYSTEM | LOGOUT

OpenVPN
Administration
Tunnel Configuration
Client Management

IPsec
Administration
Tunnel Configuration

PPTP
Administration
Tunnel Configuration

IPsec Administration

IPsec administrative status: enabled
 disabled

Propose NAT traversal:

Restart on link change:

- IPsec administrative status Enable or disable IPsec
- Propose NAT Traversal NAT-Traversal is mainly used for connections which traverse a path where a router modifies the IP address/port of packets. It encapsulates packets in UDP and therefore requires a slight overhead which has to be taken into account when running over small-sized MTU interfaces.

Restart on link change If checked, the tunnel is restarted whenever any link changes the status.



Note

Running NAT-Traversal makes IKE using UDP port 4500 rather than 500 which has to be taken into account when setting up firewall rules.

Configuration

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

OpenVPN

- Administration
- Tunnel Configuration
- Client Management

IPsec

- Administration
- Tunnel Configuration

PPTP

- Administration
- Tunnel Configuration

GRE

- Administration
- Tunnel Configuration

Dial-in Server

IPsec Tunnel 1 Configuration

General

IKE Proposal

IPsec

Networks

Configuration mode: standard
 expert

Remote peer address:

Dead Peer Detection (DPD)

Administrative status:

Detection cycle: seconds

Failure threshold:

Action:

General

Remote peer address	The IPsec peer/responder/server IP address or host name
Administrative status	Enable or disable Dead Peer Detection. DPD will detect any broken IPsec connection, in particular the ISAKMP tunnel, and refresh the corresponding SAs (Security Associations) and SPIs (Security Payload Identifiers) for a faster tunnel re-establishment.
Detection cycle	Set the delay (in seconds) between Dead Peer Detection (RFC 3706) keepalives (R_U_THERE, R_U_THERE_ACK) that are sent for this connection (default 30 seconds)
Failure threshold	The number of unanswered DPD R_U_THERE requests until the IPsec peer is considered dead (the router will then try to re-establish a dead connection automatically)
Action	The action when a DPD enabled peer is declared dead. Hold (default) means the route is put into the hold status, while clear means the route and SA will both be cleared. Restart means that the SA will be immediately renegotiated.

IKE Proposal

HOME | INTERFACES | ROUTING | FIREWALL | **VPN** | SERVICES | SYSTEM | LOGOUT

OpenVPN

Administration
Tunnel Configuration
Client Management

IPsec

Administration
Tunnel Configuration

PPTP

Administration
Tunnel Configuration

GRE

Administration
Tunnel Configuration

Dial-in Server

IPsec Tunnel 1 Configuration

General | **IKE Proposal** | IPsec | Networks

IKE Authentication

Key exchange:	<input type="text" value="IKEv1"/>
Authentication type:	<input type="text" value="pre-shared key"/>
PSK:	<input type="text" value="••••••••"/>
Local ID type:	<input type="text" value="IP Address"/>
Local ID:	<input type="text" value="10.203.0.29"/>
Peer ID type:	<input type="text" value="IP Address"/>
Peer ID:	<input type="text" value="10.203.0.28"/>

IKE Proposal (Phase 1)

Negotiation mode:	<input type="text" value="main"/>
Encryption algorithm:	<input type="text" value="3des"/>
Authentication algorithm:	<input type="text" value="md5"/>
Diffie-Hellman group:	<input type="text" value="Group 2 (modp1024)"/>
Pseudo-random function:	<input type="text" value="md5"/>
SA life time:	<input type="text" value="86400"/> seconds

RACOM routers support IKEv1 or IKEv2 authentication via the pre-shared keys (PSK) or certificates within a public key infrastructure.

Using PSK requires the following settings:

PSK	The pre-shared key used
Local ID Type	The identification type for the local router which can be FQDN, username@FQDN or IP address
Local ID	The local ID value
Peer ID type	The identification type for the remote router
Peer ID	The peer ID value

Note

When using certificates you would need to specify the Operation mode. When run as the PKI client you can create a Certificate Signing Request (CSR) in the certificates section which needs to be submitted at your Certificate Authority and imported to the router afterwards. In

the PKI server mode the router represents the Certificate Authority and issues the certificates for remote peers.

Negotiation mode	Choose the negotiation mode (main, aggressive). The aggressive mode has to be used when dealing with dynamic endpoint addresses, but it is referred to be less secure compared to the main mode as it reveals your identity to an eavesdropper.
Encryption algorithm	The IKE encryption method (3DES, AES128, AES192, AES256)
Authentication algorithm	The IKE authentication method (MD5, SHA1, SHA2-256)
IKE Diffie-Hellman group	The IKE Diffie-Hellman group (2, 5 and 16-21)
SA life time	The Security Association lifetime
Perfect forward secrecy (PFS)	This feature heavily increases security as PFS avoids penetration of the key-exchange protocol and prevents compromising the keys negotiated earlier.

Using Public Key Infrastructure requires similar settings, but the Operation mode must be configured.

Operation mode

Mode can be set either to "server" or "client". As a "server" and once you have successfully set up an IPsec tunnel, you can manage and enable clients connecting to your service. It is possible to generate and download expert mode files for enabled clients which can be used to easily populate each client.

IPsec Proposal

HOME | INTERFACES | ROUTING | FIREWALL | **VPN** | SERVICES | SYSTEM | LOGOUT

IPsec Tunnel 1 Configuration

General | **IKE Proposal** | IPsec | Networks

IPsec Proposal (IKE Phase 2)

Encapsulation mode: Tunnel

IPsec protocol: ESP

Encryption algorithm: 3des

Authentication algorithm: md5

SA life time: 28800 seconds

Perfect forward secrecy (PFS):

Force encapsulation:

Apply Continue

Encapsulation mode	Only the tunnel encapsulation mode is enabled
IPsec protocol	Only the ESP IPsec protocol is enabled
Encryption algorithm	The IKE encryption method (3DES, AES128, AES192, AES256, blowfish128, 192 and 256)

- Authentication algorithm: The IKE authentication method (MD5, SHA1, SHA256, SHA384, SHA512)
- SA life time: The Security Association lifetime in seconds
- Perfect forward secrecy (PFS): Specifies whether Perfect Forward Secrecy (PFS) should be used. This feature increases security as PFS avoids penetration of the key-exchange protocol and prevents compromization of previous keys.
- Force encapsulation: Force UDP encapsulation for ESP packets even if no NAT situation is detected.

Networks

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

OpenVPN
Administration
Tunnel Configuration
Client Management

IPsec
Administration
Tunnel Configuration
Client Management

PPTP
Administration
Tunnel Configuration

IPsec Tunnel 1 Configuration

General | IKE Proposal | IPsec | **Networks**

Networks

Local network address	Local network mask	Peer network address	Peer network mask	NAT address	
<input type="text" value="192.168.1.0"/>	<input type="text" value="255.255.255.0"/>	<input type="text" value="192.168.10.0"/>	<input type="text" value="255.255.255.0"/>	<input type="text"/>	<input checked="" type="checkbox"/>
<input type="button" value="+"/>					

When creating Security Associations, IPsec keeps track of routed networks within the tunnel. Packets are only transmitted when a valid SA with the matching source and destination network is present. Therefore, you may need to specify the networks behind the endpoints by applying the following settings:

- Local network address: The address of your Local Area Network (LAN)
- Local network mask: The netmask of your LAN
- Peer network address: The address of the remote network behind the peer
- Peer network mask: The netmask of the remote network behind the peer
- NAT address: Optionally, you can apply NAT (masquerading) for packets coming from a different local network. The NAT address must reside in the network previously specified as the local network.



Note

Since the firmware 3.7.40.103, the maximum number of networks for individual IPsec tunnels has increased from 4 to 10.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

OpenVPN
Administration
Tunnel Configuration
Client Management

IPsec
Administration
Tunnel Configuration

IPsec Tunnel Configuration

Name	Type	Peer	IKE	IPsec	Local Network	Remote Network	
Tunnel 1	pki-server	10.203.0.28	3des-md5	3des-md5	192.168.1.0/24	192.168.10.0/24	<input checked="" type="checkbox"/> <input type="button" value="-"/>
<input type="button" value="+"/>							

Excl. Networks

OpenVPN
Administration
Tunnel Configuration
Client Management

IPsec
Administration
Tunnel Configuration

HOME | INTERFACES | ROUTING | FIREWALL | **VPN** | SERVICES | SYSTEM | LOGOUT

IPsec Tunnel1 Configuration

General | IKE Proposal | IPsec | Networks | **Excl. Networks**

Excluded Networks

Network	Netmask
<input type="text"/>	<input type="text"/>

If IPsec is used as default gateway (Remote Network 0.0.0.0/0), this option can be used to exclude some subnet/network. I.e. IPsec is not used for this particular subnet/network.



Note

See the *IPsec configuration example*³ in our Application notes.

7.5.3. PPTP

The Point-to-Point Tunneling Protocol (PPTP) is a method for implementing virtual private networks between two hosts. PPTP is easy to configure and widely deployed amongst Microsoft Dial-up networking servers. However, due to its weak encryption algorithms, it is nowadays considered insecure but it still provides a straightforward way for establishing tunnels. When setting up a PPTP tunnel, you would need to choose between server or client.

OpenVPN
Administration
Tunnel Configuration

IPsec
Administration
Tunnel Configuration

PPTP
Administration
Tunnel Configuration

GRE
Administration
Tunnel Configuration

Dial-in Server

HOME | INTERFACES | ROUTING | FIREWALL | **VPN** | SERVICES | SYSTEM | LOGOUT

Tunnel 1 | Tunnel 2 | Tunnel 3 | Tunnel 4

PPTP Tunnel 1 Configuration

Operation mode:

disabled
 client
 server

Server listen address:

ANY
 specify

Server address:

Client address range: to

Username:

Password:

Apply

Listen address Specifies on which IP address should be listened for incoming client connections

Server address The server address within the tunnel

Client address range Specifies a range of IP addresses assigned to each client

³ <https://www.racom.eu/eng/products/m/midge/app/vpn/IPsec.html>

Username/password The common username/password configuration

Once configured, individual clients can be configured with different credentials and IP addresses.

HOME | INTERFACES | ROUTING | FIREWALL | **VPN** | SERVICES | SYSTEM | LOGOUT

OpenVPN
Administration
Tunnel Configuration

IPsec
Administration
Tunnel Configuration

PPTP
Administration
Tunnel Configuration
Client Management

PPTP Clients

Username	Address		
racom	192.168.250.10		
security	192.168.250.11		

HOME | INTERFACES | ROUTING | FIREWALL | **VPN** | SERVICES | SYSTEM | LOGOUT

Tunnel 1 | Tunnel 2 | Tunnel 3 | Tunnel 4

PPTP Tunnel 1 Configuration

Operation mode: disabled client server

Server address:

Username:

Password:

A client tunnel requires the following parameters to be set:

Server address The address of the remote server

Username The username used for authentication

Password The password used for authentication

7.5.4. GRE

The Generic Routing Encapsulation (GRE) is a tunneling protocol that can encapsulate a wide variety of network layer protocols inside virtual point-to-point links over IP. GRE is defined in RFC 1701, 1702 and 2784. It does not provide encryption nor authorization but can be used on an address-basis on top of other VPN techniques (such as IPsec) for tunneling purposes.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

OpenVPN
Administration
Tunnel Configuration

IPsec
Administration
Tunnel Configuration

PPTP
Administration
Tunnel Configuration

GRE
Administration
Tunnel Configuration

Tunnel 1
Tunnel 2
Tunnel 3
Tunnel 4

GRE Tunnel 1 Configuration

Operation mode: enabled
 disabled

Peer address:

Interface type:

Local tunnel address:

Local tunnel netmask:

Remote network:

Remote netmask:

The following parameters are required for setting up a tunnel:

Peer address	The remote peer IP address
Interface type	The device type for this tunnel. If "tap" device is chosen, another parameter "Bridge interface" must be configured with one LAN port.
Local tunnel address	The local IP address of the tunnel
Local tunnel netmask	The local subnet mask of the tunnel
Remote network	The remote network address of the tunnel
Remote netmask	The remote subnet mask of the tunnel

In general, the local tunnel address/netmask should not conflict with any other interface addresses. The remote network/netmask will result in an additional route entry in order to control which packets should be encapsulated and transferred over the tunnel.

7.5.5. L2TP

The Layer 2 Tunnelling Protocol is a tunnelling protocol which does not support any encryption or confidentiality. It relies on an encryption protocol that it passes within the tunnel to provide privacy. L2TPv3 is supported. Tunnel can be bridged to the local interfaces.

OpenVPN

- Administration
- Tunnel Configuration
- Client Management

IPsec

- Administration
- Tunnel Configuration

PPTP

- Administration
- Tunnel Configuration

GRE

- Administration
- Tunnel Configuration

L2TP

- Administration
- Tunnel Configuration

- Tunnel 1
- Tunnel 2
- Tunnel 3
- Tunnel 4

L2TP Tunnel 1 Configuration

Operation mode: enabled
 disabled

Transport protocol: IP
 UDP

Local IP:

Remote IP:

Local Tunnel ID:

Remote Tunnel ID:

Local Session ID:

Remote Session ID:

Local Cookie:

Remote Cookie:

MTU:

Bridge interface:

Apply

The following parameters are required for setting up a tunnel:

- | | |
|--------------------|--|
| Transport protocol | The transport protocol which shall be used |
| Local IP | The local IP address of the tunnel |
| Remote IP | The remote IP address of the tunnel |
| Local port | The local port address of the tunnel |
| Remote port | The remote port address of the tunnel |
| Local tunnel ID | The local tunnel ID identifies the tunnel into which the session will be created |
| Remote tunnel ID | The remote tunnel ID identifies the tunnel assigned by the peer |
| Local session ID | The local session ID identifies the session being created |
| Remote session ID | The remote session ID identifies the session assigned by the peer |
| Local cookie | The local cookie sets an optional cookie value to be assigned to the session |
| Remote cookie | The remote cookie set an optional per cookie value to be assigned to the session |
| MTU | The Maximum Transmission Unit of the tunnel interface |

Bridge interface The interface to which the guest interface shall be bridged

7.5.6. Dial-in Server

The Dial-in Server is not supported by MIDGE hardware. Use the "Modem bridge" mode in the *Interfaces - Serial menu*.

Besides the admin account you can configure further users in the user accounts section, which shall be allowed to dial-in. Please note that Dial-In connections are generally discouraged. As they are implemented as GSM voice calls, they suffer from unreliability and poor bandwidth.

7.6. SERVICES

7.6.1. SDK

RACOM routers are shipping with a Software Development Kit (SDK) which offers a simple and fast way to implement customer-specific functions and applications. It consists of:

1. An SDK host which defines the runtime environment (a so-called sandbox), that is, controlling access to system resources (such as memory, storage and CPU) and, by doing so, catering for the right scalability.
2. An interpreter language called arena, a light-weight scripting language optimized for embedded systems, which uses a syntax similar to ANSI-C but adds support for exceptions, automatic memory management and runtime polymorphism on top of that.
3. A RACOM-specific Application Programming Interface (API), which ships with a comprehensive set of functions for accessing hardware interfaces (e.g. digital IO ports, GPS, external storage media, serial ports) but also for retrieving system status parameters, sending E-Mail or SMS messages or simply just to configure the router.

Anyone, reasonably experienced in the C language, will find an environment that is easy to dig in. However, feel free to contact us via <support@racom.eu> and we will happily support you in finding a programming solution to your specific problem.

The Language

The arena scripting language offers a broad range of POSIX functions (like printf or open) and provides, together with tailor-made API functions, a simple platform for implementing any sort of applications to interconnect your favourite device or service with the router.

Here comes a short example:

```
/* This script prints short status and if the SMS section is setted properly, the status ►
will be send even to your mobile phone :-)
*/

printf("-----");
printf("\n\n");
printf(nb_status_summary(all));
printf("\n\n");
printf("-----");

/* Please change the following number to your mobile phone number
*/
nb_sms_send("+420123456789", nb_status_summary(all));
```

A set of example scripts can be downloaded directly from the router, you can find a list of them in the appendix. The manual at *menu SERVICES-Administration-Troubleshooting-SDK API* gives a detailed introduction of the language, including a description of all available functions.

SDK API Functions

The current range of API functions can be used to implement the following features:

1. Send/Retrieve SMS
2. Send E-mail
3. Read/Write from/to serial device
4. Control digital input/output ports
5. Run TCP/UDP servers
6. Run IP/TCP/UDP clients
7. Access files of mounted media (e.g. an USB stick)
8. Retrieve status information from the system
9. Get or set configuration parameters
10. Write to syslog
11. Transfer files over HTTP/FTP
12. Perform config/software updates
13. Control the LEDs
14. Get system events, restart services or reboot system
15. Scan for networks in range
16. Create your own web pages
17. Voice control functions
18. SNMP functions
19. Various network-related functions
20. Other system-related functions

The SDK API manual at *menu SERVICES-Administration-Troubleshooting-SDK API* provides an overview but also explains all functions in detail.

Please note that some functions require the corresponding services (e.g. E-Mail, SMS) to be properly configured prior to utilizing them in the SDK.

Let's now pay some attention to the very powerful API function `nb_status`. It can be used to query the router's status values in the same manner as they can be shown with the CLI. It returns a structure of variables for a specific section (a list of available sections can be obtained by running `cli status -h`).

By using the `dump` function you can figure out the content of the returned structure:

```
/* Dump current WAN status */  
  
dump ( nb_status ("wan") );
```

The script will then generate lines like maybe these:

```
struct(35): {  
  .WANLINK1_GATEWAY = string[3]: "n/a"  
  .WANLINK2_REGISTRATION_STATE = string[23]: "registeredInHomeNetwork"  
  .WANLINK1_STATE = string[7]: "dialing"  
  .WANLINK2_STATE_UP_SINCE = string[19]: "2018-12-03 09:08:30"  
  .WANLINK1_DIAL_ATTEMPTS = string[3]: "320"  
  .WANLINK2_SIGNAL_STRENGTH = string[3]: "-69"  
  .WANLINK2_DATA_DOWNLOADED = string[6]: "747608"  
  .WANLINK2_DATA_UPLOADED = string[7]: "1225984"  
  .WANLINK1_DATA_UPLOADED = string[3]: "n/a"  
  .WANLINK2_ADDRESS = string[11]: "10.203.0.28"  
  .WANLINK2_NETWORK = string[7]: "O2 - CZ"  
  .WANLINK1_DIAL_SUCCESS = string[1]: "0"  
  .WANLINK2_PDP = string[4]: "PDP1"
```

```
.WANLINK1_ADDRESS = string[3]: "n/a"
.WANLINK1_DOWNLOAD_RATE = string[1]: "0"
.WANLINK2_SIM = string[4]: "SIM1"
.WANLINK2_DOWNLOAD_RATE = string[2]: "52"
.WANLINK1_UPLOAD_RATE = string[1]: "0"
.WANLINK2_SIGNAL_LEVEL = string[2]: "46"
.WANLINK2_SIGNAL_QUALITY = string[4]: "good"
.WANLINK2_UPLOAD_RATE = string[2]: "85"
.WANLINK2_DIAL_FAILURES = string[1]: "0"
.WANLINK1_TYPE = string[3]: "eth"
.WANLINK1_DIAL_FAILURES = string[3]: "319"
.WANLINK2_DIAL_ATTEMPTS = string[1]: "3"
.WANLINK2_MODEM = string[7]: "Mobile1"
.WANLINK1_INTERFACE = string[4]: "LAN4"
.WANLINK1_DATA_DOWNLOADED = string[3]: "n/a"
.WAN_HOTLINK = string[8]: "WANLINK2"
.WANLINK2_INTERFACE = string[5]: "WWAN1"
.WANLINK2_SERVICE_TYPE = string[3]: "LTE"
.WANLINK2_DIAL_SUCCESS = string[1]: "3"
.WANLINK2_TYPE = string[4]: "wwan"
.WANLINK1_STATE_DIALING_SINCE = string[19]: "2018-12-03 12:15:10"
.WANLINK2_STATE = string[2]: "up"
}
```

In combination with the `nb_config_set` function, it is possible to start a re-configuration of any parts of the system upon status changes. You may find all possible parameters by reading the `/etc/config/factory-config.cfg` file accessible via CLI.

```
~ $ cat /etc/config/factory-config.cfg | grep ntp
network.ntp.status =1
network.ntp.server0 =0.pool.ntp.org
network.ntp.server1 =1.pool.ntp.org
network.ntp.ping =1
network.ntp.interval =256
network.ntp.gpstime =0
network.ntp.stratum =15
network.ntp.access.0.address =192.168.1.0
network.ntp.access.0.netmask =255.255.255.0
network.ntp.access.1.address =
network.ntp.access.1.netmask =
network.ntp.access.2.address =
network.ntp.access.2.netmask =
```

Here is an example how one might adopt those functions:

```
/* Check the current NTP server and set it to the IP address 192.168.0.2
and enable the NTP synchronisation */

printf ("The NTP server was previously using IP address: ");
printf (nb_config_get("network.ntp.server0"));
printf("\n\n");
```

```

nb_config_set("network.ntp.server0=192.168.0.2");

if (nb_config_get ("network.ntp.status") == "0"){
    printf ("and was not running.");
    printf("\n\n");
    nb_config_set ("network.ntp.status=1");
}
else {
    printf ("and was running.");
    printf("\n\n");
}

printf ("The NTP server is now running with IP address: ");
printf (nb_config_get("network.ntp.server0"));

```

Running SDK

In the SDK, we are speaking of `scripts` and `triggers` which form `jobs`. Any arena script can be uploaded to the router or imported by using dedicated user configuration packages. You may also edit the script directly at the Web Manager or select one of our examples. You also have a testing section on the router which can be used to check your syntax or doing test runs.

Once uploaded, you will have to specify a trigger, that is, telling the router when the script is to be executed. This can be either time-based (e.g. each Monday) or triggered by one of the pre-defined system events (e.g. wan-up) as described in *Section 7.6.7, "Events"*. With both, a script and a trigger, you can finally set up an SDK job now. The test event usually serves as a good facility to check whether your job is working as expected. The admin section also offers facilities to troubleshoot any issues and control running jobs. The SDK host (`sdkhost`) corresponds to the daemon managing the scripts and their operations and thus avoiding any harm to the system. In terms of resources, it will limit CPU and memory for running scripts and also provide a pre-defined portion of the available flash storage. You may, however, extend it by external USB storage.

Files written to `/tmp` will be hold in the memory and will be cleared upon a script restart.. As your scripts operate in the sandbox, you will have no access to the system tools (such as `ifconfig`).

Administration

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

SDK

- Administration
- Job Management
- Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

Administration
Status
Troubleshooting

SDK Administration

This kit provides a sandbox environment for running system jobs by means of self-scripted applications.

Administrative status: enabled disabled

Scheduling priority:

Maximum flash usage: (3..16 MB)

Enable watchdog:

SDK
Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Administration
Status
Troubleshooting

SDK Status
SDK environment is active

Finished Jobs

Job	Started	Ended	Exit Code
SMS-CONTROL	2014-06-09 13:07:08	2014-06-09 13:07:08	0

Running Jobs
There is no job currently running.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Administration
Status
Troubleshooting

SDK Troubleshooting

Select job:

job 0 started at 2014-06-09 13:07:08 (running 'sms-control.are')

job 0 ended at 2014-06-09 13:07:08 (with exit code 0)

Output:

```
=== job 0 ended at 2014-06-09 13:07:08 (with exit code 0)
```

This page can be used to control the SDK host and apply the following settings:

- | | |
|-----------------------|--|
| Administrative status | Specifies whether SDK scripts should run or not |
| Scheduling priority | Specifies the process priority of the sdkhost, higher priorities will speed up scheduling your scripts, lower ones will have less impact to the host system |
| Maximum flash usage | The maximum amount of Mbytes your scripts can write to the internal flash |
| Enable watchdog | This option enables watchdog supervision for each script. If the script does not respond or is stopped with an exit code not equal null, the system is rebooted. |

The status page informs you about the current SDK status. It provides an overview about any finished jobs, you can also stop a running job there and view the script output in the troubleshooting section where you will also find links for downloading the manuals and examples.

Job Management

SDK

Administration
Job Management
Testing

DHCP Server

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Jobs	Scripts	Triggers	
Name	Trigger	Script	Arguments
SMS-CONTROL	SMS-RECEIVED	sms-control.are	<input checked="" type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>

This page can be used to set up scripts, triggers and jobs.

SDK

Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Jobs	Scripts	Triggers
Edit Trigger		
Name:	<input type="text" value="SMS-RECEIVED"/>	
Type:	<input type="radio"/> time-based <input checked="" type="radio"/> event-based	
Event:	<input type="text" value="sms-received"/>	
<input type="button" value="Apply"/>		

It is usually a good idea to create a trigger first which is made up by the following parameters:

- Name** A meaningful name to identify the trigger
- Type** The type of the trigger, either time-based or event-based
- Condition** Specifies the time condition for time-based triggers (e.g. hourly)
- Timespec** The time specification which, together with the condition, specifies the `time(s)` when the trigger should be pulled
- Event** The system event upon which the trigger should be pulled

SDK

Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

SNMP Agent

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Jobs	Scripts	Triggers
Edit Script		
Name:	<input type="text" value="sms-control.are"/>	
Description:	<input type="text" value="SMS control daemon"/> (optional)	
Arguments:	<input type="text"/> (optional)	
Action:	<input type="radio"/> edit <input type="radio"/> upload <input checked="" type="radio"/> select	
	<input type="text" value="sms-control.are (uploaded)"/>	
<input type="button" value="Apply"/>		

You can now add your personal script to the system by applying the following parameters:

Name	A meaningful name to identify the script
Description	An optional script description
Arguments	An optional set of arguments passed to the script (supports quoting)
Action	You may either edit a script, upload it to the system or select one of the example scripts or an already uploaded script

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

SDK
Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Jobs Scripts Triggers

Edit Job

Name:

Trigger:

Script:

Arguments:

(precede script arguments if specified)

You are ready to set up a job afterwards, it can be created by using the following parameters:

Name	A meaningful name to identify the job
Trigger	Specifies the trigger that should launch the job
Script	Specifies the script to be executed
Arguments	Defines arguments which can be passed to the script (supports quoting), they will precede the arguments you formerly may have assigned to the script itself

Testing

```
/* Check the current NTP server and set it to the IP address 192.168.0.2
and enable the NTP synchronisation */

printf ("The NTP server was previously using IP address: ");
printf (nb_config_get("network.ntp.server0"));
printf("\n\n");

nb_config_set("network.ntp.server0=192.168.0.2");

if (nb_config_get ("network.ntp.status") == "0"){
    printf ("and was not running.");
    printf("\n\n");
    nb_config_set ("network.ntp.status=1");
}
else {
    printf ("and was running.");
    printf("\n\n");
}
}
```

```
printf ("The NTP server is now running with IP address: ");
printf (nb_config_get("network.ntp.server0"));
```

The testing page offers an editor and an input field for optional arguments which can be used to perform test runs of your script or test dedicated portions of it. Please note that you might need to quote arguments as they will otherwise be separated by white-spaces.

```
/* arguments : schnick schnack "s c h n u c k" */

for (i = 0; i < argc ; i++) {
    printf (" argv %d: %s\n", i, argv [i]);
}

/* generates:
* argv 0: /scripts/testrun
* argv 1: schnick
* argv 2: schnack
* argv 3: s c h n u c k
*/
```

In case of syntax errors, arena will usually print error messages as follows (indicating the line and position where the parsing error occurred):

```
/scripts/testrun:2:10:FATAL: parse error, unexpected $, expecting ';''
```



Note

It is now possible to upload SDK scripts into the Testing menu via browsing the required SDK script and clicking on the "Run" button.

SDK Sample Application

As an introduction, you can step through a sample application, namely the SMS control script, which implements remote control over short messages and can be used to send a system status back to the sender. The source code is listed in the appendix.

Once enabled, you can send a message to the phone number associated with a SIM / modem. It generally requires a password to be given on the first line and a command on the second, such as:

```
admin01
status
```

We strongly recommend to use authentication in order to avoid any unintended access, however you may pass noauth as argument to disable it. You can then skip the first line containing the password. Having a closer look to the script, you will see that you will also be able to restrict the list of permitted senders. Please inspect the system log for troubleshooting any issues.

The following commands are supported:

status An SMS with the following information will be returned

- Signal strength

	<ul style="list-style-type: none">• Mobile connection state (up/down)• current IP address of the mobile interface• current IP address of the VPN interface (if enabled)
connect	This will initiate a Dial-out connection over configured WAN (LAN or cellular) and the VPN connection (if enabled) and trigger sending an SMS with the following information: <ul style="list-style-type: none">• current IP address of the PPP interface• current IP address of the VPN interface (if enabled)
disconnect	terminates all WAN connections (including VPN)
reboot	Initiates a system reboot
output 1 on	Switch digital output 1 on
output 1 off	Switch digital output 1 off
output 2 on	Switch digital output 2 on
output 2 off	Switch digital output 2 off

A response to the status command typically looks like:

```
System: MIDGE midge (0002A9FFC32E)
WAN1: WWAN1 is up (10.204.8.3, Mobile1,
HSPA, -65 dBm, LAI 23003)
DIO: IN1=off, IN2=off, OUT1=off, OUT2=on
```

7.6.2. DHCP Server

This section can be used to individually configure a DHCP service for each LAN interface.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

SDK
Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

SNMP Agent

Web Server

Discovery

Redundancy

Modbus TCP

DHCP Server LAN1

Operation mode: server
 relay
 disabled

First lease address:

Last lease address:

Lease duration: seconds

Persistent leases:

DHCP options: use default specify

Only allow static hosts:

Static Hosts

IP Address	Identified by
+	

Apply

Operational mode	The DHCP operational mode can be disabled or set to the "server" or "relay" mode. As a server, the unit answers to DHCP requests from hosts in the LAN directly. As a relay, the unit resends the requests to the configured DHCP server which handles them.
First lease address	First address for DHCP clients
Last lease address	Last address for DHCP clients
Lease duration	Number of seconds (30-86400) how long a given lease will be valid until it has to be requested again
Persistent leases	By checking this option, only static hosts will obtain the IP leases
DHCP options	By default DHCP will hand out the interface address as the default gateway and DNS server address if not configured elsewhere. It is possible to specify different addresses here.
Static Hosts	The option to add a static host configured with the IP address, MAC address and/or hostname.

7.6.3. DNS Server

The DNS server can be used to proxy DNS requests towards servers on the net which have for instance been negotiated during WAN link negotiation. By pointing DNS requests to the router, one can reduce outbound DNS traffic as it is caching already resolved names but it can be also used for serving fixed addresses for particular host names.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

SDK

- Administration
- Job Management
- Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

SNMP Agent

Web Server

Redundancy

Modbus TCP

DNS Server Administration

Administrative status: enabled
 disabled

DNS Server Configuration

Domain name:

Primary name server:

Secondary name server:

Current name servers: 80.74.32.240
80.74.32.241

Static Hosts

Hostname	Address
+	

Administrative status	Enabled or disabled
Domain name	The domain name used for short name lookups.
Primary name server	The primary default name server which will be used instead of negotiated name servers.
Secondary name server	The secondary default name server which will be used instead of negotiated name servers.

You may further configure static hosts for serving fixed IP addresses for various hostnames. Please remember to point local hosts to the router's address for resolving them.

7.6.4. NTP Server

This section can be used to individually configure the Network Time Protocol (NTP) server function.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | **SERVICES** | [SYSTEM](#) | [LOGOUT](#)

SDK
Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

NTP Server Administration

Administrative status: enabled
 disabled

NTP Server Configuration

Poll interval: seconds

Allowed hosts: Address:
Netmask:

Apply

Administrative status	Enabled or disabled
Poll interval	Defines the polling interval (64-4096 seconds) for synchronizing the time with the master clock servers
Allowed hosts	Defines the IP address range which is allowed to poll the NTP server



Note

See the description of how to set the correct router time in *the section called "Time & Region"*.

7.6.5. Dynamic DNS

Dynamic DNS client on this box is generally compatible with various DynDNS services on the Internet running by means of definitions by the DynDNS organization (see www.dyndns.com for server implementations).

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | **SERVICES** | [SYSTEM](#) | [LOGOUT](#)

SDK
Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

DynDNS Administration

Administrative status: enabled
 disabled

DynDNS Update Services

Provider	URL / Host	Status
+		

Apply

Administrative status:	Enabled or disabled
------------------------	---------------------

SDK

- Administration
- Job Management
- Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

SNMP Agent

Add DynDNS Service

Provider:

Dynamic address: derive from hotlink interface
 use outgoing interface address
 query CheckIP service at dyndns.org

Hostname:

Username:

Password:

Protocol:

- Dynamic address Specifies whether the address is derived from the hotlink, outgoing interface address or via an external service. Usually, the hotlink option is used.
- Hostname The host-name provided by your DynDNS service (e.g. mybox.dyndns.org)
- Username The user-name used for authenticating at the service
- Password The password used for authentication
- Protocol The protocol used for authentication (HTTP, HTTPS).
- Server address The address of the server which shall be updated.
- Server port The port of the server which shall be updated.
- TSIG key name The name of the TSIG key which is allowed to perform updates.
- TSIG key The TSIG key encoded in base64.

Please note that your RACOM router can operate as DynDNS service as well, provided that you hold a valid SERVER license and have your hosts pointed to the DNS service of the router.

7.6.6. E-mail client

The E-Mail client can be used to send notifications to a particular E-Mail address upon certain events or by SDK scripts.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Configuration

E-mail Client Configuration

Administrative status: enabled
 disabled

From address:

Server address:

Server port:

Authentication:

Encryption:

Username:

Password:

Administrative status	E-mail client administrative status - enabled or disabled
From address	Sender e-mail address
Server address	SMTP server address
Server port	SMTP server port (typically 25)
Authentication	Choose the required authentication method to authenticate against the SMTP server
Encryption	The optional encryption for the e-mail messaging (none or TLS)
Username	User name for authentication
Password	Password for authentication

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Configuration Testing

Send E-Mail

Recipient:

Subject:

Message:

Send

After configuring E-mail successfully, you can also test e-mail messages.

7.6.7. Events

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Event Notification

Event(s)	Description	Send	Destination	
dio-in1-on	Power supply failure	SNMPv1 trap	192.168.10.200:162	
dio-in1-off	Power supply OK	SNMPv1 trap	192.168.10.200:162	

Fire test event

By using the event manager you can notify remote systems about system events. A notification can be sent using E-Mail, SMS or SNMP traps.

Events

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | **SERVICES** | [SYSTEM](#) | [LOGOUT](#)

SDK

Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

SNMP Agent

Web Server

Add Event Notification

Description:

Send:

E-Mail address:

Phone number:

Category	Event	Description
CALL	<input type="checkbox"/> call-incoming	A voice call is coming in
	<input type="checkbox"/> call-outgoing	Outgoing voice call is being established
DDNS	<input type="checkbox"/> ddns-update-failed	Dynamic DNS update failed
	<input type="checkbox"/> ddns-update-succeeded	Dynamic DNS update succeeded
DIALIN	<input type="checkbox"/> dialin-down	Dial-In connection went down
	<input type="checkbox"/> dialin-up	Dial-In connection came up

E-Mail address The E-Mail address to which the notification shall be sent (E-Mail client must be enabled)

Phone number The phone number to which the notification shall be sent (SMS service must be enabled)

SNMP host The SNMP host or address to which the trap shall be sent

SNMP port The port of the remote SNMP service

Username The username for accessing the remote SNMP service

Password The password for accessing the remote SNMP service

Authentication The authentication algorithm for accessing the remote SNMP service (MD5 or SHA)

Encryption The encryption algorithm for accessing the remote SNMP service (DES or SHA)

Engine ID The engine ID of the remote SNMP service

The messages will contain a description provided by you and a short system information.

The default texts for a specific Event are as follows:

Category	Event (ID)	Description
CALL	call-incoming (701)	A GSM call is coming in
	call-outgoing (702)	Outgoing voice call is being established
DDNS	ddns-update-failed (802)	Dynamic DNS update failed
	ddns-update-succeeded (801)	Dynamic DNS update succeeded
DIALIN	dialin-down (409)	Dial-In connection went down
	dialin-up (408)	Dial-In connection came up

Category	Event (ID)	Description
DIO	dio-in1-off (202)	DIO IN1 turned off
	dio-in1-on (201)	DIO IN1 turned on
	dio-in2-off (204)	DIO IN2 turned off
	dio-in2-on (203)	DIO IN2 turned on
	dio-out1-off (206)	DIO OUT1 turned off
	dio-out1-on (205)	DIO OUT1 turned on
	dio-out2-off (208)	DIO OUT2 turned off
	dio-out2-on (207)	DIO OUT2 turned on
GPS	gps-down (302)	GPS signal is not available
	gps-up (301)	GPS signal is available
GRE	gre-down (413)	GRE connection went down
	gre-up (412)	GRE connection came up
IPSEC	ipsec-down (404)	IPsec connection went down
	ipsec-up (403)	IPsec connection came up
MOBILEIP	mobileip-down (411)	Mobile IP connection went down
	mobileip-up (410)	Mobile IP connection came up
OPENVPN	openvpn-down (402)	OpenVPN connection went down
	openvpn-up (401)	OpenVPN connection came up
PPTP	pptp-down (407)	PPTP connection went down
	pptp-up (406)	PPTP connection came up
REDUNDANCY	redundancy-backup (1002)	System is now backup router
	redundancy-master (1001)	System is now master router
SDK	sdk-startup (507)	SDK has been started
SMS	sms-notsent (602)	SMS has not been sent
	sms-received (603)	SMS has been received
	sms-report-received (604)	SMS report has been received
	sms-sent (601)	SMS has been sent
SYSTEM	system-error (510)	System is in error state
	system-login-failed (501)	User login failed
	system-login-succeeded (502)	User login succeeded
	system-logout (503)	User logged out
	system-no-error (511)	System left error state
	system-poweroff (509)	System poweroff has been triggered
	system-rebooting (504)	System reboot has been triggered
	system-startup (505)	System has been started
system-time-updated (508)	System time has been updated	
TEST	test (506)	test event
USB	usb-eth-added (903)	USB Ethernet device has been added
	usb-eth-removed (904)	USB Ethernet device has been removed

Category	Event (ID)	Description
	usb-serial-added (905)	USB serial device has been added
	usb-serial-removed (906)	USB serial device has been removed
	usb-storage-added (901)	USB storage device has been added
	usb-storage-removed (902)	USB storage device has been removed
WAN	wan-down (101)	WAN link went down
	wan-up (102)	WAN link came up

7.6.8. SMS

This page lets you turn on the SMS event notification service and enable remote control via SMS.

Administration

On RACOM routers it is possible to receive or send short messages (SMS) over each mounted modem (depending on the assembly options). Messages are received by querying the SIM card over a modem, so prior to that, the required assignment of a SIM card to a modem needs to be specified on the SIMs page.

Please bear in mind, in case you are running multiple WWAN interfaces sharing the same SIM, that the system may switch SIMs during operation which will also result in different settings for SMS communication.

Sending messages heavily depends on the registration state of the modem and whether the provided SMS Center service works and may fail. You may use the sms-report-received event to figure out whether a message has been successfully sent.

Received messages are pulled from the SIMs and temporarily stored on the router but get cleared after a system reboot. Please consider to consult an SDK script in case you want to process or copy them.

Sending messages heavily depends on the registration state of the modem and whether the provided SMS Center service works and may fail. You may use the sms-report-received event to figure out whether a message has been successfully sent.

Please do not forget that modems might register roaming to foreign networks where other fees may apply. You can manually assign a fixed network (by LAI) in the SIMs section.

We identify SIMs based on their IMEI number and track their statistics in a non-volatile manner.

The relevant page can be used to enable the SMS service and specify on which modem should operate.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Administration | Routing | Status | Testing

SMS Administration

Administrative status: enabled
 disabled

Request delivery report: enabled
 disabled

Activated SIMs

SIM	Gateway	Modem	State	Registered	
SIM1	+420602909909	Mobile1	ready	yes	

Apply

Administrative status

Enable or disable SMS notifications and control

Request delivery report

Enable or disable receiving the confirmation whether SMS was successfully received or not. This can be then read in the SMS Status menu.

Routing & Filtering

By using SMS routing you can specify outbound rules which will be applied whenever messages are sent. You can forward them to an enabled modem. For a particular number, you can for instance enforce messages be sent over a dedicated SIM.

HOME | INTERFACES | **ROUTING** | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

Administration | Routing | Status | Testing

SMS Routing

The following list will be processed by order, forwarding outgoing messages over the specified SIM or dropping them. Messages which are not matching any of the rules below will be dispatched to the first available SIM.

Number	Mode	
+123456789	FORWARD over SIM1	
*	DROP	

SMS Filtering

The rules below can be used to drop any incoming messages before entering the system. All others will be allowed.

Number	Receiving SIM	Mode	
+123456789	SIM1	DROP	
*	SIM1	DROP	

Phone numbers can also be specified by regular expressions, here are some examples:

- +12345678 Specifies a fixed number
- +1* Specifies any numbers starting with +1
- +1*9 Specifies any numbers starting with +1 and ending with 9
- + [12]* Specifies any numbers starting with either +1 or 2

Please note that numbers have to be entered in international format including a valid prefix. On the other hand, you can also define rules to drop outgoing messages, for instance, when you want to avoid using any expensive service or international numbers.

Both types of rules form a list will be processed in order, forwarding outgoing messages over the specified modem or dropping them. Messages which are not matching any of the rules below will be dispatched to the first available modem.

Filtering serves a concept of firewalling incoming messages, thus either dropping or allowing them on a per-modem basis. The created rules are processed in order and in case of matches will either drop or forward the incoming message before entering the system. All non-matching messages will be allowed.

Status

The status page can be used to the current modem status and get information about any sent or received messages. There is a small SMS inbox reader which can be used to view or delete the messages. Please note that the inbox will be cleared each midnight in case it exceeds 512 kbytes of flash usage.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | **[SERVICES](#)** | [SYSTEM](#) | [LOGOUT](#)

SDK

- Administration
- Job Management
- Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

Administration
Routing
Status
Testing

SMS Status

Modem	Status	Used Memory	Sent / Received
Mobile1	idle	0 of 10	2 / 1

Testing

This page can be used to test whether SMS sending in general or filtering/routing rules works. The maximum length per message part is limited to 160 characters, we also suggest to exclusively use characters which are supported by the GSM 7-bit alphabet.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | **[SERVICES](#)** | [SYSTEM](#) | [LOGOUT](#)

SDK

- Administration
- Job Management
- Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

SNMP Agent

Web Server

Administration
Routing
Status
Testing

Send SMS

Phone number:

Message:

text

7.6.9. SSH/Telnet Server

Apart from the Web Manager, the SSH and Telnet services can be used to log into the system. Valid users include root and admin as well as additional users as they can be created in the User Accounts section. Please note, that a regular system shell will only be provided for the root user, the CLI will be launched for any other user whereas normal users will only be able to view status values, the admin user will obtain privileges to modify the system.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

SDK

- Administration
- Job Management
- Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

Telnet Server Configuration

Administrative status: enabled
 disabled

Server port:

SSH Server Configuration

Administrative status: enabled
 disabled

Server port:

Disable admin login:

Disable password-based login: [upload authorized keys](#)

Please note that these services will be accessible from the WAN interface also. In doubt, please consider to disable or restrict access to them by applying applicable firewall rules.

The following parameters can be applied to the Telnet service:

Administrative status	Whether the Telnet service is enabled or disabled
Server port	The TCP port of the service (usually 23)

The following parameters can be applied to the SSH service:

Administrative status	Whether the SSH service is enabled or disabled
Server port	The TCP port of the service (usually 22)
Disable admin login	If checked, access via SSH for admin and root users will be blocked. Other users may have access as usual, but with restricted privileges.
Disable password-based login	By turning on this option, all users will have to authenticate by SSH keys which can be uploaded to the router.



Note

You can manually upload the authorized keys.

7.6.10. SNMP Agent

M!DGE is equipped with an SNMP daemon, supporting basic MIB tables (such as ifTable), plus additional enterprise MIBs to manage multiple systems. M!DGE OID starts with 1.3.6.1.4.1.33555.10 prefix. The corresponding VENDOR MIB can be downloaded from the router.

Parameter	Supported MIBs
.1.3.6.1.2.1	MIB-II (RFC1213), SNMPv2-MIB (RFC3418)
.1.3.6.1.2.1.2.1	IF-MIB (RFC2863)
.1.3.6.1.2.1.4	IP-MIB (RFC1213)
.1.3.6.1.2.1.10.131	TUNNEL-MIB (RFC4087)
.1.3.6.1.2.25	HOST-RESOURCES-MIB (RFC2790)
.1.3.6.1.6.3.10	SNMP-FRAMEWORK-MIB
.1.3.6.1.6.3.11	SNMPv2-SMI (RFC2578)
.1.0.8802.1.1.2	LLDP-MIB
.1.0.8802.1.1.2.1.5.4795	LLDP-EXT-MED-MIB
.1.3.6.1.4.1.33555	VENDOR-MIB

The VENDOR-MIB tables offer some additional information over the system and its WWAN, GNSS and WLAN interfaces. They can be accessed over the following OIDs:

Parameter	RACOM MIB OID Assignment
admin	.1.3.6.1.4.1.33555.10.40
mgWwanTable	.1.3.6.1.4.1.33555.10.50
mgGnssTable	.1.3.6.1.4.1.33555.10.51
dio	.1.3.6.1.4.1.33555.10.53
mgSerialTable	.1.3.6.1.4.1.33555.10.54
mgWlanTable	.1.3.6.1.4.1.33555.10.60
mgWlanStationTable	.1.3.6.1.4.1.33555.10.61
mgHotLink	.1.3.6.1.4.1.33555.10.70
mgWanTable	.1.3.6.1.4.1.33555.10.71
sdk	.1.3.6.1.4.1.33555.10.90
traps	.1.3.6.1.4.1.33555.10.100



Note

GNSS and WLAN on M!DGE are available with special extension only.

M!DGE extensions contain support for:

- Rebooting the device
- Updating to a new system software via FTP/TFTP/HTTP
- Updating to a new system configuration via FTP/TFTP/HTTP
- Getting WWAN/GNSS/WLAN/DIO information

**Note**

Attention must be paid to the fact that SNMP passwords have to be more than 8 characters long. Shorter passwords will be doubled for SNMP, e.g. 'admin01' becomes 'admin01admin01'.

SNMP extensions can be read and triggered as follows:

- To get system software version:
`snmpget -v 3 -u admin -n "" -l authNoPriv -a MD5 -x DES -A admin01admin01 192.168.1.1 1.3.6.1.4.1.33555.10.40.1.0`
- To get a kernel version:
`snmpget -v 3 -u admin -n "" -l authNoPriv -a MD5 -x DES -A admin01admin01 192.168.1.1 1.3.6.1.4.1.33555.10.40.2.0`
- To get a serial number:
`snmpget -v 3 -u admin -n "" -l authNoPriv -a MD5 -x DES -A admin01admin01 192.168.1.1 1.3.6.1.4.1.33555.10.40.3.0`
- To restart the device:
`snmpset -v 3 -u admin -n "" -l authNoPriv -a MD5 -x DES -A admin01admin01 192.168.1.1 1.3.6.1.4.1.33555.10.40.10.0 i 1`
- To run a configuration update:
`snmpset -v 3 -u admin -n "" -l authNoPriv -a MD5 -x DES -A admin01admin01 192.168.1.1 1.3.6.1.4.1.33555.10.40.11.0 s "http://server/directory"`

**Note**

config Update expects a zip-file named <serial-number>.zip in the specified directory which contains at least a "user-config.zip".

Supported protocols are TFTP, HTTP(s) and FTP.

Specifying a username/password or port is not yet supported.

- get configuration update status:
`snmpget -v 3 -u admin -n "" -l authNoPriv -a MD5 -x DES -A admin01admin01 192.168.1.1 1.3.6.1.4.1.33555.10.40.12.0`
The return value can be one of: (1) succeeded, (2) failed, (3) inprogress, (4) notstarted.
- run software update:
`snmpset -v 3 -u admin -n "" -l authNoPriv -a MD5 -x DES -A admin01admin01 192.168.1.1 1.3.6.1.4.1.33555.10.40.13.0 s "http://server/directory"`
- get software update status:
`snmpget -v 3 -u admin -n "" -l authNoPriv -a MD5 -x DES -A admin01admin01 192.168.1.1 1.3.6.1.4.1.33555.10.40.14.0`
Return value can be either of: (1) succeeded, (2) failed, (3) inprogress, (4) notstarted.

SNMP Configuration

SDK
Administration
Job Management
Testing
DHCP Server
DNS Server
NTP Server
Dynamic DNS
E-mail
Events
SMS
SSH/Telnet Server
SNMP Agent

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Configuration	Authentication
SNMP Agent Configuration	
Administrative status:	<input checked="" type="radio"/> enabled <input type="radio"/> disabled
Operation mode:	<input checked="" type="radio"/> v1 v2c v3 <input type="radio"/> v3 only
Contact:	<input type="text"/>
Location:	<input type="text"/>
Listening port:	<input type="text" value="161"/>
Download MIB	
<input type="button" value="Apply"/>	

Administrative status	Enable or disable the SNMP agent
Operation mode	Specifies if agent should run in compatibility mode or for SNMPv3 only
Contact	System maintainer or other contact information
Location	Device location
Listening port	SNMP agent port

Once the SNMP agent is enabled, SNMP traps can be generated using SDK scripts or can be triggered by various Events (see the SYSTEM → Events menu).

SNMP Authentication

SDK
Administration
Job Management
Testing
DHCP Server
DNS Server
NTP Server
Dynamic DNS
E-mail
Events
SMS
SSH/Telnet Server
SNMP Agent
Web Server
Redundancy

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Configuration	Authentication
SNMP v3 Authentication	
Authentication:	<input type="text" value="MD5"/>
Encryption:	<input type="text" value="DES"/>
Manage users	
SNMP v1/v2c Authentication	
Read community:	<input type="text" value="public"/>
Admin access:	<input checked="" type="radio"/> enabled <input type="radio"/> disabled
Admin community:	<input type="text"/>
Allowed host:	<input type="text"/>
<input type="button" value="Apply"/>	

When running in SNMPv3, it is possible to configure the following two authentication options:

Authentication	Defines the authentication (MD5 or SHA)
Encryption	Defines the privacy protocols to use (DES or AES)

Both the Authentication and Encryption passwords are the same and equal to the user's password. In general, the admin user can read and write any values. Read access will be granted to any other system users.

There is no authentication/encryption in SNMPv1/v2c and should not be used to set any values. However, it is possible to define its communities and authoritative host which will be granted administrative access.

Read community	Defines the community name for read access
Admin community	Defines the community name for admin access
Allowed host	Defines the host which is allowed for admin access



Note

The SNMP daemon is also listening on WAN interfaces and it is therefore suggested to restrict the access via the firewall.

7.6.11. Web Server

This page can be used to configure different ports for accessing the Web Manager via HTTP/HTTPS. We strongly recommend to use HTTPS when accessing the web service via a WAN interface as the communication will be encrypted and thus avoids any misuse of the system.

In order to enable HTTPS you would need to generate or upload a server certificate in the section SYSTEM-Keys and Certificates.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Web Server Configuration

HTTP

Administrative status: enabled
 disabled

HTTP port:

HTTPS

Administrative status: enabled
 disabled

HTTPS port:

HTTPS certificate: installed

HTTPS security: modern (Firefox 27, Chrome 30, IE 11 on Windows 7, ...)
 old (Firefox 1, Chrome 1, IE 7, ...)
 none (Windows XP IE6, Java 6)

Enable CLI-PHP:

Administrative status	Enable or disable the Web server
HTTP port	Web server port for HTTP connections
HTTPS port	Web server port for HTTPS connections
HTTPS certificate	Either information that the certificate is 'installed' or a link to create such certificate.
HTTPS security	Choose the HTTPS security level - follow the help within the menu itself.
Enable CLI-PHP	Enable CLI-PHP service (see <i>Section 8.16, "CLI-PHP"</i>)

7.6.12. Softflow

This page can be used to configure the network traffic analyser daemon Softflow used for exporting NetFlow traffic data.

HOME
INTERFACES
ROUTING
FIREWALL
VPN
SERVICES
SYSTEM
LOGOUT

- SDK
 - Administration
 - Job Management
 - Testing
- DHCP Server
- DNS Server
- NTP Server
- Dynamic DNS
- E-mail
- Events
- SMS
- SSH/Telnet Server
- SNMP Agent
- Web Server
- Softflow**
- Discovery

Add Softflow setup

Interface:

Host address:

Port:

Protocol Version:

Maximum Flows:

Track Level:

Sample Rate:

Parameters	Softflow Settings
Interface	Interface on which to listen for traffic
Host address	Destination address of the traffic data
Port	Port of the destination address
Protocol version	Protocol version of the data
Maximum flows	The maximum number of flows to concurrently track
Track level	Flow elements that should be used to define a flow
Sample rate	Periodical sampling rate

7.6.13. Discovery

SDK
Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

SNMP Agent

Web Server

Discovery

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Discovery

Administrative status: enabled
 disabled

Enabled protocols:

- LLDP
- CDP
- SONMP
- EDP
- FDP
- IRDP

Apply

Discovery protocols can be used to discover and to get discovered by other hosts.

Administrative status Enable or disable the Discovery

The following protocols are supported:

LLDP	Link Layer Discovery Protocol
CDP	Cisco Discovery Protocol
FDP	Foundry Discovery Protocol
SONMP	Nortel Discovery Protocol
EDP	Extreme Discovery Protocol
IRDP	ICMP Router Discovery Protocol

IRDP implements RFC1256 and can also inform locally connected hosts about the nexthop gateway. Any discovered hosts will be exposed to the LLDP-MIB and can be queried over SNMP or CLI/GUI.

7.6.14. Redundancy

This section can be used to set up a redundant pair of M!DGE (or other systems) by running the Virtual Router Redundancy Protocol (VRRP) among them. A typical VRRP scenario defines the first host playing the master and another the backup device, they both define a virtual gateway IP address which will be distributed by gratuitous ARP messages for updating the ARP cache of all LAN hosts and thus redirecting the packets accordingly.

A takeover will happen within approximately 3 seconds as soon as the partner is no longer reachable (checked via multicast packets). This may happen when one device is rebooting or the Ethernet link went down. Same applies when the WAN link goes down.

In case DHCP has been activated, please keep in mind that you will need to reconfigure the DHCP gateway address offered by the server and let them point to the virtual gateway address. In order to

avoid conflicts you may turn off DHCP on the backup device or even better, split the DHCP lease range in order to prevent any lease duplication.



Note

M!DGE assigns a priority of 100 to the master and 1 to the backup router. Please adapt the priority of your third-party device appropriately.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT

SDK
Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

SNMP Agent

Web Server

Redundancy

Administrative status: enabled disabled

Role:

VID:

Interface:

Virtual gateway address:

Administrative status	Enable or disable Redundancy
Role	Role of this system (either master or backup)
VID	The Virtual Router ID (you can theoretically run multiple instances)
Interface	Interface on which VRRP should be performed
Virtual gateway address	Virtual gateway address formed by the participating hosts

7.6.15. Modbus TCP

While in UHF RipEX radios, using Modbus TCP transparently was not a preferred option, in the cellular routers, on contrary, it is a recommended solution. In such a case that all connected devices use Modbus TCP, there is no need to use and configure this feature. Just send data transparently as TCP over the cellular network.

But if you combine Modbus TCP and Modbus RTU within one network, you should use our Modbus TCP solution. You do not need any external Modbus TCP - Modbus RTU converter, the functionality is implemented in the M!DGE firmware.

The Modbus TCP daemon listens for the local TCP connection on the TCP port 502 by default. After the connection is established, the communication can be initiated. Any incoming Modbus TCP datagram is investigated and based on the Modbus TCP "Unit ID" Byte and Address translation Table/mask rules,

is forwarded as UDP to the final destination (by default the UDP port is 8902), e.g. another M!DGE unit with Modbus RTU device connected over the RS232 port.



Note

This behaviour comes from the RipEX functionality where UDP is a preferred transport solution. In case of cellular networks, TCP might be a better solution. When implementing this solution into your network, you might configure Modbus TCP on the remote M!DGE (not a unit locally connected via Ethernet) causing the TCP session to be between a local device and remote M!DGE instead of UDP. The final conversion from TCP to UDP so the Protocol server listening on the UDP port 8882 by default is done at the remote unit afterwards. In such a case, make a Translation rule which sends all received packets to the localhost.



Important

In some Modbus TCP implementations, Unit ID field within the datagram is always set to "FF". In such a case, you can use the "Replace PLC address" option so that the Unit ID is replaced by some Modbus RTU address. Thanks to this parameter, regular Mask/Table address translation can be used. Consider carefully where you put the corresponding parameter (local or remote M!DGE and if placed in Modbus TCP or Modbus RTU Protocol server menu - it can be set at both places, but not simultaneously).

See the Application note for more details and examples.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

SDK

- Administration
- Job Management
- Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

SNMP Agent

Web Server

Redundancy

Modbus TCP

Modbus TCP

Administrative status enabled
 disabled

My TCP Port TCP Inactivity [s]

Transport Protocol

Port

Broadcast

Replace PLC address

Address translation

Address translation

Base IP

Mask

Interface (Destination port)

Administrative status

Enable or disable the feature.

My TCP Port

The TCP port for a session with local Modbus TCP Master. It can also be a remote Modbus TCP Master resulting in a TCP session over the cellular network instead of UDP.

TCP inactivity [s]

The TCP inactivity timeout in seconds.

Transport protocol	The transport protocol used, must be set to UDP only.
Port	The port number for a transport protocol (8902 by default).
Broadcast	The broadcast is always disabled in cellular networks.
Replace PLC address	If set, manually configure replacing the current PLC with a configured Modbus RTU address. Modbus TCP consists of the Unit ID field which can be changed manually by this parameter.
Address translation	See <i>Protocol Server</i> article.

7.6.16. Terminal Server

Generally a Terminal Server (also referred to as a Serial Server) enables connection of devices with serial interface to a M!DGE over the local area network (LAN), or even over the cellular network. It is a virtual substitute for devices used as serial-to-TCP(UDP) converters. It is possible to configure two Terminal servers.

Examples of the use:

A SCADA application in the centre should be connected to the cellular (M!DGE) network via a serial interface, however for some reason that serial interface is not used. The operating system (e.g. Windows) can provide a virtual serial interface to such application and converts the serial data to TCP (UDP) datagrams, which are then received by the Terminal server in M!DGE. This type of interconnection between M!DGE and application is especially advantageous when:

- there is not any physical serial interface on the computer
- the serial cable between M!DGE and computer would be too long (e.g. the M!DGE is installed very close to the antenna to improve radio coverage)
- the LAN between the computer and the place of M!DGE installation already exists
- Modbus TCP is used with local TCP sessions on slave sites or when combination of Modbus RTU and Modbus TCP is used. For more information refer to *Application note Modbus TCP/RTU*⁴. This applies also to other SCADA protocol TCP versions, e.g. DNP3 TCP.



Note

If configured on LAN, the TCP (UDP) session operates only locally between the M!DGE and the central computer, hence it does not increase the data load on WWAN (cellular network).

In some special cases, the Terminal server can be also used for reducing the network load from applications using TCP. A TCP session can be terminated locally at the Terminal server in M!DGE, user data extracted from TCP messages and processed like it comes from a serial (RS232) port. When data reaches the destination M!DGE, it can be transferred to the RTU either via a serial interface or via TCP (UDP), using the Terminal server again.

⁴ <https://www.racom.eu/eng/products/m/ripex/app/modbus/index.html>

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Servers

Terminal Server Administration

Administrative status enabled
 disabled

Terminal Servers

Number	Type	My IP	My Port	Status
1	TCP	0.0.0.0	50001	disabled 
2	TCP	0.0.0.0	50002	disabled 

SDK
Administration
Job Management
Testing

DHCP Server

DNS Server

NTP Server

Dynamic DNS

E-mail

Events

SMS

SSH/Telnet Server

SNMP Agent

Web Server

Discovery

Redundancy

Modbus TCP

Terminal Server

Administrative status Enable or disable the feature

If Enabled, 2 independent Terminal servers can be set up.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT

Servers **Terminal Server** Protocol Settings **Server number: 1**

Terminal Server

Administrative status enabled
 disabled

Type

TCP Inactivity

My IP

My Port

Destination IP

Destination Port

Administrative status Enable or disable the particular TS

Type Set the TS Type - either TCP or UDP session

TCP Timeout If the Type is TCP, configure the required TCP timeout (i.e. close the TCP session if there is no communication for a given time period)

My IP	IP address of M!DGE - usually Ethernet interface, but IP address of any interface can be used (pre-set IP address of given interface). "Manual" IP can also be filled.
My Port	Set any listening TCP/UDP port (i.e. M!DGE listens for incoming connection on a given port).
Destination IP	The destination IP address of TCP/UDP session (e.g. locally connected SCADA, virtual serial interface). IP address 0.0.0.0 can also be configured - any host can open the session with M!DGE.
Destination Port	The destination port of TCP/UDP session. In some cases, applications dynamically change the IP port with each datagram. In such a case set Destination port=0. M!DGE will then send replies to the port from which the last response was received. This feature allows to extend the number of simultaneously opened TCP connections between a M!DGE and locally connected application to any value up to 10 on each Terminal server.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | **[SERVICES](#)** | [SYSTEM](#) | [LOGOUT](#)

Servers	Terminal Server	Protocol Settings	Server number: 1
Protocol Server			
Protocol	<input type="text" value="- None -"/>		
Transport Protocol	<input type="text" value="UDP"/>		
Port	<input type="text" value="8892"/>		
<input type="button" value="Apply"/>	<input type="button" value="Continue"/>		

Protocol follows the same principles as a protocol on RS232 interface. The default UDP port is 8892 (transporting data usually over cellular network).

7.6.17. Voice Gateway

You can set up a voice gateway on the MIDGE2 router which can be used to connect mobile calls to VoIP clients and vice versa.

Administration:

The screenshot shows the web configuration interface for the Voice Gateway Administration page. At the top, there is a navigation bar with links: HOME | INTERFACES | ROUTING | FIREWALL | VPN | **SERVICES** | SYSTEM | LOGOUT. Below this, there are three tabs: Administration (selected), Endpoints, and Routing. The main content area is titled 'Administration' and contains two settings: 'Administrative status' with radio buttons for 'enabled' (selected) and 'disabled', and 'Call Routing' with a dropdown menu set to 'Generic'. An 'Apply' button is located at the bottom of the settings. On the left side, there is a sidebar menu with various service categories: SDK (Administration, Job Management, Testing), DHCP Server, DNS Server, NTP Server, Dynamic DNS, E-mail, Events, SMS, SSH/Telnet Server, SNMP Agent, Web Server, Discovery, Redundancy, Modbus TCP, Terminal Server, and Voice Gateway (highlighted).

The following parameters can be used to set it up:

Administrative status	Specifies whether the gateway shall be enabled or disabled
Call routing	Defines who will be responsible for call routing. If SDK has been specified you would need to install a script (see examples) which will be responsible for routing and accepting the calls. Otherwise the static routing configuration will be used.

In case you are running multiple WWAN interfaces sharing the same SIM, please bear in mind that the system may switch SIMs during operation which will also result in different settings for voice communication.

Endpoints:

Administration	Endpoints	Routing
----------------	-----------	---------

Edit Voice Endpoint Vom1

Type:

Modem:

Audio profile:

Volume level:

On this page you can activate the endpoints used for voice communication, the following types are supported:

Voice-Over-Mobile Endpoint for GSM/UMTS/LTE calls (can be used for calls to mobile or landline phones)

Nil-Device A proforma Device to enable Call Signaling without Voice Support

Based on your equipment, we recommend to adjust the modem's audio profile for a better sound experience. The following profiles are available:

Handset Provides a mild echo, short delay (less than 16-ms dispersion). This mode is intended for use with a well-designed handset, where the Echo Return Loss (ERL) is generally high. Full-duplex performance is easiest to achieve in this mode.

Headset Provides a moderate echo, short delay (less than 16-ms dispersion). This mode is intended for use in situations where the echo may be loud but low in delay. There are a variety of different headsets available with a wide variety of echo characteristics and noise pickup. Although the echo delay is typically short (< 16 ms) with all headsets, the echo return loss characteristics can vary significantly and are not well known a priori to the handset designer. This mode is more robust and more aggressive at echo cancellation.

Speakerphone Handle situations of loud echo with extreme acoustic distortion. This mode is intended for use with a car kit or speakerphone applications with high volume and high distortion. Acoustic echo in this situation has negative ERL and is impossible to cancel completely. It operates in a half-duplex manner and will be very aggressive in muting the entire signal to prevent any echo blips from being heard.

Bluetooth/Carkit Provides moderate echo, long delay (up to 64-ms dispersion). These modes are intended for bluetooth headsets and carkits which may have DSP processing on board and could give added delay to the system.

Volume level Specifies the modem's volume level. 1 = low. 9 = high.

Routing:

Administration Endpoints Routing

Edit Voice Route

Source: Vom1

Mode: DROP

Apply Cancel

DROP

ROUTE

This page can be used to configure generic voice routing between the endpoints.

Enhanced routing facilities are provided via the SDK interface which is able to dispatch voice calls based on their attributes (such as phone number) and other system related status information (e.g. number/duration of calls per endpoint, registration status and so on). Using the SDK, you can also initiate or accept a call, adjust its volume level or do a hangup.

Anyway, for simple scenarios the generic method should be sufficient and can be configured as follows:

Source Specifies the source endpoint (i.e. where the call comes in)

Mode The type of action which shall be applied for the call: DROP will silently hangup the call, ROUTE will route the call to the specified endpoint. Destination Specifies the target endpoint (i.e. where to call is routed to).

7.7. SYSTEM

7.7.1. System

Settings

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System Syslog LEDs Bootloader

System Settings Time & Region Reboot

Authentication Authentication User Accounts Remote Authentication

Local hostname: MIDGE

Application area: stationary

Reboot delay: 3 seconds

Enable TCP timestamps:

- Local host name:** The local system hostname
- Application area:** The desired application area which influences the system behaviour such as registration timeouts when operating in the mobile environment.
- Reboot delay:** The number of seconds to wait before the reboot is initiated (might be needed for some system-rebooting events).
- Enable TCP timestamps:** Enable TCP timestamps for system wide TCP communication. This is needed for Protection Against Wrapped Sequence numbers (PAWS), but with these timestamps enabled a remote attacker can guess the uptime of the system. The uptime is a lower bound for the age of the main system components like the kernel. If the system has an uptime of 3 years, it's unlikely that recent security patches were applied.

Syslog

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System Syslog LEDs Bootloader

System Settings Time & Region Reboot

Authentication Authentication User Accounts Remote Authentication

Software Update

Storage: flash root

Max. filesize: 2048 kB (max. 65536)

Redirect address:

Apply

- Storage** The storage device on which logfiles shall be stored.
- Max. filesize** The maximum size of the logfiles (in kB) until they will get rotated.
- Redirect address** Specifies an IP address to which log messages should be redirected to. A tiny system log server for Windows is included in TFTP32 which can be provided if requested.

In general, the unit comes with an internal flash device which can be used to store data or you can use the external USB disk.

- Flash root The root partition of the internal flash.
- USB disk A storage disk connected to the external USB port.

LEDs

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System Syslog **LEDs** Bootloader

LED1 (WAN):

LED2 (LAN):

LED3 (VPN):

LED4 (EXT):

LED5 (SYS):

This menu allows to configure the behaviour of the LEDs on the front panel. The first LED (STAT) cannot be changed.

Bootloader

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System Syslog LEDs **Bootloader**

New password:

Confirm new password:

Password The password used to unlock the bootloader. If empty, the admin password will be used.

Time & Region

Network Time Protocol (NTP) is a protocol for synchronizing the clocks of computer systems over packet-switched, variable-latency data networks. M!DGE can synchronize its system time with an NTP server. If enabled, time synchronization is usually triggered after a WAN link has come up but before starting any VPN connections. Further time synchronizations are scheduled in the background every 60 minutes.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System

- Settings
- Time & Region
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Software Update

- Software Update
- Modem Firmware Update
- Software Profiles

Configuration

- File Configuration
- Factory Configuration

Troubleshooting

- Network Debugging

System Time

Current system time:

Time Synchronisation

Primary NTP server:

Secondary NTP server:

Ping check: enabled

Time Zone

Time zone:

Daylight saving changes:

- Current system time: The current system time which can be synchronized against a valid NTP server or set manually. If manually set, the time is lost after the reboot.
- NTP server 1: The primary NTP server IP address or hostname.
- NTP server 2 (optional): The optional secondary NTP server IP address or hostname.
- Ping check: Uses an ICMP ping to check whether NTP servers are available when running initial time update.
- Time zone: Time zone based on your geographical location.
- Daylight saving changes: This option can be used to reflect daylight saving changes (e.g. switching from summer to standard time) depending on the selected time zone.

Sync will perform the time synchronization immediately.

Virtualization

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System

- Settings
- Time & Region
- Virtualization
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Software Update

- Software Update
- Modem Firmware Update

Virtualization

Administrative status: enabled disabled

Guests

Description	Type	Storage	Path	Network	
Guest1	LXC	flash	/mnt/storage0/lxc/guest0	VIRT1	<input type="button" value="-"/> <input type="button" value="📄"/>

Virtualization gives customers the possibility to execute their own applications.

Reboot

This menu can be used to reboot the system. All WAN links will be interrupted.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System

- Settings
- Time & Region
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Software Update

- Software Update
- Firmware Update
- Software Profiles

Automatic Reboot

Status: enabled
 disabled

Time of day:

Manual Reboot

7.7.2. Authentication

Authentication

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System

- Settings
- Time & Region
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Authentication

Authentication method:

Allowed login methods:

This page offers a simple shortcut to allow only secure connections (SSH, HTTPS) for managing the router. If the option "Secure authentication preferred" is set, users will be redirected to HTTPS but can still login via HTTP/telnet.

User Accounts

This page lets you manage the user accounts on the device.

The standard admin user is a built-in power user that has permission to access the Web Manager and other administrative services and is used by several services as the default user. Keep in mind that the admin password will be also applied to the root user which is able to enter a system shell. Any other user represents a user with lower privileges, for instance it has only permission to view the status page or retrieve status values when using the CLI.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System

- Settings
- Time & Region
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Software Update

User Accounts

Admin accounts represent users with administrative privileges that can alter the system configuration. Other users only have the permission to view status information and can be used for VPN access.

Username	Role	Description	Shell	
admin	administrator	Administrator	cli	
test	user	testing	cli	

Username:

Description:	The user description.
Role	Either admin or user.
Old password	Enter the current password.
New password	Enter a new password.
Confirm new password	Enter a new password again to confirm correctness.



Note

When adding additional admin users you are required to provide the password of the default administrator.

Remote Authentication

A remote RADIUS server can be used to authenticate users. This applies for the Web Manager and other services supporting and incorporating remote authentication.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | **[SYSTEM](#)** | [LOGOUT](#)

System

- Settings
- Time & Region
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Software Update

- Software Update
- Modem Firmware Update
- Software Profiles

Configuration

- File Configuration
- Factory Configuration

Troubleshooting

- Network Debugging
- System Debugging
- Tech Support

Keys & Certificates

Licensing

Legal Notice

Remote Authentication

Administrative Status: enabled disabled

Use for login:

Primary RADIUS Configuration

Server address:

Secret:

Authentication port:

Accounting port:

Secondary RADIUS Configuration

Server address:

Secret:

Authentication port:

Accounting port:

Administrative status:	Enable or disable remote authentication.
Use for login:	This option enables remotely-defined users to access the Web Manager.

Primary RADIUS configuration:

Server address:	RADIUS server address.
Secret:	Secret used to authenticate against the RADIUS server.

Authentication port: Port used for authentication.

Accounting port: Port used for accounting messages.

Secondary RADIUS configuration:

This is used if the first server is not available.

7.7.3. Software Update

Manual Software Update

This menu can be used to run a manual software update.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System

- Settings
- Time & Region
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Software Update

- Software Update
- Modem Firmware Update
- Software Profiles

Configuration

- File Configuration
- Factory Configuration

Troubleshooting

Manual
Automatic

Manual Software Update

Current version:	99.99.40.98
Installed at:	2018-11-23 12:33:53

Update operation:

Upload image
 Download from URL

Upload image:

Soubor nevybrán.

Admin password:

(Required for downgrades to releases before 4.2)

Update operation: The update operation method being used. You can upload the image or download it from the given URL

URL: You can upload the image or download it from the given URL.

Admin password: Required for downgrades to releases before 4.2.

When issuing a software update, the current configuration (including files like keys/certificates) will be backed up. Any other modifications to the filesystem will be erased. The configuration is generally backward-compatible. We also apply forward compatibility when downgrading to a previous software within the same release line, which is accomplished by sorting out unknown configuration directives which actually may lead to loss of settings and features. Therefore, it's always a good idea to keep a copy of the working configuration. Generally, we do not recommend downgrading the software.

A software image can be either uploaded via the Web Manager or retrieved from a specific URL. It will be unpacked and deployed to a spare partition which gets activated if the update completed successfully. The whole procedure is accompanied by all green LEDs flashing up, the subsequent system reboot gets denoted by a slowly blinking Status LED. The backed up configuration will be applied at bootup and the Status LED will blink faster during this operation. Depending on your configuration, this may take a while.



Note

Starting with SW release 4.2 we set default to not saving passwords; using password hashes instead. Storing passwords for users can be enabled, but is not recommended for new applications.

Older SW releases require the passwords to be stored encrypted on the device. As we don't have them any more in release version 4.2 and later you will have to provide the administrator password if you want to downgrade to a release 4.1.x and lower. The same passphrase will be used for bootloader login as well.

All users which have no password stored on the device will not be able to login after downgrade until new passwords have been applied.

Automatic Software Update

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System
 Settings
 Time & Region
 Reboot

Authentication
 Authentication
 User Accounts
 Remote Authentication

Software Update
 Software Update
 Modem Firmware Update
 Software Profiles

Manual | **Automatic**

Automatic Software Update

Status: enabled
 disabled

Time of day:

URL:

Status: Enable/disable automatic software update

Time of day: Every day at this time M!DGE will do a check for updates

URL: The server URL where the software update package should be downloaded from. Supported protocols are TFTP, HTTP(s), and FTP

Firmware Update

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System
 Settings
 Time & Region
 Reboot

Authentication
 Authentication
 User Accounts
 Remote Authentication

Software Update
 Software Update
 Modem Firmware Update
 Software Profiles

Configuration
 File Configuration
 Factory Configuration

Modem Firmware Update

Modem firmware update manages internal firmware of modules integrated into the router like WWAN or WLAN.

Update operation: Upload image
 Download from URL

Module:

Storage:

Firmware package: Soubor nevybrán.

This menu can be used to perform a firmware update of a specific module.

Update operation:	The update operation method being used. You can upload a firmware package or download the files from a specific URL.
Module:	The module which shall be updated.
Storage:	The temporary storage which shall be used for the update procedure. For boxes with limited amount of flash it is possible to use an USB stick which must be properly set up in the USB section and hold a proper filesystem such as ext4.
URL:	The server URL where the firmware files should be downloaded from. Supported protocols are TFTP, HTTP, HTTPS, and FTP (protocol://server/path/file).

Software Profiles

In every router you have two software profiles. One is active (currently used) and one is inactive. You can easily switch between these profiles any time.

It can be for example useful when there is some issue with the newest firmware and you need to restore the previous firmware version easily. Or you can just test some new features in the newest firmware and then get back to the previous one.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System

- Settings
- Time & Region
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Software Update

- Software Update
- Firmware Update
- Software Profiles

Configuration

- File Configuration
- Factory Configuration

Available Software Profiles

Profile 1	Status: active
	Version: 3.8.40.100
	Installed: 2015-05-28 17:05:07
Profile 2	Status: inactive
	Version: 0.0.0.0
	Installed: 2015-04-27 02:04:10

Switch Profile

Current profile: Profile 1

Switch to: Profile 2 ▾ with current ▾ configuration

7.7.4. Configuration

Configuration via the Web Manager becomes tedious for large volumes of devices. MIDGE therefore offers automatic and manual file-based configuration to automate things. Once you have successfully set up the system you can back up the configuration and restore the system with it afterwards. You can either upload a single configuration file (.cfg) or a complete package (.zip) containing the configuration file and a packed version of other essential files (such as certificates).

File Configuration

This section can be used to download the currently running system configuration (including essential files such as certificates).

The current configuration file is updated after every change and the time of this update is displayed along with a configuration version and a security hash. The current configuration can be updated manually by pressing the Apply button.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

File Configuration | **Automatic Updates**

System
Settings
Time & Region
Reboot

Authentication
Authentication
User Accounts
Remote Authentication

Software Update
Software Update
Firmware Update
Software Profiles

Configuration
File Configuration
Factory Configuration

Troubleshooting
Network Debugging
System Debugging
Tech Support

Keys & Certificates

Licensing

Current Configuration

Description:

Version: 1.5

Last modified: 2015-06-11 08:26:47

Hash: 4abcf0c43bb98be6e0db7d54bc423e6f

File Configuration

Operation:

Download configuration file

Upload configuration file

Update configuration from URL

Configuration file: No file selected.

Configuration mode:

missing config directives will be replaced with factory defaults

missing config directives will be ignored

In order to restore a particular configuration you can upload a configuration previously downloaded or update configuration from the provided URL link.

You can choose between missing configuration directives stay the same as in the currently running configuration.

Automatic Updates

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

File Configuration | **Automatic Updates**

Automatic Updates

Status: enabled
 disabled

Time of day:

URL:

Status: Enable/disable automatic configuration update

Time of day: Time of day when the system will check for updates

URL: The server URL where the configuration file should be retrieved from (supported protocols are HTTP(s), TFTP, FTP)

Factory Configuration

This menu can be used to reset the device to factory defaults. Your current configuration will be lost.

This procedure can also be initiated by pressing and holding the Reset button for at least 10 seconds. A successfully initiated factory reset can be noticed by all LEDs being turned on.

Factory reset will set the IP address of the Ethernet interface back to 192.168.1.1. You will be able to communicate again with the device using the default network parameters.

You may store the currently running configuration as factory defaults which will reside active even when a factory reset has been initiated (e.g. by your service staff). Please ensure that this corresponds to a working configuration. A real factory reset to the default settings can be achieved by restoring the original factory configuration and initiating the factory reset again.



Important

If you store the currently running configuration as the factory defaults, have in mind that the password is also stored within this configuration.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System

- Settings
- Time & Region
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Software Update

- Software Update
- Firmware Update
- Software Profiles

Configuration

- File Configuration
- Factory Configuration

Initiate Factory Reset

This operation will reset all settings to factory defaults. Your current configuration will be lost. You may consider backing up the current configuration prior to running a reset.

Factory Default Configuration

You may store the currently running configuration as factory defaults. This configuration will be activated whenever a factory reset has been triggered.

7.7.5. Troubleshooting

Network Debugging

Various tools reside on this page for further analysis of potential configuration issues. The **ping** utility can be used to verify the remote host reachability.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | **SYSTEM** | [LOGOUT](#)

- System
 - Settings
 - Time & Region
 - Reboot
- Authentication
 - Authentication
 - User Accounts
 - Remote Authentication
- Software Update
 - Software Update
 - Firmware Update
 - Software Profiles
- Configuration
 - File Configuration
 - Factory Configuration
- Troubleshooting**
 - Network Debugging
 - System Debugging
 - Tech Support

Network Debugging

[ping](#) | [traceroute](#) | [tcpdump](#) | [darkstat](#)

The ping utility can be used to verify whether a remote host can be reached via IP.

Host:

Packet count:

Packet size:

Define the remote host (IP address or hostname), number of packets and the packet size.

The **traceroute** utility can be used to print the route to a remote host.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | **SYSTEM** | [LOGOUT](#)

- System
 - Settings
 - Time & Region
 - Reboot
- Authentication
 - Authentication
 - User Accounts
 - Remote Authentication
- Software Update
 - Software Update
 - Firmware Update
 - Software Profiles
- Configuration
 - File Configuration
 - Factory Configuration
- Troubleshooting**
 - Network Debugging
 - System Debugging
 - Tech Support

Network Debugging

[ping](#) | [traceroute](#) | [tcpdump](#) | [darkstat](#)

The traceroute utility can be used to print the route packets trace to a remote host.

Target host:

Time-To-Live:

Timeout:

Define the target host (IP or hostname), Time-To-Live (TTL - number of hops on the resulting route) and the timeout in seconds (max. time to wait for the final respond).

The **tcpdump** utility generates a network capture (PCAP) of an interface which can be later analyzed with Wireshark.

System

Settings
Time & Region
Reboot

Authentication

Authentication
User Accounts
Remote Authentication

Software Update

Software Update
Modem Firmware Update
Software Profiles

Configuration

File Configuration
Factory Configuration

Troubleshooting

Network Debugging
System Debugging
Tech Support

Network Debugging

ping

traceroute

tcpdump

darkstat

The tcpdump utility generates a network capture (PCAP) of an interface which can be later analyzed with [Wireshark](#).

Interface:	<input type="text" value="LAN1"/>
Maximum number of packets:	<input type="text" value="1000"/>
Exclude:	<input type="checkbox"/> http <input type="checkbox"/> https <input type="checkbox"/> telnet <input type="checkbox"/> ssh
IP whitelist:	<input type="text"/>
Port whitelist:	<input type="text"/>
<input type="button" value="Start"/>	

Several basic protocols can be excluded from the resulting PCAP file (HTTP, HTTPS, Telnet and SSH). Only specific IP addresses and/or ports can be captured.


**Note**

The default number of received packets is set to 1000. For downloading the file, just click on the Download button. The captured file can be also downloaded from the /tmp/ directory via the appropriate file manager.


The **darkstat** utility can be used to visualize your current network connections and traffic on a particular interface.

Graphs (lan1)


Running for 28 mins, 47 secs, since 2014-06-10 06:28:31 UTC+0000.
Total 893,904 bytes, in 5,276 packets. (8,038 captured, 0 dropped)




in ■ min: 0.6 KB/s, avg: 0.6 KB/s, max: 1.9 KB/s
out ■ min: 0.1 KB/s, avg: 0.9 KB/s, max: 3.1 KB/s
last 60 seconds



in ■ min: 0.0 KB/s, avg: 0.0 KB/s, max: 0.5 KB/s
out ■ min: 0.0 KB/s, avg: 0.0 KB/s, max: 0.7 KB/s
last 60 minutes



in ■ min: 0.0 KB/s, avg: 0.0 KB/s, max: 0.0 KB/s
out ■ min: 0.0 KB/s, avg: 0.0 KB/s, max: 0.0 KB/s
last 24 hours



in ■ min: 0.0 KB/s, avg: 0.0 KB/s, max: 0.0 KB/s
out ■ min: 0.0 KB/s, avg: 0.0 KB/s, max: 0.0 KB/s
last 31 days

- automatic reload is:

After the utility initialization, it can be viewed in a separate window. Displaying graphs and individual host statistics are supported.

System Debugging

Log files can be viewed, downloaded and reset here. Please study them carefully in case of any issues.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | **SYSTEM** | [LOGOUT](#)

System
Settings
Time & Region
Reboot
Authentication
Authentication
User Accounts
Remote Authentication
Software Update
Software Update
Firmware Update
Software Profiles
Configuration
File Configuration
Factory Configuration
Troubleshooting
Network Debugging
System Debugging
Tech Support
Keys & Certificates
Licensing
Legal Notice

System Debugging

Log Viewer
Debug Levels

Show of Reset

```

Jun 10 17:14:31 mg daemon.info pppd[7979]: terminating on signal 15
Jun 10 17:14:31 mg daemon.info pppd[7979]: Connect time 152.6 minutes.
Jun 10 17:14:31 mg daemon.info pppd[7979]: Sent 7296 bytes, received 7248 bytes.
Jun 10 17:14:31 mg daemon.notice pppd[7979]: Connection terminated.
Jun 10 17:14:32 mg daemon.info pppd[7979]: Serial link disconnected.
Jun 10 17:14:33 mg daemon.info pppd[7979]: Exit.
Jun 10 17:14:34 mg local1.notice MIDGE: Scanning networks on Mobile1
Jun 10 17:14:35 mg local1.notice MIDGE: Activating WWAN connections
Jun 10 17:14:35 mg user.info sdkhost[11627]: testrun: 1 networks found
Jun 10 17:14:35 mg user.info sdkhost[11627]: testrun: skipping invalid network '02 - CZ' (Current)
Jun 10 17:14:35 mg user.info sdkhost[11627]: testrun: no best operator found
Jun 10 17:14:35 mg user.info sdkhost[11627]: testrun: done
Jun 10 17:14:35 mg user.notice link-manager[7827]: wanlink1: unsuspending link on request
Jun 10 17:14:35 mg user.notice link-manager[7827]: wanlink1: permanent link is unsuspending now
Jun 10 17:15:23 mg user.notice link-manager[7827]: wanlink1: starting to dial WWAN interface at -93 dBm
Jun 10 17:15:27 mg daemon.notice pppd[12127]: pppd 2.4.4 started by root, uid 0
Jun 10 17:15:29 mg daemon.info pppd[12127]: Serial connection established.
Jun 10 17:15:29 mg daemon.info pppd[12127]: Using interface wwan0
Jun 10 17:15:29 mg daemon.notice pppd[12127]: Connect: wwan0 <-> /dev/wwanmd0/modem
Jun 10 17:15:30 mg daemon.notice pppd[12127]: PAP authentication succeeded
Jun 10 17:15:35 mg daemon.warn pppd[12127]: Could not determine remote IP address: defaulting to 10.64.64.64
Jun 10 17:15:35 mg daemon.notice pppd[12127]: local IP address 10.203.3.28
Jun 10 17:15:35 mg daemon.notice pppd[12127]: remote IP address 10.64.64.64
Jun 10 17:15:35 mg daemon.notice pppd[12127]: primary DNS address 80.74.32.240
Jun 10 17:15:35 mg daemon.notice pppd[12127]: secondary DNS address 80.74.32.241

```

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | **SYSTEM** | [LOGOUT](#)

System
Settings
Time & Region
Reboot
Authentication
Authentication
User Accounts
Remote Authentication
Software Update
Software Update
Firmware Update
Software Profiles
Configuration
File Configuration
Factory Configuration
Troubleshooting
Network Debugging
System Debugging
Tech Support
Keys & Certificates

System Debugging

Log Viewer
Debug Levels

link-manager

0
 1
 2
 3
 4
 5
 6
 7

configd
 watchdog
 swupdate
 wwan-manager
 led-manager
 event-manager
 link-manager
 wwanmd
 surveyor
 mobile-node
 home-agent
 voiced
 smsd
 sdkhost
 qmid
 ser2net
 qosd
 rrs2

Default debugging levels for individual daemons are as follows:

- configd – 4
- watchdog – 4
- swupdate – 5
- wwan-manager – 5
- led-manager – 5

- event-manager – 5
- link-manager – 5
- wwanmd – 5
- surveyor – 5
- mobile-node – 4
- home-agent – 4
- voiced – 4
- smsd – 5
- sdkhost – 6
- qmid – 4
- ser2net – 4
- rrsp2 – 1
- rrsp11 - 1
- rrsp12 - 1
- rrsp21 - 1
- qosd – 0

You can change the values to suit your needs and you can reset the values into their defaults by pressing the "**Reset**" button afterwards.

Tech Support

You can generate and download a tech support file here.

We strongly recommend providing this file when getting in touch with our support team, either by e-mail or via our online support form, as it would significantly speed up the process of analyzing and resolving your problem.



Note

For both direct E-mail and Online support form a connection to the Internet has to be available.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | **SYSTEM** | [LOGOUT](#)

- System
 - Settings
 - Time & Region
 - Reboot
- Authentication
 - Authentication
 - User Accounts
 - Remote Authentication
- Software Update
 - Software Update
 - Firmware Update
 - Software Profiles
- Configuration
 - File Configuration
 - Factory Configuration
- Troubleshooting
 - Network Debugging
 - System Debugging
 - Tech Support

Tech Support

You can generate and download a tech support file here.

We strongly recommend to provide this when getting in touch with our support team (either by [E-Mail](#) or via our [online support form](#)) as it would significantly speed up the process of analyzing and resolving your problem.

Exclude secrets:

Encrypt file:

You can encrypt the Techsupport file in order to secure the file against reading it without knowing the security key for decrypting the file. It is more secure way to send the techsupport file via nonsecure e-mail. The decrypting key is known by our support team only and cannot be provided to anybody. Another option is to exclude secrets - passwords, credentials... But they are not readable in a plain text anyway.

7.7.6. Keys & Certificates

The key and certificate page lets you generate required files for securing your services (such as the HTTPS/WebServer and SSH server). Keep in mind that you will need to create keys and certificates for VPN or WLAN in case of certificate based authentication. You can also revoke and invalidate certificates again (for instance if they have been compromised or lost).

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | **SYSTEM** | [LOGOUT](#)

- System
 - Settings
 - Time & Region
 - Reboot
- Authentication
 - Authentication
 - User Accounts
 - Remote Authentication
- Software Update
 - Software Update
 - Firmware Update
 - Software Profiles
- Configuration
 - File Configuration
 - Factory Configuration
- Troubleshooting
 - Network Debugging
 - System Debugging
 - Tech Support

Keys & Certificates		Configuration
Name	Description	Status
Root CA	The root authority used for issuing local certificates	installed 
Web Server	The SSL certificates used by the Web server	installed 
SSH Server	The host keys used by the SSH server	installed 
SSH Authorization	The keys used for SSH authorization	missing 
OpenVPN1	The certificates used for authenticating OpenVPN Tunnel 1	installed 
Authorities	Other certificate authorities which we trust	missing 

Keys & Certificates

The entry pages shows an overview about installed keys and certificates. The following sections may appear:

- Root CA: The root Certificate Authority (CA) which issues certificates, its key can be used to certify it at trusted third party on other systems.
- Web Server: The certificates for the Web server required for running HTTP over SSL (HTTPS).
- SSH Server: The DSS/DSA keys for the SSH server.
- SSH Authorization: The keys used for SSH authorization.
- OpenVPN: Server or client keys and certificates for running OpenVPN tunnels.
- IPsec: Server or client keys and certificates for running IPsec tunnels.
- WLAN: Keys and certificates for implementing certificate-based WLAN authentication (e.g. WPA-EAP-TLS).
- Authorities: Other certificate authorities which we trust when establishing SSL client connections.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System

- Settings
- Time & Region
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Software Update

- Software Update
- Firmware Update
- Software Profiles

Configuration

- File Configuration
- Factory Configuration

Troubleshooting

- Network Debugging
- System Debugging
- Tech Support

Keys & Certificates

Web Server

The SSL certificates used by the Web server

Server certificate	installed	view
Server key	installed	view
CA certificate	installed	view

Action:

generate locally ▼

- generate locally
- upload files
- enroll via SCEP
- download certificate
- create signing request
- erase certificate

X.509 attributes: L=Czech Republic, O=RACOM, OU=Networking, support@racom.eu

For each certificate section it is possible to perform the following operations:

- generate locally: Generate key and certificate locally on M!DGE
- upload files: Key and certificate will be uploaded. We support files in PKCS12, PKCS7, PEM/DER format as well as RSA/DSS keys in OpenSSH or Dropbear format.
- enroll via SCEP: Enroll key and certificate via SCEP
- download certificate: Download key and certificate in ZIP format (files will be encoded in PEM format)
- create signing request: Generate key locally and create a signing request to retrieve a certificate signed by another authority

erase certificate: Erase all keys and certificates associated with this section

Configuration

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

Keys & Certificates Configuration

Organization (O)	<input type="text" value="RACOM"/>
Department (OU)	<input type="text" value="Networking"/>
Location (L)	<input type="text" value="Czech Republic"/>
State (ST)	<input type="text" value="Czech Republic"/>
Country (C)	<input type="text" value="Czech Republic"/>
Common Name (CN)	<input type="text" value="MIDGE"/>
E-Mail	<input type="text" value="support@racom.eu"/>
Expiry period:	<input type="text" value="7300"/> days
Key size:	<input type="text" value="2048"/> bits
DH primes:	<input type="text" value="1024"/> bits
Signature:	<input type="text" value="md5"/>
Cipher:	<input type="text" value="des3"/>
Passphrase:	<input type="password" value="••••••••"/>

SCEP Configuration

SCEP Status: enabled disabled

This page provides some general configuration options which will be applied when operating with keys and certificates. If keys, certificates and signing requests are generated locally, the following settings will be taken into account:

Organization (O):	The certificate owner's organization
Department (OU):	The name of the organizational unit to which the certificate issuer belongs
Location (L):	The certificate owner's location
State (ST):	The certificate owner's state
Country (C):	The certificate owner's country (usually a TLD abbreviation)
Common Name (CN)	The certificate owner's common name, mainly used to identify a host
E-Mail	The certificate owner's email address
Expiry period	The number of days a certificate will be valid from now on
Key size	The length of the private key in bits

DH primes	The number of bits for custom Diffie-Hellman primes
Signature	The signature algorithm when signing certificates
Cipher:	Choose a required Cipher
Passphrase	The passphrase for accessing/opening a private key

Please be aware of the fact, that the local random number generator (RNG) provides pretty good randomness for most applications. If stronger cryptography is mandatory, we suggest to create the keys at an external RNG device or manage all certificates completely on a remote certification server. Nevertheless, using a local certificate authority can issue and manage all required certificates and also run a certificate revocation list (CRL).

When importing keys, the certificate and key file can be uploaded individually encoded in PEM/DER or PKCS7 format. All files (CA certificate, certificate and private key) can also be uploaded in one stroke by using the container format PKCS12. RSA/DSS keys can be converted from OpenSSH or Dropbear formats. It is possible to specify the passphrase for opening the private key. Please note that the system will generally apply the system-wide certificate passphrase on a key when installing the certificate. Thus, changing the general passphrase will result in all local keys getting equipped with the new one.

SCEP Configuration

SCEP Configuration

SCEP Status: enabled
 disabled

URL:

CA fingerprint:

Fingerprint algorithm:

CA identifier: (optional)

Poll interval: seconds

Request timeout: seconds

ID type:

Password:

If certificates are getting enrolled by using the Simple Certificate Enrollment Protocol (SCEP) the following settings can be configured:

SCEP status:	Specifies whether SCEP is enabled or not.
URL:	The SCEP URL, usually in the form http://<host>/<path>/pkiclient.exe.
CA fingerprint:	The fingerprint of the certificate used to identify the remote authority. If left empty, any CA will be trusted.
Fingerprint algorithm:	The fingerprint algorithm for identifying the CA (MD5 or SHA1).

CA Identifier:	The Certification Authority issuer identifier (if SCEP server requires it). The CA Identifier is any string that is understood by the SCEP server (e.g. a domain name).
Poll interval:	The polling interval in seconds for a certificate request.
Request timeout:	The max. polling time in seconds for a certificate request.
ID type	It can be IP, Email or DNS.
Password	The password for the scep server.

When enrolling certificates, the CA certificate will be initially fetched from the specified SCEP URL using the getca operation. It will be shown on the configuration page and it has to be verified that it belongs to the correct authority. Otherwise, the CA must be rejected. This part is essential when using SCEP as it builds up the chain of trust. If a certificate enrollment request times out, it is possible to re-trigger the interrupted enrollment request and it will be resumed using the previously generated key. In case a request has been rejected, you are required to erase the certificate first and then start the enrollment process all over again.

Authorities

For SSL client connections (as used by SDK functions or when downloading configuration/software images) you might upload a list of CA certificates which are considered trusted. To obtain the CA certificate from a particular site with Mozilla Firefox, the following steps will be required:

- Point the browser to the relevant HTTPS website
- Click the padlock in the address bar
- Click the More Information and the View Certificate button
- Select the Details tab and press the Export button
- Choose a path for the file (e.g. website.pem)

7.7.7. Licensing

This menu allows you to view and update the license status of your system. Note that some features are disabled if no valid license is provided.

HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | **SYSTEM** | LOGOUT

System

- Settings
- Time & Region
- Reboot

Authentication

- Authentication
- User Accounts
- Remote Authentication

Software Update

- Software Update
- Modem Firmware Update
- Software Profiles

Configuration

- File Configuration
- Factory Configuration

Troubleshooting

- Network Debugging
- System Debugging
- Tech Support

Keys & Certificates

Licensing

Legal Notice

License Installation

Operation: Upload license file
 Download license from URL

License file: Soubor nevybrán.

Licensing Status

Serial number: 0002A9FFEB54

License status: A valid license is installed.

Feature	Availability	Licensing Status
GPS	no	unlicensed
GSM	yes	licensed
LTE	yes	licensed
SERVER	yes	unlicensed
TX_ADV	yes	unlicensed
UMTS	yes	licensed
VIRT	yes	unlicensed
VOICE	yes	unlicensed
WLAN	no	unlicensed

Availability means that the licence can be applied to the current hardware. The valid license is active if the status "licensed" is displayed in the respective line.

7.7.8. Legal Notice

A dedicated GUI page under SYSTEM is pointing out that M!DGE contains in part open source software that may be licensed under GPL, LGPL or other open source licenses. It further provides detailed information for each package, including the relevant license text and the corresponding source URL. The user is now obliged to accept our end user license agreement during the initial setup of the router. We remind you that the source code of any package can be obtained by contacting our technical support at support@racom.eu.

System
Settings
Time & Region
Reboot
Authentication
Authentication
User Accounts
Remote Authentication
Software Update
Software Update
Modem Firmware Update
Software Profiles
Configuration
File Configuration
Factory Configuration
Troubleshooting
Network Debugging
System Debugging
Tech Support
Keys & Certificates
Licensing
Legal Notice

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | **[SYSTEM](#)** | [LOGOUT](#)

Legal Notice | Licenses

OSS Notice

We inform you that RACOM products may contain in part open source software. We are distributing such open source software to you under the terms of GNU General Public License (GPL), GNU Lesser General Public License (LGPL) or other open source licenses. These licenses allow you to run, copy, distribute, study, change and improve any software covered by GPL, Lesser GPL, or other open source licenses without any restrictions from us or our end user license agreement on what you may do with that software. Unless required by applicable law or agreed to in writing, software distributed under open source licenses is distributed on an "AS IS" basis, WITHOUT WARRANTIES BY THE COPYRIGHT HOLDERS. To obtain the corresponding open source codes covered by these licenses, please contact our technical support at support@racom.eu.

Acknowledgements

This product includes:

- PHP, freely available from <http://www.php.net>
- Software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>)
- Cryptographic software written by Eric Young (ey@cryptsoft.com)
- Software written by Tim Hudson (tjh@cryptsoft.com)
- Software written Jean-loup Gailly and Mark Adler
- MD5 Message-Digest Algorithm by RSA Data Security, Inc.
- An implementation of the AES encryption algorithm based on code released by Dr Brian Gladman
- Multiple-precision arithmetic code originally written by David Ireland
- Software from The FreeBSD Project (www.freebsd.org)
- Map and reverse geocoding tools using OpenStreetMap services (<http://wiki.openstreetmap.org>)
- An Internet metrics tool using Ookla Speedtest services (<http://www.speedtest.net>)

© Copyright 2018, RACOM s.r.o., Czech Republic. All rights reserved.

[HOME](#) | [INTERFACES](#) | [ROUTING](#) | [FIREWALL](#) | [VPN](#) | [SERVICES](#) | **[SYSTEM](#)** | [LOGOUT](#)

System
Settings
Time & Region
Reboot
Authentication
Authentication
User Accounts
Remote Authentication
Software Update
Software Update
Modem Firmware Update
Software Profiles
Configuration
File Configuration
Factory Configuration
Troubleshooting
Network Debugging
System Debugging
Tech Support
Keys & Certificates
Licensing
Legal Notice

Legal Notice | Licenses

Package:	kernel
Version:	3.18.16 (modified)
URL:	http://www.kernel.org
License:	GPL v2

```
NOTE! This copyright does *not* cover user programs that use kernel
services by normal system calls - this is merely considered normal use
of the kernel, and does *not* fall under the heading of "derived work".
Also note that the GPL below is copyrighted by the Free Software
Foundation, but the instance of code that it refers to (the Linux
kernel) is copyrighted by me and others who actually wrote it.

Also note that the only valid version of the GPL as far as the kernel
is concerned is _this_ particular version of the license (ie v2, not
v2.2 or v3.x or whatever), unless explicitly otherwise stated.

-----
Linus Torvalds

-----

GNU GENERAL PUBLIC LICENSE
Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc.
51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA
Everyone is permitted to copy and distribute verbatim copies
```

7.8. LOGOUT

Log out from Web Manager.

M!DGE



Logout

You are now logged out. Goodbye.

To log in again, please click [here](#)

8. Command Line Interface

The Command Line Interface (CLI) offers a unified control interface to the router and can be used to get/set configuration parameters, apply updates, restart services or perform other system tasks.

The CLI should be started using `cli -i` command from system shell or when logging as root user. A list of available commands can be displayed by running `cli -l`. It will be started automatically in interactive mode when logging in as *admin* user.

```
$ cli
Name:
      cli (Command Line Utility)

Usage:
      [-ilvh] <command>
```

```
~ $ cli -i
MIDGE2 Command Line Interface (version 1.1)
(C) Copyright RACOM s.r.o, Czech Republic
This kit is distributed under the terms of GPLv2.

Enter 'help' for a list of available commands
or hit the TAB key for auto-completion.

Ready to serve.

>
```

The CLI supports the TAB completion, that is expanding entered words or fragments by hitting the TAB key at any time. This applies to commands but also to arguments and generally offers a convenient way for working on the shell.

Please note that each CLI session will perform an automatic logout as soon as a certain time of inactivity (10 minutes by default) have been reached. It can be turned off by the command `no-autologout`.

The CLI can be exited by running `exit`.

8.1. General usage

When operating the CLI in interactive mode, each entered command will be executed by the RETURN key. You can use the Left and Right keys to move the current point between entered characters or use the Up and Down keys to search the history of entered commands. Pressing CTRL-c twice or CTRL-d on an empty command line will exit the CLI.

List of supported key sequences:

Key Sequence	Action
CTRL-a	Move to the start of the current line.
CTRL-e	Move to the end of the line.
CTRL-f	Move forward a character.
CTRL-b	Move back a character.
ALT-f	Move forward to the end of the next word.
ALT-b	Move back to the start of the current or previous word.
CTRL-l	Clear the screen leaving the current line at the top of the screen, with an argument given refresh the current line without clearing the screen.
CTRL-p	Fetch the previous command from the history list, moving back in the list.
CTRL-n	Fetch the next command from the history list, moving forward in the list.
ALT-<	Move to the first line in the history.
ALT->	Move to the end of the input history.
CTRL-r	Search backward starting at the current line and moving up through the history.
CTRL-s	Session will be frozen.
CTRL-q	Reactivate frozen session.
CTRL-d	Delete character at point or exit CLI if at the beginning of the line.
CTRL-t	Drag the character before point forward moving point forward as well. If point is at the end of the line, then this transposes the two characters before point.
ALT-t	Drag the word before point past the word after point, moving point over that word as well. If point is at the end of the line, this transposes the last two words on the line.
CTRL-k	Delete the text from point to the end of the line.
CTRL-y	Yank the top of the deleted text into the buffer at point.

Please note, that it can be required to apply quotes (") when entering commands with arguments containing whitespaces.

The following sections are trying to explain the available commands.

8.2. Print help

The `help` command can be used to get the list of available commands when called without arguments, otherwise it will print the usage of the specified command.

```
> help
Usage:
    help [<command>]

Available commands:

    get           Get config parameters
    set           Set config parameters
    done         Check done
    update       Update system facilities
    cert         Manage keys and certificates
    status       Get status information
    scan         Scan networks
    send         Send message, mail, techsupport or ussd
    restart      Restart service
    debug        Debug system
    reset        Reset system facilities
    reboot       Reboot system
    shell        Run shell command
    dio          DIO control
    help         Print help for command
    no-autologout Turn off auto-logout
    history      Show command history
    exit         Exit
```

8.3. Getting config parameters

The `get` command can be used to get configuration values (not the current values).

```
get -h
Usage:
    get [-hsvfc] <parameter> [<parameter>..]

Options:
    -s      generate sourceable output
    -v      validate config parameter
    -f      get factory default rather than current value
    -c      show configuration sections
```

See the following example for reading configuration DIO values:

```
> get dio.out1
dio.out1=on
> get dio.out2
dio.out2=on
```

8.4. Setting config parameters

The **set** command can be used to set configuration values.

```
> set -h
Usage:
    set [-hv] <parameter>=<value> [<parameter>=<value>..]

Options:
    -v    validate config parameter
```

See the following example for setting configuration digital output values. Both values will be "off" and both values will be also "off" after the next start-up procedure.

```
> set dio.out1=off
> set dio.out2=off
```

8.5. Updating system facilities

The **update** command can be used to perform various system updates.

```
> update -h
Usage:
    update [-hfrsnbv] <software|config|firmware <module>|license|sshkeys> <URL>

Options:
    -r    reboot after update
    -f    force update
    -n    don't reset missing config values with factory defaults
    -b    update backup config
    -s    show update status

Available update targets:

    software          Perform software update
    firmware <module> Perform module firmware update on upgradable module
    config            Update configuration
    license           Update licenses
    sshkeys           Install SSH authorized keys
```

8.6. Manage keys and certificates

The **update** command can be used to manage keys and certificates.

```
> cert -h
Usage:
    cert [-h] [-p phrase] <operation> <cert> [<url>]

Possible operations:
```

install	install a certificate from specified URL
create	create a certificate locally
enroll	enroll a certificate via SCEP
erase	erase an installed certificate
view	view an installed certificate

8.7. Getting status information

The **status** command can be used to get various status information of the system.

```
> status -h
Usage:
    status [-hs] <section>

Options:
    -s      generate sourceable output

Available sections:

    summary          Short status summary
    info             System and config information
    config           Current configuration
    system           System information
    configuration    Configuration information
    license          License information
    storage          Storage information
    led              LED status
    virt             Virtualization status
    wwan             WWAN module status
    wlan            WLAN module status
    gnss             GNSS (GPS) module status
    eth             Ethernet interface status
    lan             LAN interface status
    wan             WAN interface status
    openvpn         OpenVPN connection status
    ipsec           IPsec connection status
    pptp            PPTP connection status
    gre             GRE connection status
    dialin          Dial-In connection status
    mobileip        MobileIP status
    dio             Digital IO status
    audio           Audio module status
    can             CAN module status
    uart           UART module status
    redundancy      Redundancy status
    sms            SMS status
    firewall        Firewall status
    qos            QoS status
    neigh          Neighborhood status
    location        Current location
    users           Active users
```

```
hotspot          Hotspot status
bgp              BGP status
ospf            OSPF status
```

In the following example, we read the current DIO values. Remember that the current states do not correspond to the configuration values set with "set dio.out" commands.

```
> status dio
=== DIGITAL IO INFORMATION ===
IN1:                off
IN2:                on
OUT1:               on
OUT2:               off
```

8.8. Scan

The **scan** command can be used to scan the mobile network for the possible networks. Note that the active mobile connection will be deactivated during the scan procedure.

```
> scan -h
Usage:
    scan [-hs] <interface>

Options:
    -s      generate sourceable output

Available interfaces:

    Mobile1    (wwan0)
```

See the example below:

```
> scan -s Mobile1

NETWORK1_NAME="EUROTEL - CZ"
NETWORK1_LAI="23002"
NETWORK1_RAT="GSM"
NETWORK1_SERVICE="CSD"
NETWORK1_STATUS="Current"

NETWORK2_NAME="vodafone CZ"
NETWORK2_LAI="23003"
NETWORK2_RAT="GSM"
NETWORK2_SERVICE="CSD"
NETWORK2_STATUS="Forbidden"

NETWORK3_NAME="T-Mobile CZ"
NETWORK3_LAI="23001"
NETWORK3_RAT="GSM"
NETWORK3_SERVICE="CSD"
```

```
NETWORK3_STATUS="Forbidden"  
  
NETWORK_COUNT="3"
```

8.9. Sending e-mail or SMS

The **send** command can be used to send a message via E-Mail/SMS to the specified address or phone number.

```
> send -h  
Usage:  
    send [-h] <type> <dest> <msg>  
  
Options:  
    <type>    type of message to be sent (mail, sms, techsupport, ussd)  
    <dest>    destination of message (mail-address, phone-number or argument)  
    <msg>    message to be sent
```

8.10. Restarting services

The **restart** command can be used to restart system services.

```
> restart -h  
Usage:  
    restart [-h] <service>  
  
Available services:  
  
    configd          Configuration daemon  
    dnsmasq         DNS/DHCP server  
    dropbear        SSH server  
    firewall        Firewall and NAPT  
    gpsd            GPS daemon  
    gre             GRE connections  
    ipsec           IPsec connections  
    lighttpd        HTTP server  
    link-manager    WAN links  
    network         Networking  
    openvpn         OpenVPN connections  
    pptp           PPTP connections  
    qos            QoS daemon  
    smsd           SMS daemon  
    snmpd          SNMP daemon  
    surveyor       Supervision daemon  
    syslog         Syslog daemon  
    telnet         Telnet server  
    voiced         Voice daemon  
    vrrpd          VRRP daemon  
    wlan           WLAN interfaces  
    wwan-manager    WWAN manager
```

8.11. Debug

The **debug** command can be used to display individual daemons debugging output.

```
> debug -h
Usage:
    debug [-hr] [-l <level>] <target>

Options:
    -l <level>      set debug level
    -r              reset debug level

Available debug targets:

    system
    scripts
    configd
    watchdog
    swupdate
    wwan-manager
    led-manager
    event-manager
    link-manager
    wwanmd
    surveyor
    mobile-node
    home-agent
    voiced
    smsd
    sdkhost
    ser2net
    qosd
    gpsd
    ubxd
    rrsp2
    rrsp11
    rrsp12
    rrsp21
```

8.12. Resetting system

The **reset** command can be used to reset the router back to factory defaults.

```
> reset -h
Usage:
    reset [-h] [facility]

Available reset facilities:

    factory          Reset system to factory defaults
    statistics       Reset link statistics
```

8.13. Rebooting system

The **reboot** command can be used to reboot the router.

```
> reboot -h
Usage:
    reboot [-h]
```

8.14. Running shell commands

The **shell** command can be used to execute a system shell and run any arbitrary application.

```
> shell -h
Usage:
    shell [-h] [<cmd>]
```

8.15. CLI commands history

The **history** command displays the history of CLI commands entered on the unit.

```
> history
 1 help
 2 get -h
 3 get dio.out1
 4 set dio.out1=off
 5 set dio.out2=off
 6 set dio.out1=on
 7 get dio.out1
 8 get dio.out2
 9 set -h
```

8.16. CLI-PHP

CLI-PHP, an HTTP front-end to the CLI application, can be used to configure and control the router remotely. It is enabled in factory configuration, thus can be used for deployment purposes, but disabled as soon as the admin account has been set up. The service can later be turned on/off by setting the `cliphp.status` configuration parameter:

```
> get cliphp.status
cliphp.status=0

> set cliphp.status=1
> get cliphp.status
cliphp.status=1
```

<code>cliphp.status=0</code>	Service is disabled
<code>cliphp.status=1</code>	Service is enabled

This section describes the CLI-PHP interface for Version 2, the general usage (GET requests) is defined as follows:

Usage:

```
http (s)://cli.php?<key1>=<value1>&<key2>=<value2>..<keyN>=<valueN>
```

Available keys:

output	Output format (html, plain)
usr	Username to be used for authentication
pwd	Password to be used for authentication
commandV	Command to be executed
arg0..arg31	Arguments passed to commands

Notes:

The commands correspond to CLI commands as seen by 'cli -l', the arguments (arg0..arg31) will be directly passed to the cli application

Thus, an URL containing the following sequence:

```
command=get&arg0=admin.password&arg1=admin.debug&arg2=admin.access
```

will lead to cli being called as:

```
$ cli get "admin.password" "admin.debug" "admin.access"
```

It supports whitespaces but please be aware that any special characters in the URL must be specified according to RFC1738 (which usually done by common clients such as wget, lynx, curl).

Response:

The returned response will always contain a status line in the format:

```
<return>: <msg>
```

with return values of OK if succeeded and ERROR if failed. Any output from the commands will be appended

Examples:

```
OK: status command successful  
ERROR: authentication failed
```

status – Display status information

Key usage:

```
command=status[&arg0=<section>]
```

Notes:

Available sections can be retrieved by running command=status&arg0=-h.
System status can be displayed without authentication.

Examples:

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=admin01&command=
```

```
status&arg0=-h
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=admin01&command=
status&arg0=summary
http://192.168.1.1/cli.php?version=2&output=html&command=status
```

get – Get configuration parameter

Key usage:

```
command=get&arg0=<config-key> [&arg1=<config-key>..]
```

Examples:

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=
admin01&command=get&arg0=config.version
```

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=
admin01&command=get&arg0=openvpn.status&arg1=snmp.status&arg2=ipsec.status
```

set – Set configuration parameter

Key usage:

```
command=set&arg0=<config-key>&arg1=<config-value> [&arg2=<config
-key>&arg3=<config-value>..]
```

Notes:

In contrast to the other commands, this command requires a set of tuples because of the reserved '=' char, i.e.

[arg0=key0, arg1=val0], [arg2=key1, arg3=val1], [arg4=key2, arg5=val2], etc

Examples:

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=
admin01&command=set&arg0=snmp.status&arg1=1
```

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=
admin01&command=set&arg0=snmp.status&arg1=0&arg2=openvpn.status&arg3=1
```

restart – Restart a system service

Key usage:

```
command=restart&arg0=<service>
```

Notes:

Available services can be retrieved by running 'command=restart&arg0=-h'

Examples:

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=
```

```
admin01&command=restart&arg0=-h
```

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=
admin01&command=restart&arg0=link-manager
```

reboot - Trigger system reboot

```
Key usage:
  command=reboot
```

Examples:

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=admin01&command=reboot
```

reset - Run factory reset

```
Key usage:
  command=reset
```

Examples:

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=admin01&command=reset
```

update - Update system facilities

```
Key usage:
  command=update&arg0=<facility>&arg1=<URL>
```

Notes:

```
  Available facilities can be retrieved by running 'command=update
&arg0=-h'
```

Examples:

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=127
admin01&command=update&arg0=software&arg1=tftp://192.168.1.254/latest
```

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=
admin01&command=update&arg0=config&arg1=tftp://192.168.1.254/user-
config.zip
```

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=
admin01&command=update&arg0=license&arg1=http://192.168.1.254/xxx.lic
```

send - Send SMS

Key usage:

```
command=send&arg0=sms&arg1=<number>&arg2=<text>
```

Notes:

The phone number has to be specified in international format such as +123456789 including a leading plus sign (which can be encoded with %2B). The SMS daemon must be properly configured prior to using that function.

Examples:

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=admin01&command=send&arg0=sms&arg1=%2B123456789&arg2=test
```

send - Send E-Mail

Key usage:

```
command=send&arg0=mail&arg1=<address>&arg2=<text>
```

Notes:

The address has to be a valid E-Mail address such as abc@abc.com (the at-sign can be encoded with %40). The E-Mail client must be properly configured prior to using that function.

Examples:

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=admin01&command=send&arg0=mail&arg1=abc%40abc.com&arg2=test
```

send - Send TechSupport

Key usage:

```
command=send&arg0=techsupport&arg1=stdout
```

```
command=send&arg0=techsupport&arg1=<address>&arg2=<subject>
```

Notes:

The address has to be a valid E-Mail address such as abc@abc.com (the at-sign can be encoded with %40). The E-Mail client must be properly configured prior to using that function. In case of stdout, the downloaded techsupport file will be called 'download'.

Examples:

```
http://192.168.1.1/cli.php?version=2&output=mime&usr=admin&pwd=admin01&command=send&arg0=techsupport&arg1=stdout
```

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=admin01&command=send&arg0=techsupport&arg1=abc%40abc.com&arg2=subject
```

send - Send USSD code

Key usage:

```
command=send&arg0=ussd&arg1=<card>&arg2=<code>
```

Notes:

The argument card specifies the card module index (e.g. 0 for wwan0).
The USSD code can consist of digits, plus signs, asterisks
(can be encoded with %2A) and dashes (can be encoded with %23).

Examples:

```
http://192.168.1.1/cli.php?version=2&output=html&usr=admin&pwd=admin01&  
command=send&arg0=ussd&arg1=0&arg2=%2A100%23
```

9. Troubleshooting

9.1. Common errors

With cellular connection (even if signal is good enough) following Errors are common:

SIM missing	Check the SIM card status in the INTERFACES → SIMs menu, turn off the unit, insert/re-insert the SIM card and power up the unit again
PIN code required	Insert the correct PIN code in the INTERFACES → SIMs → Configuration menu
Connection not established or failed	See the SYSTEM → Troubleshooting → System Debugging output for any errors/warnings

9.2. Messages

The Web Manager displays messages in the status bar in the footer of a web page.

The screenshot shows the M!DGE web manager interface. At the top right is the RACOM logo. Below it is a navigation bar with links: HOME | INTERFACES | ROUTING | FIREWALL | VPN | SERVICES | SYSTEM | LOGOUT. On the left is a 'Status' menu with options: Summary, WAN, Ethernet, LAN, DHCP, QoS, System. The main content area has a 'Summary' section with a table:

Description	Administrative Status	Operational Status
Hotlink		WWAN1
WWAN1	enabled	up

Below the table is a red error message: **✘** 2014-06-10 11:45 SystemSettings: Invalid syslog filesize (must be 1024..8192)

There are three levels:

- Green The action was performed successfully.
- Yellow Warning – please consider the information.
- Red Error – command was not performed, typically with recommended action which is required before the possible successful action.

9.3. Troubleshooting tools

9.3.1. Pinger

Connection from the M!DGE router can be checked using the built-in pinger available in the **SYSTEM** → **Troubleshooting** → **Network Debugging menu**.

The traceroute command is available in the same menu for tracing the packets from the M!DGE router to the Host.

9.3.2. Log Files

Information about boot-up process and about running processes can be found in the Linux-like Log files, see the **SYSTEM** → **Troubleshooting** → **System Debugging** menu.

10. Safety, environment, licensing

10.1. Safety instructions

The M!DGE Wireless Router must be used in compliance with any and all applicable international and national laws and in compliance with any special restrictions regulating the utilization of the communication module in prescribed applications and environments.

To prevent possible injury to health and damage to appliances and to ensure that all the relevant provisions have been complied with, use only the original accessories. Unauthorized modifications or utilization of accessories that have not been approved may result in the termination of the validity of the guarantee.

The M!DGE Wireless Routers must not be opened. Only the replacement of the SIM card is permitted.

Voltage at all connectors of the communication module is limited to SELV (Safety Extra Low Voltage) and must not be exceeded.

For use with certified (CSA or equivalent) power supply, which must have a limited and SELV circuit output. The M!DGE is designed for indoor use only. Do not expose the communication module to extreme ambient conditions. Protect the communication module against dust, moisture and high temperature.

We remind the users of the duty to observe the restrictions concerning the utilization of radio devices at petrol stations, in chemical plants or in the course of blasting works in which explosives are used. Switch off the communication module when traveling by plane.

When using the communication module in close proximity of personal medical devices, such as cardiac pacemakers or hearing aids, you must proceed with heightened caution.

If it is in the proximity of TV sets, radio receivers and personal computers, M!DGE Wireless Router may cause interference.

It is recommended that you should create an approximate copy or backup of all the important settings that are stored in the memory of the device.

You must not work at the antenna installation during a lightning.

Always keep a distance bigger than 40cm from the antenna in order to keep your exposure to electromagnetic fields below the legal limits. This distance applies to Lambda/4 and Lambda/2 antennas. Larger distances apply for antennas with higher gain.

Adhere to the instructions documented in this user's manual.

10.2. RoHS and WEEE compliance

RoHS
compliant

WEEE
compliant

This product is fully compliant with the European Parliament's 2011/65/EU RoHS (Restriction of Certain Hazardous Substances in Electrical and Electronic Equipment) and 2012/19/EU WEEE (Waste Electrical and Electronic Equipment) environmental directives.



Used equipment must be collected separately, and disposed of properly. COMPANY has instigated a programme to manage the reuse, recycling, and recovery of waste in an environmentally safe manner using processes that comply with the WEEE Directive.

Battery Disposal - This product may contain a battery. Batteries must be disposed of properly, and may not be disposed of as unsorted municipal waste within the European Union. See the product documentation for specific battery information. Batteries are marked with a symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point.



EU DECLARATION OF CONFORMITY

Equipment	RipEX, RipEX2 RAy2, RAY3 M!DGE, M!DGE2 MRxxx, MDxxx
Manufacturer	RACOM s.r.o. Mirova 1283, 592 31 Nove Mesto na Morave, Czech Republic

This declaration of conformity is issued under the sole responsibility of the manufacturer.

The equipment described above is in conformity with the Directive 2011/65/EU of the European Parliament and of the Council on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS), as amended by Directive (EU) 2015/863, and Directive 2012/19/EU of the European Parliament and of the Council on waste electrical and electronic equipment (WEEE).

RoHS Applicable Exemption: 7(b)

Compliance has been verified via internal design controls, supplier declarations and/or analytical test data.

Signed for and on behalf of the manufacturer:

Nove Mesto na Morave, 11th July 2019
Jiri Hruska, CEO


RACOM s.r.o. | Mirova 1283 | 592 31 Nove Mesto na Morave | Czech Republic
Tel.: +420 722 937 522 | E-mail: racom@racom.eu

www.racom.eu

ver. 1.0

Fig. 10.1: EU Declaration of Conformity RoHS, WEEE

10.3. EU Declaration of Conformity



The image shows a formal EU Declaration of Conformity document for a RACOM MIDGE 2 router. It includes the RACOM logo, a title bar, a table of equipment details, a statement of responsibility, a list of applicable standards, a signature, and contact information.

RACOM
www.racom.eu

EU DECLARATION OF CONFORMITY

Equipment Type	MIDGE MIDGE 2
Manufacturer	RACOM s.r.o. Mirova 1283, 592 31 Nove Mesto na Morave, Czech Republic

This declaration of conformity is issued under the sole responsibility of the manufacturer.

The radio equipment described above is in conformity with the Directive 2014/53/EU of the European Parliament and of the Council on the harmonisation of the laws of the Member States relating to the making available on the market of radio equipment and repealing Directive 1999/5/EC.

Harmonised standards used for demonstration of conformity:

Safety / Health (RED, article 3.1a)	EN 62368-1:2014 EN 62311:2008
EMC (RED, article 3.1b)	EN 55035:2017 EN 55032:2015 EN 61000-6-2:2016 EN 61000-6-3:2007+A1:2011+AC:2012 EN 301 489-1 V2.1.1 EN 301 489-3 V2.1.1 EN 301 489-7 V1.3.1 EN 301 489-17 V3.2.0 EN 301 489-24 V1.5.1 EN 301 489-52 V1.1.1
RF Spectrum (RED, article 3.2)	EN 300 328 V2.1.1 EN 301 511 V9.0.2 EN 301 908-1 V11.1.1 EN 301 908-2 V11.1.1 EN 301 908-13 V11.1.1

Signed for and on behalf of the manufacturer:

Nove Mesto na Morave, 29th of January 2019
Jiri Hruska, CEO

RACOM s.r.o. | Mirova 1283 | 592 31 Nove Mesto na Morave | Czech Republic
Tel.: +420 565 659 511 | E-mail: racom@racom.eu

www.racom.eu

ver. 1.2

Fig. 10.2: EU Declaration of Conformity

10.3.1. Simplified EU declaration of conformity

BG	С настоящото RACOM s.r.o. декларира, че този тип радиосъоръжение MIDGE 2 е в съответствие с Директива 2014/53/EC.
ES	Por la presente, RACOM s.r.o. declara que el tipo de equipo radioeléctrico MIDGE 2 es conforme con la Directiva 2014/53/UE.
CS	Tímto RACOM s.r.o. prohlašuje, že typ MIDGE 2 rádiového zařízení MIDGE 2 je v souladu se směrnicí 2014/53/EU.
DA	Hermed erklærer RACOM s.r.o., at radioudstyrstypen MIDGE 2 er i overensstemmelse med direktiv 2014/53/EU.
DE	Hiermit erklärt RACOM s.r.o., dass der Funkanlagentyp MIDGE 2 der Richtlinie 2014/53/EU entspricht.
ET	Käesolevaga deklareerib RACOM s.r.o., et käesolev raadioseadme tüüp MIDGE 2 vastab direktiivi 2014/53/EL nõuetele.
EL	Με την παρούσα ο/η RACOM s.r.o., δηλώνει ότι ο ραδιοεξοπλισμός MIDGE 2 πληροί την οδηγία 2014/53/EE.
EN	Hereby, RACOM s.r.o. declares that the radio equipment type MIDGE 2 is in compliance with Directive 2014/53/EU.
FR	Le soussigné, RACOM s.r.o., déclare que l'équipement radioélectrique du type MIDGE 2 est conforme à la directive 2014/53/UE.
HR	RACOM s.r.o. ovime izjavljuje da je radijska oprema tipa MIDGE 2 u skladu s Direktivom 2014/53/EU.
IT	Il fabbricante, RACOM s.r.o., dichiara che il tipo di apparecchiatura radio MIDGE 2 è conforme alla direttiva 2014/53/UE.
LV	Ar šo RACOM s.r.o. deklarē, ka radioiekārta MIDGE 2 atbilst Direktīvai 2014/53/ES.
LT	Aš, RACOM s.r.o., patvirtinu, kad radijo įrenginių tipas MIDGE 2 atitinka Direktyvą 2014/53/ES.
HU	RACOM s.r.o. igazolja, hogy a MIDGE 2 típusú rádióberendezés megfelel a 2014/53/EU irányelvnek.
MT	B'dan, RACOM s.r.o., niddikjara li dan it-tip ta' tagħmir tar-radju MIDGE 2 huwa konformi mad-Direttiva 2014/53/UE.
NL	Hierbij verklaar ik, RACOM s.r.o., dat het type radioapparatuur MIDGE 2 conform is met Richtlijn 2014/53/EU.
PL	RACOM s.r.o. niniejszym oświadcza, że typ urządzenia radiowego MIDGE 2 jest zgodny z dyrektywą 2014/53/UE.
PT	O(a) abaixo assinado(a) RACOM s.r.o. declara que o presente tipo de equipamento de rádio MIDGE 2 está em conformidade com a Diretiva 2014/53/UE.

- RO Prin prezenta, RACOM s.r.o. declară că tipul de echipamente radio MIDGE 2 este în conformitate cu Directiva 2014/53/UE.
- SK RACOM s.r.o. týmto vyhlasuje, že rádiové zariadenie typu MIDGE 2 je v súlade so smernicou 2014/53/EÚ.
- SL RACOM s.r.o. potrjuje, da je tip radijske opreme MIDGE 2 skladen z Direktivo 2014/53/EU.
- FI RACOM s.r.o. vakuuttaa, että radiolaitetyyppi MIDGE 2 on direktiivin 2014/53/EU mukainen.
- SV Härmed försäkrar RACOM s.r.o. att denna typ av radioutrustning MIDGE 2 överensstämmer med direktiv 2014/53/EU.

10.4. Country of Origin

...the broadest narrowband money can buy



Country of Origin Declaration

Manufacturer: RACOM s.r.o.
Address: Mirova 1283, 592 31 Nove Mesto na Morave, Czech Republic
VAT No: CZ46343423

We, the manufacturer, hereby declare that Country of Origin of the MG102i and MIDGE routers and its accessories is the Czech Republic, EU.

Part Number	Description
MG102i-L	dual SIM GPRS/EDGE/HSPA+/LTE router - 5Eth, RS232, 2DI, 2DO
MG102i-U	dual SIM GPRS/EDGE/UMTS/HSPA router - 5Eth, RS232, 2DI, 2DO
MG102i-2UW-G	dual module GPRS/EDGE/UMTS/HSPA router + WiFi + GPS
MG102_DINSET	DIN rail mounting accessories
MIDGE-UMTS	GPRS/EDGE/UMTS/HSPA router, 2Eth, RS232, 2DI, 2DO, DIN rail
MIDGE-LTE	GPRS/EDGE/HSPA/LTE router, 2Eth, RS232, 2DI, 2DO, DIN rail
MIDGE2	GPRS/EDGE/HSPA/LTE router, 2Eth, RS232, 2DI, 2DO, DIN rail

Nove Mesto na Morave, 1 of November 2018
 Jiri Hruska, CEO

RACOM s.r.o. • Mírová 1283 • 592 31 Nové Město na Moravě • Czech Republic
 Tel.: +420 565 659 511 • Fax: +420 565 659 512 • E-mail: racom@racom.eu

www.racom.eu

Fig. 10.3: Country of Origin declaration

10.5. Warranty

RACOM-supplied parts or equipment ("equipment") is covered by warranty for inherently faulty parts and workmanship for a warranty period as stated in the delivery documentation from the date of dispatch to the customer. The warranty does not cover custom modifications to software. During the warranty period RACOM shall, on its option, fit, repair or replace ("service") faulty equipment, always provided that malfunction has occurred during normal use, not due to improper use, whether deliberate or accidental, such as attempted repair or modification by any unauthorised person; nor due to the action of abnormal or extreme environmental conditions such as overvoltage, liquid immersion or lightning strike.

Any equipment subject to repair under warranty must be returned by prepaid freight to RACOM direct. The serviced equipment shall be returned by RACOM to the customer by prepaid freight. If circumstances do not permit the equipment to be returned to RACOM, then the customer is liable and agrees to reimburse RACOM for expenses incurred by RACOM during servicing the equipment on site. When equipment does not qualify for servicing under warranty, RACOM shall charge the customer and be reimbursed for costs incurred for parts and labour at prevailing rates.

This warranty agreement represents the full extent of the warranty cover provided by RACOM to the customer, as an agreement freely entered into by both parties.

RACOM warrants the equipment to function as described, without guaranteeing it as befitting customer intent or purpose. Under no circumstances shall RACOM's liability extend beyond the above, nor shall RACOM, its principals, servants or agents be liable for any consequential loss or damage caused directly or indirectly through the use, misuse, function or malfunction of the equipment, always subject to such statutory protection as may explicitly and unavoidably apply hereto.

Appendix A. Glossary

APN	Access Point Name / Access Point Node
CE	Conformity of equipment according to EU rules
CS	Coding Scheme
CSD	Circuit Switched Data
DHCP	Dynamic Host Configuration Protocol
DMZ	Demilitarized Zone
DNS	Domain Name System
EDGE	Enhanced Data Service for GSM Evolution
EMC	Electromagnetic compatibility
FTP	File Transfer Protocol
GPRS	General Packet Radio Service
GSM	Global System for Mobile communications
GUI	Graphical User Interface
HSCSD	High Speed Circuit Switched Data
HSDPA	High-Speed Downlink Packet Access
HSUPA	High-Speed Uplink Packet Access
HTML	Hypertext Markup Language
HW	Hardware
IP	Internet Protocol
IPsec	Internet Protocol Security
ISDN	Integrated Services Digital Network
ISP	Internet Service Provider
LAN	Local Area Network
NAPT	Network Address Port Translation
NAT	Network Address Translation
POP	Point of Presence
POP, POP3	Post Office Protocol, Version 3
PPP	Point to Point Protocol

RAS	Remote Access Service (Dial-in Networking PPP)
RoHS	Restriction of hazardous substances
SIM	Subscriber Identity Module
SW	Software
TCP	Transmission Control Protocol
TFTP	Trivial File Transfer Protocol
UDP	User Datagram Protocol
UMTS	Universal Mobile Telecommunications System
URL	Universal Resource Locator
VPN	Virtual Private Network
WEEE	Waste Electrical and Electronic Equipment environmental directives

Index

A

accessories, 24
antenna
 GSM/UMTS, 25
 mounting, 27
authentication, 141

B

basic setup, 26
brc
 COM, 52
bridges, 43

C

certificates, 153
CLI, 161
client
 e-mail, 115
COM
 protocols, 49
Command Line Interface, 161
configuration, 28
conformity, 180
connecting M!DGE, 25
connectors
 Antenna SMA, 12
 ETH RJ45, 13
 screw terminal, 15
 SIM, 15
 USB, 13

D

declaration of conformity, 180
digital I/O, 64-65
dimensions, 12
discovery, 129
dynamic DNS, 113

E

e-mail, 115
ethernet, 34
event manager, 116

F

F bracket, 24
factory reset, 147
features, 19
 key features, 7
file configuration, 145

firewall, 83

G

glossary, 185

H

home, 28

I

implementation notes, 11
indication LEDs, 18
installation, 27
interfaces, 29
IPsec, 92

K

keys, 153

L

LAN cable, 25
LED, 18
legal notice, 159
licensing, 158
logout, 160

M

menu
 firewall, 83
 home, 28
 interfaces, 29
 logout, 160
 routing, 69
 services, 102
 system, 138
 troubleshooting, 148
 VPN, 88
mobile, 39
modbus TCP, 130
modems, 39
mounting, 27

P

power supply, 27
 connect, 25
product
 Conformity, 180
 conformity
 EU, 181
protocols COM, 49
protocolserver, 49

R

redundancy, 129
reset, 147
RoHS and WEEE, 178
router, 7
routing, 69

S

safety instructions, 177
serial port, 45
server
 DHCP, 111
 dial-in, 101
 DNS proxy, 112
 PPTP, 97
 SSH/Telnet, 122
 web, 127-128
services, 102
SIM, 39
SIM card, 25
SMS, 119
SNMP agent, 123
software update, 143
specification, 19
standards, 8
start, 6
system, 138
 bootloader, 139
 leds, 139
 restart, 141
 settings, 138
 syslog, 138

T

technical specification, 19
terminalserver, 132
time®ion, 139
troubleshooting, 148, 175

U

update, 143
USB, 44

V

Virtualization, 140
voicegateway, 135
VPN, 88

W

WAN, 29
web configuration, 28

Revision History

Revision 1.0 1st version	2018-01-10
Revision 1.1 update fw 4.2.x.x	2018-04-12
Revision 1.2 GNSS	2019-06-10
Revision 1.3 update fw 4.3.x.x L2TP added	2019-08-02
Revision 1.4 Section 8.16 CLI-PHP modified	2019-08-13
Revision 1.5 <i>MIDGE2-SW-SERVER</i> details changed <i>Environmental Conditions</i> changed	2019-11-25